

## **Diesel injection system - naturally-aspirated engines 07**



Job No.

Survey - injection pumps	07.1 - 001
Survey -injectors	- 002
Explanation of injection pump type plate	- 003
Function - Injection system	- 010
Function - EGR	- 015
Testing, adjusting idle speed	- 100
Checking electronic idle speed control	- 103
Checking electronic idle speed control (ELR)	- 105
Checking, tuning engine	- 110
Checking start of delivery (Position sensor RIV-Method)	- 111
Checking start of delivery with digital tester (RIV-Method)	- 112
Establishing fuel consumption by road test	- 113
Adjusting start of delivery (position sensor RIV-method)	- 116
Adjusting start of delivery with digital tester (RIV-method)	- 117
Checking fuel pump	- 145
Checking fuel pressure (after checking fuel delivery capacity)	- 146
Testing vacuum shutoff for leaks	- 150
Checking vacuum pump	- 160
Testing and adjusting vacuum control valve for automatic transmission and EGR	- 170
Testing exhaust gas recirculation	- 195
Removal, installation of injection pump	- 200
Replacing delivery valve seal	- 210
Replacing vacuum unit	- 220
Replacing electromagnetic actuator	- 225
Removal and installation of injectors	- 230
Checking injectors	- 231
Reconditioning injectors	- 232
Removal, installation of fuel pump	- 235
Removal, installation of injection timing device	- 240
Reconditioning injection timing device	- 241
Replacing fuel filter	- 245
Electrical wiring diagrams	- 400
Vacuum diagrams	- 500

## 07.1-001 Survey - injection pumps

Engine	Injection pump Bosch designation	Part no.	Bosch combination number	Test values MB sheet Edition
--------	-------------------------------------	----------	--------------------------------	------------------------------------

### Standard basic version from start of production

602.91	PES 5 M 55 C 320 RS 153	602 070 05 01 <sup>1)</sup>	0 400 075 982 <sup>1)</sup>	2.5 e 1st edition
--------	-------------------------	-----------------------------	-----------------------------	-------------------

### Standard - as of 02/89

602.91	PES 5 M 55 C 320 RS 170	602 070 32 01 <sup>2)</sup>	0 400 075 953 <sup>2)</sup>	2.5 w 5 09/88
		<b>602 070 33 01<sup>2)</sup></b>	<b>0 400 075 952<sup>2)</sup></b>	<b>2.5 w 4 09/88</b>
		602 070 34 01 <sup>1)2)</sup>	0 400 075 951 <sup>1)2)</sup>	2.5 w 3 09/88

<sup>1)</sup> ELR - Electronic idle speed control

<sup>2)</sup> ADA - Atmospheric pressure-dependent full-load stop

### Production breakpoint: January 1989

Model	Engine	Engine end no. Manual transmission	Engine end no. Automatic transmission
201.126	602.911	<b>073017</b>	<b>014820</b>

Transfer pump Bosch designation FP'KG **24** M 150 is identical on all engines.

### Note

**An accurate check and adjustment of the injection pump is only possible on an injection pump calibrating test stand.**

## 07. 1-002 Survey - injectors

---

Engine		602.91
Injection nozzle	Bosch designation	DN 0 SD 265
	MB part no.	001 017 49 12
Injector holder	Bosch designation	KCA 30 S 44 KCA 27 S 55 <sup>1)</sup>
	Combination MB part no.	<del>002 017 26 21</del> 002 017 34 21 <sup>1)</sup>
Injection pressure or opening pressure in bar <sup>2)</sup>	with new injectors	115 – 125
	with used injectors at least	100


<sup>1)</sup> With inclined injection.

<sup>2)</sup> The difference of the injection pressure among injectors within the same engine may not be more than 5 bar gauge pressure.

## 07.1-003 Explanation of injection pump type plate

For example **PES 5 M 55 C 320 RS 158/1**

<b>P</b>	Pump
<b>E</b>	Self-driven
<b>S</b>	Front flange attachment
<b>5</b>	Number of cylinders
<b>M</b>	Pump size
<b>55</b>	Element diameter in 1/10 mm
<b>C</b>	Character of revision
<b>320</b>	Assembly number
<b>R</b>	Direction of rotation
<b>S158/1</b>	Special version




107-33288

### RSF- governor


<b>R</b>	Governor
<b>S</b>	Coil spring
<b>F</b>	Drive control

### Arrangement of components

1	Injection pump
1b	Type plate
2	Governor
3	Fuel pump
4	Vacuum unit idle speed Increase
5	ADA unit
6	Stop unit
65	Vacuum control valve
Y22	Electromagnetic actuator ELR



P07-2409-13



P07-2383-13

## 07.1-010 Function - injection system

---


### A. Lubrication of injection pump

The injection pump is connected to the engine oil circuit by way of an oil hole (arrow).

The oil returns to the crankcase by way of the circular groove (x) between bearing and housing.


The O-ring (10) on the flange (1a) seals.

The hole (y) serves to reduce the load exerted by the oil on the radial sealing ring.



## B. Fuel circuit


### a) Fuel circuit diagram



P07-0496-57

3	Injection pump	73a	Choke orifice in fuel filter upper part 0.8 mm diameter
15	Fuel pump	86	Fuel thermostat open, position up to + 8 °C, fuel is preheated
30	Overflow valve with choke dia. 1.5 mm	86a	Fuel thermostat closed, as of + 25 °C, fuel is no longer preheated
43	Injection nozzles	87	Supply line - cold fuel
50	Fuel prefilter	87a	Return line - preheated fuel
54	Leak-off fuel hose	148	Heater supply pipe with fuel heat exchanger
63	Injection line cylinder 1		
73	Fuel tank		
	Fuel filter upper part		

b) Low-pressure side




P07-0495-57

3	Injection pump	79	Banjo fitting
15	Fuel pump	80	Return line
27	Over-flow valve with choke dia. 1.5 mm	81	Hose return
42	Hollow screw	82	Supply fuel filter
43	Fuel filter	83	Supply injection pump
44	Fuel prefilter	84	Hose clamp
50	Fuel filter	86	Fuel thermostat
51	Leak-off fuel hose	87	Supply line fuel heat exchanger
52	Hose clamp	87a	Return line fuel heat exchanger
73	Screw plug	88	Supply fuel thermostat
74	Fuel filter upper part	89	Suctionline fuel pump
74	Hollow screw fuel filter	131	Fuel holder
76	O-ring	148	Heater supply pipe with fuel heat exchanger
77	Seal fuel filter		
78	Sealing ring		



c) High-pressure side



- 30 Injection pump
- 52 Injection nozzle complete
- 53 Screw plug
- 53 Nozzle plate
- 54 Injection line 1
- 55 Injection line 2
- 56 Injection line 3
- 57 Injection line 4
- 58 Injection line 5
- 59 Injection line 6

- 64 Holder, cylinder 4, nozzle side
- 64a Holder, cylinder 4, pump side
- 64b Screw
- 66 Holder, lines
- 68 Plastic clip
- 68a Plastic clip
- 69 Rubber backing
- 70 Plastic holder for 3 lines
- 71 Plastic holder for 2 lines


**Note**

Injection line cylinders 2 - 6 not shown in the figure.  
 Injection line cylinders 5 - 6 holders as of cylinder 4.

### C. Fuel prefilter (43)

Installed in the suction line ahead of the fuel pump (3). The filter housing is made of transparent plastic material.

The mesh size is 0.6 mm (600  $\mu\text{m}$ ).



### D. Fuel filter (42)


Installed in the delivery line between fuel pump and injection pump.

The paper filter element is integrated in a metal housing. The paper element has a mean pore size of 0.006-0.01 mm (6-10  $\mu\text{m}$ ).

- |    |                         |
|----|-------------------------|
| 42 | Filter                  |
| 73 | Fuel filter upper part  |
| 74 | Screw                   |
| 76 | O-ring                  |
| 77 | Sealing ring (aluminum) |

#### Note

Owing to the greater delivery capacity of the fuel pump and the chokes in the filter upper part and on the injection pump the fuel system is bled automatically during starting.




## E. Fuel preheating (148)

A heat exchanger (148) for preheating the fuel is installed in the supply line of the heating system.

Heat exchanger

- C Supply
- D Return
- E Heater supply
- 148 Heat exchanger



### Function

Full preheating up to + 8 °C fuel temperature; the required fuel is drawn via the heat exchanger by the fuel pump.


From + 8 °C to + 25 °C mixed operation; the required fuel flows partially via the heat exchanger.


Above + 25 °C the heat exchanger is by-passed by the thermostat action: the fuel pump draws the fuel directly.

The fuel preheating allows trouble-free operation with winter diesel fuel usually up to approx. -25 °C outside temperature.

Fuel thermostat

- A Supply from fuel tank
- B Suction line to fuel pump
- C Supply to heat exchanger
- D Return from heat exchanger





Function diagram fuel preheating


1	Injection pump	54	Injection line cylinder 1
3	Fuel pump	63	Fuel tank
15	Overflow valve with choke 1.5 mm dia.	73	Fuel filter upper part
30	Nozzle holder combination	73a	Choke orifice in fuel filter upper part
42	Fuel filter	86	Fuel thermostat up to + 8 °C
42a	Choke orifice in fuel filter upper part 0.8 mm diameter	86a	Fuel thermostat above + 25 °C
43	Fuel prefilter	87	Supply line (cold fuel)
50	Fuel bleed hose	87a	Return line (preheated fuel)
		148	Fuel heat exchanger

## F. Fuel pump

The increased delivery capacity of the fuel pump ensures that the fuel system is bled automatically. The manual priming pump is no longer required.

Rate of delivery  $> 150 \text{ cm}^3/30 \text{ s}$ , with starter speed  $> 150/\text{min}$ , in fuel return.


E Suction side  
D Delivery side



A choke in the overflow valve on the injection pump is required for bleeding the injection pump


Overflow valve with choke dia. 1.5 mm (arrow).

The overflow valve prevents unfiltered fuel from reaching the injection pump via the return line if the supply is clogged (e.g. filter).




Choke with overflow valve

a Housing  
b Ball  
c Spring  
d Plunger  
e Supply  
f Choke orifice dia. 1.5 mm




## G. Start of delivery adjusting device

An adjusting device (arrow) is provided on the injection pump flange in order to allow adjustment of start of delivery with the engine running.




## H. Relief chokes in delivery valve holder

In order to reduce the hydrocarbon content in the exhaust gas, relief chokes (7b) are installed in the delivery valve holders (7) of the injection pump. The delivery valve holders with relief choke are identified externally by one or two circular grooves (arrows). The relief choke (7b) is a plate valve (7c) with a choke orifice opening in the direction of the injector. The choke orifice for all engines is 0.45 mm diameter. The valve seat (7d) is riveted into the delivery valve holder.




- 7 Delivery valve holder connection
- 7a Spring
- 7b Relief choke
- 7c Plate valve
- 7d Valve seat
- 7e Delivery valve holder
- 7f Seal
- 7g Delivery valve




## I. Injection timing device

The timing device is mounted on the injection pump shaft and secured with a left-hand threaded center bolt.



Timing device advance curve

$n$  = 1 /min injection pump  
 $PW^\circ$  = Advance angle injection pump




## J. RSF governor, construction and mode of operation

The governor is an idle speed/maximum speed governor whose control spring (2m) is dimensioned and adjusted such that, with the exception of torque control (see "Speed regulation during starting and full-load operation"), it does not regulate in the part load range.


In the part load and full-load ranges the control rod (2t) of the injection pump is only actuated by the accelerator pedal which is connected with the adjusting lever (2g) of the governor by way of the control linkage.

The vacuum unit (4) serves to preload the idle speed spring (2n) and adjust the idle speed.






- 2 Governor
- 2a Guide lever
- 2b Stop screw for idle speed volume
- 2c Reverse-transfer lever
- 2d Fulcrum lever
- 2e Spring capsule (torque control)
- 2f Full-load adjusting screw
- 2g Control lever
- 2h Sliding sleeve
- 2i Flyweights (pump governor assembly)
- 2j Idle speed auxiliary spring shut-off
- 2k Adjusting screw for idle speed auxiliary spring (tickler)
- 2l Tension lever
- 2m Governor spring
- 2n Idle speed spring
- 2o Idle speed auxiliary spring (tickler)
- 2p Control lever
- 2r Stop lever
- 2s Emergency stop lever
- 2t Control rod
- 4 Vacuum unit idle speed increase
- 4a Idle speed adjusting nut
- 6 Vacuum unit (stop)



### a) Idle speed regulation

The adjusting lever (2g) contacts the idle speed stop screw (2b). With increasing speed the sliding sleeve (2h) passes through the idle speed stage. The guide lever (2a) pivots around the fulcrum "A" in this way acting against the idle speed spring (2n).



- a Start
- b stop
- c Idle speed stage

P07-0498-15

At a certain engine speed (approx. 600/min) the guide lever (2a) contacts the adjusting nut of the idle speed auxiliary spring (20). The movement of the sliding sleeve (2h) is transferred to the injection pump control rod in the same direction via the reverse-transfer lever (2c) and the control lever (2d). After passing through the idle speed stage the sliding sleeve (2h) contacts the spring capsule (2e).


If the engine speed continues to rise (e.g. while coasting), the spring capsule (2e) and then the governor spring (2m) are overcome at a certain speed. The control rod is then moved into "stop position" (deceleration shut-off).

## b) Speed regulation with electromagnetic actuator

The stroke rod (163) contacts the guide lever (2a). The electromagnetic actuator (Y22) is supplied with a timed DC voltage in the frequency range of approx. 50 Hz from the control unit (electronic idle speed control).

If the engine speed drops (e.g. when engaging the driving position or power steering at the end limit), the electromagnetic actuator is given a higher voltage. As a result the stroke rod (163) will push against the guide lever (2a) and the control rod (2t) moves in the direction "a" **more volume**.

- 161 Sealing ring
- 162 Electrical connection
- 163 Stroke rod
- 164 Magnetic coil
- 165 Magnetic core




As soon as the engine speed rises, the voltage is reduced and the control rod (2t) moves in the direction "b" **less volume**.

### c) Start position

If, with the engine stationary, the control lever (2g) contacts the full-load stop (c), the reverse-transfer lever (2c) pivots around the fulcrum "B", taking with it the fulcrum lever (2d) in the direction of start.

With the control lever (2g "full throttle") in full-load position the idle speed auxiliary spring (2o, tickler) is pushed off the guide lever by the idle speed auxiliary spring shut-off (2j). This allows faster speed regulation from the starting position of the governor.

a Start  
b Stop




### d) Maximum speed regulation/torque control

After passing through the idle speed stage (c) (see figure regulation at idle speed) the sliding sleeve (2h) contacts the spring capsule (2e). In this way the control rod of the injection pump is brought into full-load position via the reverse-transfer lever (2c) and the fulcrum lever (2d).

When a certain speed has been reached, the spring capsule (2e) is pushed on by a specified distance (d) (torque control).

If the speed of the engine rises again, the force of the flyweights is sufficient to overcome the control spring (2m) (maximum speed regulation).


The start of the speed regulation is dependent on the preload of the governor spring (2m).



### e) Shut off

The vacuum unit (6) is connected to vacuum from the vacuum pump via the glow starter switch of the vehicle. As a result, the diaphragm of the vacuum unit is pulled against the compression spring.

The vacuum unit (6) is connected with a stop lever (2r). This lever pivots around the fulcrum "D" pulling the control rod of the injection pump into the "stop position". The bypass spring of the fulcrum lever is overcome in this process. Via the emergency stop lever (2s) the control rod can likewise be pulled into "stop position" on the outside of the governor.



a Star-t  
b Stop

## K. Atmospheric pressure-dependent full-load stop (ADA)


The atmospheric pressure-dependent full-load stop serves to correct the low air density at higher altitudes.

Mode of operation with a **reduction of pressure** with Increasing altitude. With diminishing pressure the aneroid boxes (103b) expand, pushing the ADA correction linkage (103c) in direction (c). The ADA guide pin (5b) continues to push the ADA correction linkage (103c) in the direction of (c), pivoting the ADA template (5c) in the direction of (d).

With the ADA template the toggle lever (5c) and the reverse-transfer lever (5d) pivot in the directions of (e) and (d). The reverse-transfer lever now pulls the control rod (2t) in stop direction (b) via the fulcrum lever (2d).

In this way the pressure drop causes a reduction of the full-load volume.


A **pressure rise** results in the process taking place in reverse order.



The atmospheric pressure-dependent full-load stop consists of aneroid boxes vertically installed in a housing, and which have been adjusted to a certain barometric level by means of an adjusting screw and counteracting spring-loaded threaded pin. Within the operating range of the aneroid boxes an expansion takes place with decreasing air pressure. The spring-loaded threaded pin on the lower side of the aneroid boxes and the connected levers transmit the changes in altitude to the control rod of the injection pump.

If the aneroid boxes expand, the control rod is pulled in the direction of “stop” and the delivery volume is reduced; if the altitude decreases, the control rod is moved into the direction of “additional volume”, resulting in an increase of the delivery volume.

- 5c Template
- 103 Pressure box
- 103a Connecton for atmospheric connection line (for registering atmospheric pressure)
- 103b Aneroid boxes
- 103c Correction linkage
- 103d Adjusting screw (adjusted by manufacturer)




## L. Governor impulse method (RIV)

In order to be able to register the relationship of the injection pump relative to the engine two signals are required:

- TDC impulse from the crankshaft
- Governor impulse from the injection pump

Both impulses are supplied by pulse generators. In order to obtain a measuring signal the sensor pins must be moved past the pulse generators with a minimum speed (idle speed). A measuring instrument measures the time interval of the two impulses, converting the result into an angular value which is then indicated.

Checking, adjusting start of delivery  
(see 07.1-I 11/112/116/117).



P07-0453-57

- 001 Digital tester
- 015 Test cable
- 016 Socket
- 017 RIV generator (governor impulse)
- 021 TDC pulse generator
- 059 Sensor pin
- 2 Governor
- 2i Flyweight with sensor pin

## **M. Electronic idle speed control (ELR)**

In addition to the mechanical governor an electronic idle speed governor is installed in engine 602 with air conditioner and automatic transmission.


The speed sensor (L 3) registers the engine speed (144 impulses/revolution) passing it on to the control unit (N8 or N8/1) in form of an AC voltage.

The control unit processes the speed signal and compares set value with actual value. The idle speed is kept constant by the electromagnetic actuator (Y22) independent of the load on the engine.

initiated by the temperature sensor (B 1 1/1), with coolant temperatures  $< 60\text{ }^{\circ}\text{C}$  the idle speed set value is increased according to a predetermined characteristic.



## Block diagram idle speed control



### System diagnosis (as of approx. June 1988)\*

With the self-testing program integrated in the control unit it is possible to test the ELR system.

A signal can be called up by way of the test coupling (X92) giving specific information on faults of a component.


However, only permanent faults can be indicated. Faults of a temporary nature cannot be registered and indicated by the control unit.

The number of signals shows which component is faulty, or whether components in the control circuit are defective.

Impulse display	Component/Control circuit
1	All functions "in order"
2	Speed signal "fault"
3	Coolant temperature "fault"
6	Control circuit ELR "fault"

## Arrangement of components

### Electrical components



P07-0011-61

B11/1 Coolant temperature sensor  
 K1/1 Overvoltage protection relay  
 L3 Speed sensor  
 L3x Connector speed sensor starter ring gear


N8 or N8/1 Control unit ELR  
 x92 Test coupling  
 Y22 ELR electromagnetic actuator

## N. Injection Nozzles

### b) Hole-type pintle nozzle

#### Bosch designation DN 0 SD 240/

This nozzle is distinguished from the pintle nozzle by transverse and longitudinal bores (46 and 47) in the throttling pintle.



- 31 Nozzle needle
- 32 Nozzle body
- 46 Transverse bore
- 47 Longitudinal bore

## Q. Nozzle holder

Bosch designation

KCA 30 S 44 (without edge-type filter)

(vertical injection)

KCA 30 S 46 (with edge-type filter)


(vertical injection)

KCA 27 S 55

(inclined injection)

The compression spring (36) in the holding body (37) presses on the nozzle needle (31) via thrust pin (34). The preload of the compression spring (36) and the shim (40) determine the opening pressure of the injection nozzle. The injection pressure can be adjusted by means of different shim thickness dimensions. Fuel flows to the nozzle seat via the respective supply bore (a) in the holding body (37), intermediate washer (33) and injection nozzle. During the injection process the injection pressure lifts the nozzle needle and the fuel flows through the circular groove on the throttling pintle into the prechamber.

After the injection pressure has dropped, the compression spring (36) forces the nozzle needle (31) back onto its seat; the injection process is completed.




Nozzle holder for vertical injection

### 5° inclined injection

Engine 602 model years 1987 and 1988

The nozzle holder combination is screwed into the upper prechamber with an inclination of 5° with reference to the prechamber longitudinal axis. The inclined injection results in an even more intensive mixing of air with fuel.

- 70 Cylinder head
- 71 Cylinder head gasket
- 109 Sealing sleeve
- 110 Prechamber
- 112 Threaded ring
- 113 Sealing plate
- 114 Nozzle holder



### 5°/180° inclined injection

**Production breakpoint:** Standard version January 1989

Model	Engine	Engine end no.	
		Manual transmission	Automatic transmission
201.126	602.911		014820


Engine 602 and Code 830 as of model year 1989

The nozzle holder combination inclined by 5° is twisted by 180° and installed into the upper prechamber.

This has the following advantages:


- Improved cold starting
- Improved mixing of air and fuel due to shortened glow plug (23 mm previously 27 mm) in connection with recess and spherical indentation in the ball pin.
- Particle reduction and improvement in the emission of hydrocarbons and carbon monoxide.

R9 Glow plug  
109 Sealing sleeve  
110 Prechamber  
112 Threaded ring  
113 Nozzle plate  
114 Nozzle holder combination



- 31 Nozzle needle
- 32 Nozzle body
- 33 Intermediate washer
- 34 Thrust pin
- 35 Nozzle mounting nut
- 36 Compression spring
- 37 Holding body
- 38 Fuel bleed connection
- 40 Shim
- 45 Supply bore
- a Fuel supply
- b Leak-off fuel (return)

Nozzle holder for inclined injection




## O. Injection lines

The injection lines are so designed that the injection pump can be pivoted with the engine running.


### Note

Due to vibration the plastic clips 68 and 68a must be mounted as closely as possible to the radius of the injection lines (arrows). The plastic clips (71) must be fully engaged.



## P. Vacuum shut-off with vehicle key (glow starter switch)


The vacuum for the key shut-off has been supplied by the check valve (140) of the main vacuum line since July 1987.



### Production breakpoint: July 1987

Model	Engine	Vehicle identification end no.	
		A	F
201.126	602.911	384857	383987






P07-051 I-53

Vacuum line routing

- |     |                              |   |                  |
|-----|------------------------------|---|------------------|
| 1   | Injection pump               | A | Partition panel  |
| 6   | Vacuum unit (stop)           | c | Remaining users  |
| 61c | Valve glow starter switch    | e | To brake booster |
| 67  | Vacuum pump                  |   |                  |
| 140 | Check valve/main vacuum line |   |                  |

Key shut-off version prior to July 1987




1073 - 11 505/1

Function diagram

- |     |                                      |    |                  |
|-----|--------------------------------------|----|------------------|
| 1   | Injection pump                       | A  | Partition panel  |
| 6   | Vacuum unit (stop)                   | c  | Remaining users  |
| 61b | Choke 0.5 mm orifice diameter        | e  | To brake booster |
| 61c | Valve glow starter switch            | bl | blue             |
| 61d | Cam glow starter switch (valve open) | br | brown            |
| 67  | Vacuum pump                          |    |                  |


## 07.1-015 Function exhaust gas recirculation

Model 201.126 is equipped with an electronically-controlled exhaust gas recirculation system as of model year 1986.




Engine 602 in model 201  
as of model year 1986 1 st version  
Function diagram exhaust gas recirculation

2	Injection pump	B6	Hall-effect speed sensor
6	Governor	B11/1	Coolant temperature sensor
5	ADA unit	L3	Speed sensor starter ring gear
6	Vacuum unit (stop)	N6	Compressor shut-off control unit
61a	Choke, blue	N8	Idle speed control unit
61b	Choke, orange	N37	Control unit exhaust gas recirculation
62	Filter	S25/5	Temperature switch 105/115 °C
65	Vacuum control valve	S25/6	Temperature switch 50 °C
67	Vacuum pump	S25/7	Temperature switch 25 °C EGR
72	Damper	S25/9	Temperature switch 97 °C EGR
94	Air guide housing	S27/6	Microswitch compressor shut-off/EGR
100	Vacuum unit/vacuum control flap	Y22	Electromagnetic actuator ELR
105	Intake pipe	Y27	Switchover valve EGR
110	Exhaust manifold	Y28	Switchover valve vacuum control flap
120	Exhaust gas recirculationline	Y29	Switchover valve (automatic transmission)
136	Starter ring gear		



Engine 602 in model 201  
as of model year 1986 2nd version  
Function diagram exhaust gas recirculation

2	Injection pump	B6	Hall-effect speed sensor
5	Governor	B11/1	Coolant temperature sensor
6	ADA unit	L3	Speed sensor starter ring gear
61a	Vacuum unit (stop)	N6	Compressor shut-off control unit
61b	Choke, blue	N8	Idle speed control unit
62	Choke, orange	N37	Control unit exhaust gas recirculation
65	Filter	S25/5	Temperature switch 105/115 °C
67	Vacuum control valve	S25/6	Temperature switch 50 °C
72	Vacuum pump	S25/7	Temperature switch 25 °C EGR
94	Damper	S25/9	Temperature switch 97 °C EGR
100	Air guide housing	S27/6	Microswitch compressor shut-off/
105	Vacuum unit/vacuum control flap	Y22	Electromagnetic actuator ELR
110	Intake pipe	Y27	Swrtchover valve EGR
120	Exhaust manifold	Y28	Swrtchover valve vacuum control flap
136	Exhaust gas recirculation line	Y29	Swrtchover valve (automatic transmission)
	Starter ring gear		




1072 1332814

Engine 602 in model 201  
 model year 1989  
 Function diagram exhaust gas recirculation

- |     |                                 |               |  |
|-----|---------------------------------|---------------|--|
| 1   | Injection pump                  | <b>B1 I/I</b> | Coolant temperature sensor                                     |
| 2   | Governor                        | <b>B11/7</b>  | Climate temperature sensor                                     |
| 5   | ADA unit                        | <b>L3</b>     | Speed sensor starter ring gear                                 |
| 6   | Vacuum unit (stop)              | <b>N6</b>     | Compressor shut-off control unit                               |
| 60  | Exhaust gas recirculation valve | <b>N8</b>     | Idle speed control unit  |
| 61a | Choke, blue                     | <b>N37/2</b>  | Control unit exhaust gas recirculation                         |
| 61b | Choke                           | <b>S25/5</b>  | Temperature switch 105/1 15 °C                                 |
| 62  | Filter                          | <b>S25/6</b>  | Temperature switch 50 °C                                       |
| 65  | Vacuum control valve            | <b>S25/7</b>  | Temperature switch 25 °C <b>EGR</b>                            |
| 67  | Vacuum pump                     | <b>S25/9</b>  | Temperature switch 97 °C <b>EGR</b>                            |
| 72  | Damper                          | <b>S27/6</b>  | Microswitch compressor shut-off/                               |
| 94  | Air guide housing               | <b>Y22</b>    | Electromagnetic actuator ELR                                   |
| 100 | Vacuum unit/vacuum control flap | <b>Y27</b>    | Switchover valve EGR   |
| 105 | Intake pipe                     | <b>Y28</b>    | Switchover valve vacuum control flap                           |
| 110 | Exhaust manifold                | <b>Y29</b>    | Switchover valve (automatic transmission)                      |
| 120 | Exhaust gas recirculation line  | <b>a</b>      | Ventilation to vehicle interior                                |
| 123 | Vacuum amplifier                | <b>c</b>      | Remaining users  |
| 136 | Starter ring gear               | <b>d</b>      | Vacuum unit automatic transmission                             |
|     |                                 |               | Vacuum connections on vacuum amplifier                         |
|     |                                 | <b>VAC</b>    | • Vacuum from vacuum pump                                      |
|     |                                 | <b>v c v</b>  | • To vacuum control valve                                      |
|     |                                 | <b>ATM</b>    | • Ventilation to vehicle interior                              |
|     |                                 | <b>EGR</b>    | • Exhaust gas recirculation to exhaust gas recirculation valve |

## B. Components and function

### Electrical components




P 07-0432-5

L3 Starter ring gear speed sensor  
 L3x Connector starter ring gear speed sensor  
 N37/2 Control unit exhaust gas recirculation

S25/1 Temperature switch 100 °C  
 S25/7 Temperature switch 25 °C  
 S25/9 Temperature switch 97 °C  
 S27/6 Microswitch compressor shut-off/EGR

Pneumatic components



5 ADA unit  
 60 EGR valve  
 65 Vacuum control valve

100 Vacuum unit vacuum control flap  
 123 Vacuum amplifier  
 Y27 Switchover valve exhaust gas recirculation  
 Y28 Switchover valve vacuum control flap


## C. Overall function

### Vacuum control valve (65)

The vacuum control valve is attached to the injection pump and connected to the control lever by means of a driver. Using available vacuum supply (central connection) it modulates decreasing pressure with increasing load according to a characteristic map.

The vacuum control valves have a different characteristic depending on the engine and transmission design. They are identified by differently colored sealing caps and must not be interchanged (see 07. I-I 70).

- 65 Vacuum control valve
- A Control line
- B Suction line




### Vacuum amplifier (123)

(only with automatic transmission)


Attached to the unit wall.

The pressure modulated by the vacuum control valve is converted in the vacuum amplifier (123) for use in the exhaust gas recirculation system. By way of the switchover valves (Y27 and Y28) the exhaust gas recirculation valve and the vacuum control flap are activated.



### Air guide housing with vacuum control flap (99)

A pneumatically actuated vacuum control flap (99) is provided in the air guide housing in order to increase the vacuum in the intake pipe. During engine operation with exhaust gas recirculation the vacuum control flap closes off the fresh air duct.



A minimum opening (arrow) between the vacuum control flap (99) and the air guide housing is maintained in a closed condition.


### Note

The linkage on the vacuum unit for the vacuum control flap (99) may not be actuated manually.

### Mechanical pressure control flap (99) with pneumatic control group, temperature-dependent > 40 °C


The exhaust gas recirculation is optimised by a mechanical actuation of the pressure control flap (99), thus improving the degree of the exhaust gas recirculation rate.

The pressure control flap (99) is always approximately 35° open in its initial setting (at idle speed).






When the coolant temperatures are  $> 40\text{ }^{\circ}\text{C}$  between  $1000 \pm 50/\text{min}$  and  $2500 \pm 50/\text{min}$  the pressure control flap is pneumatically closed via the thermovalve (180) and is opened again mechanically via the accelerator depending on the load condition.  
The pressure control flap is open at full throttle.




It became necessary to introduce a connecting rod (200) at the vacuum unit for the pressure control flap (due to the mechanical actuation of the pressure control valve (99)).



### Exhaust gas recirculation valve


The exhaust gas recirculation valve is screwed into the side of the cylinder head. It is connected with the exhaust and the intake manifolds by way of the exhaust gas recirculation line.

The exhaust gas recirculation valve is activated by the modulated vacuum from the vacuum control valve and opens depending on the load condition.




### Control unit (N37 and N37/2)

This is installed behind the battery. Battery voltage is available on the control unit EGR (N37 or N37/2) after the ignition has been switched on. Minimum working voltage approx. 11 v.




### Electrical switchover valve (Y27)

This admits vacuum for the exhaust gas recirculation in certain operating conditions. The activation is by way of the control unit EGR (N37 or N37/2) as a function of coolant temperature and engine speed as well as speed and load-dependent on the microswitch (only with manual 5-speed transmission).



### Electrical switchover valve (Y28)

This admits the vacuum for the vacuum control flap under certain operating conditions. The activation is by way of the control unit EGR (N37 or N37/2) as a function of coolant temperature and engine speed as well as dependent on speed and load via the microswitch (S27 4).




### Microswitch (S27/6)

Microswitch I

Switches off the exhaust gas recirculation and the AC compressor before full load (A/C compressor only if climate comfort control is operative).


Microswitch II

Switches off the vacuum control flap before reaching full load.



### Coolant temperature switch 97° and 100 °C (S25/1, S25/4, S25/9)


For thermal protection of the engine the temperature switch switches off the exhaust gas recirculation via the control unit EGR (N37 or N37/2) from a coolant temperature of approx 100 °C.



Model 201 Engine 602

### Starter ring gear speed sensor (L3)


This is attached to the flange of the transmission. The speed sensor (L3) consists of a magnetic core and a coil. It registers the engine speed, passing it on to the control unit EGR (N37 or. N37 2) in form of an AC voltage.



### #all-effect speed sensor (B6)

(only with manual transmission)

The vehicle speed is taken off the speedometer by the Hall-effect speed sensor (arrow). At a speed above 87 km/h the exhaust gas recirculation is switched off by the control unit.



## D. Overall function

### Exhaust gas recirculation

Exhaust gas recirculation is effective if the following requirements have been met:

- **Engine speed**
  - between  $1200 \pm 50$ /min and  $2950 \pm 50$ /min for model years 1986 through 1988.
  - between  $1000 \pm 50$ /min and  $2950 \pm 50$ /min for model year 1989.
- **Coolant temperature** between  $25\text{ }^{\circ}\text{C}$  and  $97\text{ }^{\circ}\text{C}$  engine 602.
- **Speed** below 85 km/h approx. 56 mph, (M.Y. 1986-8), approx. 53 mph (M.Y. 1989) only manual 5-speed transmission.

- **Accelerator pedal not in full load position**  
as the EGR valve is closed via the microswitch just before full throttle position.
- **Vacuum control flap** between 1000  $\pm$ 50/min and 2500  $\pm$ 50/min closed.

The control unit EGR (N37 or N37 2) registers the following input signals

- Engine speed
- Speed (only manual 5-speed transmission)
- Temperature
- Load (accelerator pedal position)


It sends a voltage signal to the switchover valves (Y27) and (Y28). Supply vacuum is available on the vacuum control valve (65) and the vacuum amplifier (123). The vacuum control valve (65) passes a modulated vacuum on to the vacuum amplifier (123). The transducer regulates the vacuum from the vacuum control valve according to the load condition. This controlled vacuum is then used to activate the EGR valve and the vacuum control flap. The vacuum control flap is closed from 1000  $\pm$ 50/min to 2500  $\pm$ 50 min which increases the exhaust gas recirculating rate.

**Note**

The vacuum amplifier is not installed in vehicles with manual transmission. The exhaust gas recirculation valve and the vacuum control flap are activated directly by the vacuum control valve.


From model year 1990 mechanical pressure control flap (99) with pneumatic control unit, temperature dependent via thermo valve > 40 °C.

### Block diagram exhaust gas recirculation





## 07.1-100 Testing, adjusting idle speed




Digital tester (001) and pulse generator (021) . . .	connect, disconnect..
Control . . . . .	check for easy operation.
Idle speed stop on Bowden cable . . . . .	check, spring retainer (226) must contact the compression spring (227) without preload.
Bring engine to . . . . .	60-80 °C coolant temperature.
Double coupling of electromagnetic actuator (Y22) . . . . .	pull off, refit.
Idle speed . . . . .	check, adjust.
Smooth engine operation . . . . .	check by switching on all additional units.



## Test and adjusting values

Engine	Idle speed 1/min Electronic idle speed control (ELR)	
	with control	without control Plug on electromagnetic actuator pulled off
602	680 ± 20	620 ± 40

## Special tools



## Commercially available tools


Digital tester

e.g. Bosch, MOT 002.01  
Sun, DIT 9000


## Adjusting

- 1 Connect digital tester (001) and pulse generator (020).
- 2 Check control for easy operation and condition.


Check idle speed stop; in idle speed position the spring retainer (226) of the Bowden cable (230) must contact the compression spring (227) without preload.



Adjust adjusting nut (232) of Bowden cable (230) from the vehicle inside if required.




3 Run engine up to 60-80 °C coolant temperature.




**Engine 602 with electronic idle speed control**

4 Pull double coupling off electromagnetic actuator.



- 5 Loosen lock nut (arrow) and adjust idle speed  
left = higher speed  
right = lower speed

Test values see table Test and adjusting values




- 6 Switch on all additional equipment and ensure engine operates smoothly.

## 07.1-103 Checking electronic idle speed control

### Engines without test coupling (X92)

(Engines with test coupling (X92) see 07.14.05 Checking ELR).






Digital tester (001) and pulse generator (021)	connect, disconnect.
Control	check for easy operation.
Idle speed stop on Bowden cable (230)	check, the spring retainer (226) must contact the compression spring (227) without preload.
Overvoltage protection (K1 or K1 /1) and fuse	check, measure voltage between jacks 9 and 11 of the control unit coupling, set value approx. 12 V.
Engine	run to 60-80 °C coolant temperature.
Pull double coupling off electromagnetic actuator (Y22) and refit (at least for 3 s)	engine speed increases briefly.

Adjusting basic idle speed on injection pump ....	pull plug of electromagnetic actuator (Y22).
Speed sensor (L3) on coupling (L3x) .....	check, resistance 0.4-2.5 k $\Omega$ , engine at idle speed voltage > 4 V AC.
Coolant temperature sensor (B1 1 /1) .....	check, set value + 20 °C 2.2 - 2.8 k $\Omega$ .
Electrical activation of the electromagnetic actuator (Y22) .....	check, engine idling, set value approx. 12 V.

### Test and adjusting values

Engine	Idle speed 1/min Electronic idle speed control (ELR)	
	with control	without control Plug pulled off electrom. actuator
602.911	680 $\pm$ 20	620 $\pm$ 40

### Special tools



### Commercially available tools

Multimeter

e.g. Sun, DMM-5

Digital tester

e.g. Bosch, MOT 002.01  
Sun, DIT 9000

### Note

Electrical wiring diagrams see  
job no. 07.1-400.

## Testing jobs


Connect digital tester (001) and pulse generator (021).

Check control for easy operation and condition.

Check idle speed stop on Bowden cable (230).

The spring retainer (226) of the Bowden cable (230) in idle speed position must contact the compression spring (227) without preload.

Run engine to 60-80 °C coolant temperature.



## Checking overvoltage protection (K1 or K1/1)

Switch on ignition, pull off control unit (N8 or N8/1) and check voltage between the jacks (9 and 11).

**Display:** approx. = 12 V


Yes

No


Check fuse on overvoltage protection.  
Check activation according to electrical wiring diagram.

End of test

**N8**




**N8/1**




## Function check

Engine idling. Pull double coupling (arrow) off ELR electromagnetic actuator (Y22) for at least 3 sec. and refit. Engine speed increases briefly.	
Yes	No



Briefly apply battery voltage (approx. 12 V) to ELR electromagnetic actuator (Y22). Idle speed increases. <b>Caution!</b> If battery voltage is applied for longer than 3 sec. the ELR electromagnetic actuator will be damaged.	
Yes	No



Check individual parts.

Replace electromagnetic actuator (Y22).

Engine idling. Pull double coupling of electromagnetic actuator (Y22).  
Check idle speed.

**Set values:**

Engine	Idle speed/min
602.911	620 ± 40


Yes	No
-----	----

End of test

Adjust idle speed by loosening lock nut (arrow).




left = higher  
right = lower

End of test









## Checking speed sensor (L3)



## Checking coolant temperature sensor (B11/I)



## Checking electrical activation of electromagnetic actuator

Engine idling. Remove double coupling (arrow) from electromagnetic actuator (Y22) and measure voltage with multimeter in key "V =".


**Display:** approx. = 12 V

Yes


No

Check activation according to electrical wiring diagram, replace control unit (N8 or N8/1) if required.

End of test



## 07.1405 Checking electronic idle speed control (ELR)




Digital tester (001) and pulse generator (021) . . .	connect, disconnect.
Impulse counter (013) to battery (G1) and test coupling (X92) . . . . .	connect.
Control for easy operation . . . . .	check
Idle speed stop on Bowden cable (230) . . . . .	check, the spring retainer (226) must contact the compression spring (227) without preload.
Overvoltage protection fuse . . . . .	check.

Engine ..... run at coolant temperature to 60-80 °C.  
 Engine ..... run at idle speed.  
 Starting key of impulse counter (013) ..... actuate 2 to 4 seconds.  
 Display ..... read and note down.  
 Starting key ..... again actuate, if no new display appears no further fault is in the system.

Impulse display	Component/Control circuit
1	All functions "in order"
2	Speed signal "Fault"
3	Coolant temperature "Fault"
6	Control circuit ELR "Fault"

Only short-circuit faults are identified by control units with "RO1".  
 Control units with "RO2" are also able to identify interruption.  
 Production breakpoint: Control unit with "RO2" May 1988.



Impulse display "2"  
 Speed sensor (L3) on coupling (L3x) ..... check, speed signal voltage > 2.8 V AC  
 Resistance 0.4-2.5 kΩ  
 Engine at idle speed voltage > 4 V AC.

Impulse display "3"  
 Coolant temperature sensor (B1 1 / 1) ..... check, set value at + 20 °C 2.2-2.8 kΩ.

Impulse display "6"

Pull double coupling off ELR electromagnetic actuator (Y22) and refit (at least 3 s) .....

Engine speed rises briefly.

Idle speed without control, plug on electromagnetic actuator pulled off check, adjust if required. ....

Set values see table.




If fitted, pull off individual adjustment plug (R18/3), glow starter switch in position "2" .....

check voltage. Set value: approx. 5 V.

### Test and adjusting values

Engine	Idle speed 1/min Electronic idle speed control (ELR)	
	with control	without control Plug pulled off electrom. actuator
602	680 ± 20	620 ± 40

### Special tools




### Commercially available tools

Multimeter

e.g. Sun, DMM-5

Digital tester


e.g. Bosch, MOT 002.02  
Sun, DIT 9000



### Function diagram idle speed control

B11/1	Temperature sensor (ELR)	R18/3x	Connector, individual adjustment plug
K1/1	Oversoltage protection relay	W10	Ground, battery, spring dome
L3	Starter ring gear speed sensor	x92	Test coupling
L3x	Connector, starter ring gear speed sensor	x22	Electromagnetic actuator ELR (only 603)
N8/1	Control unit (ELR)	Y22/3	Electromagnetic actuator ARA (non-U.S.)
R 1 8/3	Individual adjustment plug (as required)	a	Connector X26 jack 1 terminal 15
		b	Terminal block (X7) terminal 30

## Checking



Connect digital tester (001) and pulse generator (021).

Connect impulse counter (013) to battery (G1) and test coupling (X92).


- If the LED U-Batt appears after connecting, impulse counter and voltage supply for impulse counter are in order.

### Note

LED U-Batt in the display field must light up, if not:

- a) Check impulse counter fuse.
- b) Check jack 1 of test coupling (X92) against battery plus (approx. 12 V).
- c) Check jack 4 of test coupling (X92) against battery plus (approx. 12 V).

Check control for easy operation.





Check idle speed stop on Bowden cable (230).

The spring retainer (226) of the Bowden cable (230) in idle speed position must contact the compression spring (227) without preload.

Check fuse on overvoltage protection. Run engine to 60-80 °C coolant temperature.

Run engine at idle speed.

Actuate starting key of impulse counter (013) for 2 to 4 seconds.

Read display of impulse counter (013) and note down.

Again press start key for 2 to 4 seconds. If no further fault is in the system, no new display will appear.

Correct noted faults according to the test program or carry out individual parts test.

### **Notes on impulse display**

Figures from 1 to 6 appear on the impulse counter display.



Figure 1 means that no fault has been registered in the electronic system. All other figures are allocated to a certain group of faults.

The number of impulses shows if and which component is faulty, or if components in the control circuit are defective.



Impulse display	Component/Control circuit
1	All functions "in order"
2	Speed signal "Fault"
3	Coolant temperature "Fault"
6	Control circuit ELR "Fault"

### Checking individual components





Check overvoltage protection (K1/1)



## Impulse display "2"



### Impulse display "3"




## Impulse display "6"

Engine idling. Remove double coupling (arrow) from ELR electromagnetic actuator (Y22) for at least 3 sec. and reconnect.

Upon reconnecting, the idle speed should briefly increase above normal.

Yes	No
-----	----




Apply battery voltage to ELR electromagnetic actuator (Y22) for a maximum of 3 sec..

**Caution!** If the voltage is applied for longer than 3 sec., the ELR electromagnetic actuator will be damaged.

Idle speed increases.

Yes:	No
------	----



Replace electrom. actuator.


End of test

Engine idling. Remove double coupling (arrow) from electromagnetic actuator (Y22)..

Connect multimeter and set to "V = ".

Display: approx. 12 V'

Yes:	No.
------	-----



Check lines according to wiring diagram. Check fuse of overvoltage protection relay K1 1.

If lines are OK, replace control unit (N8/1).

End of test


Engine idling. Remove double coupling (arrow) from ELR electromagnetic actuator (Y22).

Check idle speed.


Set values:

Engine	Idle speed/min
602	620 ± 40

Yes                      No




Loosen lock nut and adjust idle speed (arrow).  
left = higher  
right = lower



End of test

## 07.1-I 10 Checking, tuning engine



1073-16549





Test sheet .....	complete.
Coolant level .....	check, correct.
Engine oil level .....	check, observe oil condition (visual inspection).
Oil level in automatic transmission .....	check, correct.
Air cleaner .....	remove, reinstall.
Testers (001, 017) .....	connect
Pulse generator (021) .....	connect.

Control linkage .....	check for easy operation and condition. Lubricate pivots of reverse-transfer levers, ball sockets.
Full throttle stop on Bowden cable .....	check, adjust if required.
Idle stop on Bowden cable .....	check, adjust if required
Battery voltage .....	check. Set value: minimum 11.5 V.
Engine .....	run to 60-80 °C coolant temperature.
Air conditioner or automatic climate control .....	switch off.
Idle speed .....	check, adjust if required. Pull plug off electromagnetic actuator.
Start of delivery .....	check.
Maximum speed .....	check.
Injection timing device .....	check. Set value: approx. + 3° to + 5° after RIV at approx. 5 1 00/min.

### Test and adjusting values

Engine		602.911
Idle speed 1 /min	Electronic idle speed increase	680 ± 20
Maximum no-load speed		5150 ± 150
Start of delivery with digital tester	RI set value	-15° ± 1° ATDC

### Special tools





## Commercially available testers

### Use without adapter

Digital testers

e.g. AVL, Diesel-Tester 873


e.g. Bosch, ETD 019.002 or  
MOT 350/500/501

### Use with adapter

e.g. Sun, DIT 9100

Digital testers


e.g. Bosch, MOT 001.03



P07-0453-57

### Connection diagram for testers without adapter

001	Digital testers	021	TDC impulse sensor
015	Test cable with plug	59	TDC sensor pin
016	Diagnostic socket	2	Governor
017	Governor impulse sensor	2i	Governor Impulse sensor pin



P07-0452-57

Connection diagram for existing testers with adapter

001	Digital tester	017	Governor Impulse sensor
010	Adapter	021	TDC Impulse sensor
011	Alligator clamp	59	TDC sensor pin
015	Test cable with plug	2	Governor
016	Diagnostic socket	2i	Governor impulse sensor pin


## Checking, tuning

---

- 1 Complete test sheet, enter measured values.
- 2 Check, correct coolant level.
- 3 Check engine oil, inspect oil condition.
- 4 Check oil level in automatic transmission.
- 5 Connect testers (001, 017) according to connection diagram.
- 6 Connect pulse generator (021).
- 7 Remove, reinstall air cleaner element; check for contamination.
- 8 Check control for easy operation and condition and lubricate.


- 9 Check full load stop.

With engine off, fully depress accelerator pedal. The control lever must contact the full load stop (arrow).




- 10 Check idle stop.

In idle speed position the spring retainer (226) of the Bowden cable (230) must contact the compress/on spring (227) without preload.



Adjust Bowden cable (230) with the adjusting nut (232) from the vehicle inside if required.



11 Check battery voltage.  
Set value: at least 11.5 V.


12 Run engine to a coolant temperature of 60-80 °C.

13 Switch off air conditioner and automatic climate control.

14 Check idle speed; read off start of delivery.  
RI set value  $15 \pm 1$  ° ATDC.

**a) Engine 602 with electronic idle speed increase**


Pull double coupling off electromagnetic actuator. Loosen lock nut (arrow) and adjust idle speed.



15 Check maximum no-load speed.

16 Check injection timing device without load.  
Set value: 3° to 5° BTDC according to RIV at approx. 5 1 00/min.




## 07.1-I 11 Checking start of delivery (position sensor RIV method)



P07-0522-55


Governor housing screw plug (11) . . . . .	unscrew, tightening torque 30-35 Nm.
Position sensor (007) . . . . .	turn in.
Battery alligator clamp (009) . . . . .	connect to battery +.
Manually turn crankshaft until . . . . .	lamps A and B of the indicating instrument (008) light up simultaneously.
Read RI value (indirect start of delivery) . . . . .	of the graduated scale, set value $15^{\circ} \pm 1^{\circ}$ ATDC. Adjust start of delivery if required (07.1-I 16).

## Special tools




## Checking

- 1 Remove screw plug (11).




- 2 Turn position sensor into the governor housing. Ensure that the guide pin of the position sensor (arrow) faces up. Tighten union nut by hand.



- 3 Connect position sensor according to connection diagram.


- 007 Position sensor
- 008 Indicating instrument
- 009 Battery alligator clamp (battery plus)
- 2i Flyweight (RIV sensor pin)



- 4 Use tool to turn crankshaft manually (only in direction of rotation) until lamp "A" lights up. Continue to turn until **both lamps "A + B"** light up. In this position read WI value (indirect start of delivery) off graduated scale.


**RI set value:  $15^\circ \pm 1^\circ$  ATDC.**

If only lamp "B" lights up, repeat test.



- 5 Remove position sensor.
- 6 Turn screw plug into governor housing (tightening torque 30-35 Nm).
- 7 Carry out leak test with engine running.
- 8 Check engine oil level and correct if required.

## 07.1-I 12 Checking start of delivery with digital tester (RIV method)



P07-0519-59

Remove screw plug (arrow) from governor housing (2) .....

Testers (001, 017, 021) .....

Run engine at idle speed .....

unscrew.

Tightening torque 30-35 Nm.

connect, disconnect.





read RI value off digital tester at 15° ATDC.

RI set value: 15° ± 1° ATDC.

Adjust start of delivery if required (07. 1. 116 and 117).



## Special tools



## Commercially available tools

### Use without adapter

Digital testers

e.g. **AVL**, Diesel-Tester 873


e.g. Bosch, ETD 019.002

e.g. Sun, DIT 9100

### Use with adapter

Digital tester

e.g. Bosch, MOT 001.03




P07-0452-57

### Connection diagram for existing testers with adapter

001	Digital tester	017	RIV sensor
010	Adapter	021	TDC pulse generator
011	Alligator clamp	2	Governor
015	Test cable with plug	2i	RI sensor pin
016	Diagnostic socket	59	TDC sensor pin


### Checking

- 1 Remove screw plug (11) from governor housing.




P07-2240-13

2 Turn RIV sensor (017) into governor (injection pump).



3 Turn TDC pulse generator (021) into bracket (engine).



4 Connect digital tester according to connection diagram.

5 Engine idling. Read RIV value (indirect start of delivery) off digital tester at idle speed.

**RI set value:  $15^{\circ} \pm 1^{\circ}$  ATDC.**

6 Switch off engine.

7 Disconnect digital tester.

8 Install screw plug in governor (tightening torque 30-35 Nm).

9 Carry out leak test with engine running.

10 Check engine oil level and correct, if required.

## 07.1413 Establishing fuel consumption by road test

---

- 1 Fill up vehicle tank in the presence of the customer with the vehicle on level ground.
- 2 Drive approx. 100 km (62 mi.), of this approx. 40 km (25 mi.) highway and approx. 60 km (37 mi.) back roads and city traffic.
- 3 After driving fill up again and calculate fuel consumption.

### Example 1:

Fuel consumption in liters/100 km

$$= \frac{\text{Fuel quantity consumed in liters}}{\text{Kilometers driven}} \times 100$$


### Example 2:

Fuel consumption in miles/gallon

$$\frac{\text{Miles driven}}{\text{Fuel quantity consumed in gallons}}$$

---

## 07.1-116 Adjusting start of delivery (position sensor RIV method)



P07-0520-55

- Turn crankshaft in direction of rotation . . . . . to 15° ATDC of 1 st cylinder.  
 Loosen mounting screws (13 and 13a) on the injection pump flange and support bracket . . . . . tightening torque 20-25 Nm.  
 Indicating instrument (008) and clamp (009) . . . . . connect to B + .  
 Pivot injection pump by turning the adjusting screw at the adjusting device for start of delivery (8) . . . . . both lamps "A and B" must light up in the indicating instrument (008).

### Direction of rotation of the adjusting screw

- Right = start of delivery retarded  
 Left = start of delivery advanced  
 Position sensor (007) . . . . . remove.  
 Screw plug (11) . . . . . turn in.  
 Control linkage . . . . . check, adjust if required (30-300).  
 Leak test  
 with engine running . . . . . carry out.  
 Engine oil level . . . . . check, correct.


**Note**

Before adjustment, check start of delivery (07.1-111).



**Adjusting**

---

1 Turn crankshaft in direction of rotation to 15° ATDC of 1st cylinder.



2 Loosen mounting screws (arrows) on injection pump flange and support bracket (arrow).



Screw on support bracket


3 Connect Indicating instrument (008) and clamp (009) to battery plus.

4 Pivot injection pump by turning the adjusting screw on the start of delivery adjusting device until both lamps light up.

**Direction of rotation of the adjusting screw**

Right = retarded start of delivery  
Left = advanced start of delivery

**RIV set value:  $15^{\circ} \pm 1^{\circ}$  ATDC**



**Note**

If the adjusting range is inadequate, the injection pump must be repositioned. Injection pump, remove, reinstall (07.1-200).

5 Secure mounting bolts on injection pump flange and support bracket, tightening torque 20-25 Nm.

6 Remove position sensor.

7 Install screw plug, tightening torque 30-35 Nm.


8 Check control linkage and adjust if required (30-300).

9 Carry out leak test with engine running.

10 Check engine oil level and correct if required.



## 07.1-117 Adjusting start of delivery with digital tester (RIV method)



P07-0517-57

Mounting screws (13 and 13a) on injection pump flange and support bracket	loosen.
Engine	run at idle speed.
RIV value (indirect start of delivery)	adjust by turning the adjusting device (8)

### Direction of rotation of the adjusting screw (8)

Right	= start of delivery retarded	
Left	= start of delivery advanced	RI set value $15^{\circ} \pm 1^{\circ}$ ATDC.
Engine		switch off.
Mounting screws (13 and 13a) on injection pump flange and support bracket		secure tightening torque <b>20-25</b> Nm.
Testers		disconnect.
Screw plug (arrow) on governor		turn in, tightening torque 30-35 Nm.
Control linkage		check, adjust if required (30-300).
Leak test with engine running		perform.
Engine oil level		check.



### Note

Before adjustment, check start of delivery (07.1-112).

### Adjusting

---

- 1 Loosen mounting screws (arrows) on injection pump flange and support bracket (arrow).




Screw on support bracket

- 2 Run engine at idle speed.
- 3 Adjust RIV value (indirect start of delivery) by turning the adjusting screw on the start of delivery adjusting device.

**RIV set value:  $15^{\circ} \pm 1^{\circ}$  ATDC**

#### Direction of rotation of the adjusting screw

- Right = retards start of delivery  
Left = advances start of delivery



---

**Note**

If the adjusting range is inadequate, the injection pump must be repositioned. Injection pump, remove, reinstall (07.1-200).

4 Switch off engine.

5 Disconnect tester.

6 Turn screw plug into governor, tightening torque 30-35 Nm.


7 Secure mounting screws on injection pump flange and support bracket, tightening torque 20-25 Nm.

8 Check control linkage and adjust if required (30-300).

9 Perform leak test with engine running.

10 Check engine oil level and correct if required.

## 0X1-145 Checking fuel pump



Testers (001, 015, 016, 021) ..... connect  
 Return line (81) ..... disconnect and hold in the measuring cup  
 approx. 1 l.

### Note

The return to the fuel tank must be sealed.

Key in steering lock position ..... turn to "0", this means the injection pump is in  
 zero delivery position.

Connect contact handle (040) to terminal 30 and  
 terminal 50 ..... and start engine for 30 seconds (starting voltage  
 min. 10 V).





**Set value**

Transfer pump at least 150 cm<sup>3</sup>/30 seconds. Replace fuel filter and/or transfer pump if required. Check fuel pressure (07. I-I 46).

Use ..... stop watch (041)

**Test values**

Engine	601, 602, 603
Rate of delivery at 150/min minimum	at least 150 cm <sup>3</sup> /30 s
Test requirement	Glow starter switch in position "0"


**Special tools****Commercially available tools**

Digital tester	e.g. Bosch, MOT 001.03
Measuring glass or cup (at least 1 liter)	
Stop watch	


## Checking

1 Connect digital tester (001) according to connection diagram.

001 Digital tester  
021 TDC pulse generator




2 Disconnect return line (E) and hold into the measuring cup.



3 Turn ignition lock in position "0", the injection pump is now in "zero" delivery position.

4 Pull off coupling (X 27) and connect adapter line to terminal 50 (KI 50).




Model 201

Connect contact handle to adapter line and to one of the terminals 30 (KI 30) on terminal block (arrow) and start engine for 30 seconds.  
**(Starting voltage at least 10 V)**

Set value rate of delivery:  
at least 150 cm<sup>3</sup> 30 seconds


If the set value is not achieved, check fuel pressure (07.1- 146).







## 07.1-146 Checking fuel pressure (after checking delivery capacity)



Fuel line "A" from filter upper part (73) .....

unscrew,  
connect tester (054).

**Set values:**



at idle speed  $> 0.3$  bar

at full load  $> 0.5$  bar

If the set values are not achieved:


Replace fuel filter.

### Special tools



## 07.1-150 Testing vacuum shut-off for leaks

1 st version




- 1 Injection pump
- 6 Vacuum unit (stop)
- 61b Choke 0.5 mm orifice diameter
- 61c Valve glow starter switch
- 61d Cam glow starter switch (valve open)
- 67 Vacuum pump

- A Partition panel
- c Remaining users
- e To brake booster

- |                           |   |
|---------------------------|---|
| Glow starter switch ..... | turn to position "2".   |
| Vacuum tester (019) ..... | connect to suction line "brown" and apply vacuum of 400 + 50 mbar (max. pressure drop 6 mbar/min).<br>Turn glow starter switch to position "0", the stop lever goes down or in stop position. |
| Vacuum tester (019) ..... | connect to vacuum unit (6) and apply vacuum of 300 + 50 mbar (max. pressure drop 5 mbar/min).   |

**2nd version**

Production breakpoint as of July 1987.



P07-0510-57

- |     |                              |   |                  |
|-----|------------------------------|---|------------------|
| 1   | Injection pump               | A | Partition panel  |
| 6   | Vacuum unit (stop)           | C | Remaining users  |
| 61c | Valve glow starter switch    | e | To brake booster |
| 67  | Vacuum pump                  |   |                  |
| 140 | Check valve/main vacuum line |   |                  |

Glow starter switch .....  
 Vacuum tester (019) .....

press to position "2".  
 connect to suction line "brown" and apply vacuum of 400 + 50 mbar (max. pressure drop 6 mbar min).

Vacuum tester (019) .....


Turn glow starter switch to position "0", the stop lever goes down or in stop position.  
 connect to vacuum unit (6) and apply vacuum of 300 + 50 mbar (max. pressure drop 5 mbar/min).

**Permissible loss of vacuum mbar/min**

Model	201
Entire system at 400 + 50 mbar vacuum	6 <sup>1)</sup>
Individual parts at 300 + 50 mbar vacuum	5 <sup>1)</sup>


<sup>1)</sup> Maximum pressure drop

**Special tool**



**Testing**


- 1 Turn ignition key on glow starter switch to position "2".
- 2 Pull suction line (brown) from connector (arrow).



Model 201

Vacuum supply directly from check valve of main vacuum line.

Model 201 as of July 1987




3 Connect tester and apply vacuum of 400 + 50 mbar.

If the display on the pressure gauge fails to change, the valve for the glow starter switch is leaking.

If a vacuum drop of more than 6 mbar min occurs on the pressure gauge, the valve (61c) on the glow starter switch is leaking.

**Caution!**

Before replacing the valve for the glow starter system and the vacuum unit of the injection pump, check hose lines and connections.



4 Replace valve on glow starter switch.


5 Turn ignition key on glow starter switch to position "0".

If a vacuum drop occurs on the pressure gauge, the vacuum unit or the valve may be leaking.


6 In this case, disconnect tester from suction line (brown).

7 Pull control line (brown blue) from connector (arrow).

Model 201  
Standard version



Model 201  
California version



8 Connect tester to connector and apply vacuum of 300 + 50 mbar.

If a vacuum drop of more than 5 mbar/min occurs on the pressure gauge, the vacuum unit of the injection pump is leaking.


**Caution!**

Before replacing the vacuum unit, check hose lines and connectors.

9 Replace vacuum unit (07.1-220).

.....

## 07.1-160 Testing vacuum pump



P07-0515-57


Engine temperature .....	< 20 °C (reference value)
Main vacuum line (B) .....	disconnect from brake booster (A), ventilate and reconnect.
Vacuum line on auxiliary user connection .....	disconnect and check choke orifice with 0.8 mm gauge for open passage.
Vacuum tester (019) to auxiliary user connection .....	connect and check vacuum at idle speed.

**Nominal value:** 700 mbar after 30 s.

If the vacuum value is not achieved, replace vacuum pump.



**07.1470 Testing and adjusting vacuum control valve for automatic transmission**



P07-0524-57

Vacuum tester (019) to damper (72) of  
vacuum line .....

connect and read vacuum at idle (set values  
and test values see next page).


With engine off, move control to full-throttle stop  
position.

**Nominal value: 0** mbar, adjust vacuum control  
valve if required. Check vacuum lines, check  
vacuum pump, replace vacuum control valve.

Mounting bolts (65c).....

loosen, fully open throttle until the control lever of the injection pump contacts the full-load stop. Turn vacuum control valve (65) in the direction of the arrow until resistance can be felt. In this position secure vacuum control valve.

**Special tool**



**Test and adjusting values, characteristics**

Engine	Pressure control flap		Cap identification	Part no.	EGR valve identification	Vacuum adjustment mbar
	mech.	pneu.				
602 with EGR and automatic transmission	-	yes	black <sup>1)</sup>	123 300 10 33	blue	385 ± 25
602 with EGR and manual transmission	-	yes	green	123 300 12 33	blue	> 300
602	yes	-	yellow	124 300 03 33	brown	> 300

<sup>1)</sup> as of February 1987 with red cap

## Checking


1 Pull off vacuum line, connect vacuum tester to damper (72) and check vacuum at idle.

Nominal values see table.

2 With the engine off, move control linkage into full throttle stop position. Check vacuum.  
Nominal value: 0 mbar.

3 If nominal values are not achieved:

- a) Check vacuum control valve adjustment.
- b) Check vacuum lines according to vacuum diagram, check vacuum pump, replace vacuum control valve if necessary.




## Adjusting

4 Loosen mounting screws (65 c).

5 Fully open throttle so that the control lever of the injection pump contacts the full load stop.


6 Turn vacuum control valve (65) in the direction of the arrow until resistance can be felt. In this position secure mounting screws.



A sealing boot (arrow) is installed together with the vacuum control valve to prevent dust and dirt from entering the vacuum control valve.

## Repair instructions

Vacuum control valves differ for manual and automatic transmissions.




## 07.1-195 Testing exhaust gas recirculation

---


### A. Performance test

### B. Testing individual parts


#### Special tools




603 589 00 21 00  
07



601 589 04 21 00  
07



201 589 13 21 00  
00 42 80



201 589 00 99 00  
15 54

#### Commercially available tools

---

Digital tester

Bosch, MOT 001.03

e.g. Sun, DIT 9000

Multimeter

e.g. Sun, DMM-5

---

#### Note


Use Y-distributor, part no. 117 078 01 45 for vacuum tester.

#### Test condition

Coolant temperature 60-80 ° C.

**A. Performance test**

<p><b>Testing EGR valve (60) with engine off</b> Apply vacuum of approx. 300 mbar to EGR valve. Pull off vacuum line.</p>	
EGR valve audibly closes.	EGR valve does not close.




Test individual components
End of test

**Testing vacuum amplifier (123) and vacuum adjustment**

Connect vacuum tester with Y-distributor to connection "A" and read vacuum value with engine at idle. If the vacuum is above or below the nominal value, adjust vacuum. For this purpose pull off protective cap (124) and adjust with socket wrench insert (4 mm) according to specified Nominal value.

Nominal value:  $350 \pm 5$  mbar.  
as of model year 1986 may not be adjusted.

OK	Not OK
----	--------



Check vacuum supply at connection "C", replace vacuum amplifier if necessary. Check vacuum lines according to vacuum diagram. Check supply vacuum on vacuum pump (07.14 60).

Nominal value: greater than  
700 mbar

End of test

### Testing vacuum control

Connect vacuum tester with Y-distributor to EGR valve (60). Check vacuum values and position of vacuum unit (100) and vacuum control flap. Take vacuum readings at the following engine speeds:

EGR Model Year 1986



rpm	EGR valve mbar	Pressure control flap position
680 ± 20	0	Not activated
1200 ± 50	150 - 350	Fully activated
3000 ± 50	0	Not activated


EGR Model Years 1987 through 1989

rpm	EGR valve mbar	Pressure control flap position
680 ± 20	Approx. 30	Not activated
1000 ± 50	150 - 360	Fully activated
2500 ± 50	150 - 360	Not activated
3000 ± 50	0	Not activated

OK

Not OK





P07-2507-13

Piston rod of vacuum unit retracted • pressure control flap closed (arrow).

Check vacuum supply and individual components.

End of test

**Testing microswitch (S27/6, I + II)**

Connect vacuum tester with Y-distributor to EGR valve (60).


Run engine at  $1200 \pm 50$  rpm (M.Y. 1986).  
Run engine at  $1000 \pm 30$  rpm (M.Y. 1987- 89)

Actuate microswitch (S27/6 I), the vacuum on the EGR valve (60) should drop to 0 mbar. The pressure control flap (in the air filter housing) should move into "not activated" position.

Actuate microswitch (S27/6 II), the pressure control flap (100) in the air filter housing should move into the "not activated" position.

OK




Not OK



P07-2071-13

Check individual components.

## B. Testing individual components



A open  
B closed



### Testing vacuum control valve (65)

Connect vacuum tester with Y-distributor to connection "B" of vacuum amplifier (123) and check vacuum at idle.

Nominal values:

At  $680 \pm 20$  rpm:



approx. 360-410 mbar (M.Y. 1986-1988)

above 300 mbar (M.Y. 1989)

With engine off and control linkage at full load stop: 0 mbar.

Test values correct.

Test values not in order.




Check vacuum lines according to vacuum diagram.  
Check vacuum supply at vacuum pump.

Nominal Value:

greater than 700 mbar

Adjust vacuum control valve (65)  
(07.1-l 70), replace if necessary.




End of test

**Testing switchover valves(Y27 and Y28)**

Connect voltmeter to connector of switchover valve and measure voltage at  $1000 \pm 50$  rpm for model years 1987 through 1989 and  $1200 \pm 50$  for model year 1986.


Nominal value: approx. 12 V.

OK	Not OK
----	--------



Check electrical actuation according to wiring diagram, replace EGR control unit (N37 or N37/2) if necessary.

End of test






Connect vacuum tester with Y-distributor to connection "C" and check vacuum at  $1000 \pm 50$  rpm (or  $1200 \pm 50$  for 1986, 12 V applied) valves Y27 and Y28




300-400 mbar

Check engine with mechanical actuation of the pressure control flap at  $1000 \pm 50$  rpm ( $1200 \pm 50$  for M.Y. 1986), applying 12V.

Switchover valve (Y27) 350 - 400 mbar  
Switchover valve (Y28) > 700 mbar










1) Measured at 20 °C ambient temperature. (The resistance changes by 4% for each 10 °C change in ambient temperature).

**Testing activation of temperature switch (S25/9) 97 °C**

Connect vacuum tester with Y-distributor to I/EGR valve.

Run engine at **1200 rpm** (M.Y. 1986-I 988)  
Run engine at 1000 rpm. (M.Y. 1989)  
Pull plug off temperature switch (S25/1) and bridge 2 terminal connection, except I-pole version of temperature switch (S25/1), hold the plug against ground (engagement of electronic clutch should be heard).

Vacuum at EGR valve drops to 0 mbar.



**Testing activation of 25 °C temperature switch (S25/7)**

Connect vacuum tester with Y-distributor to EGW valve.

Engine temperature above 25 °C

Run engine at 1200 rpm (M.Y. 1986/4988)

Run engine at 1000 rpm (M.Y. 1989)

Pull plug off temperature switch and hold against ground.


Vacuum at EGR valve drops to 0 mbar.





OK

Not OK


Check electrical activation, according to wiring diagram, replace EGR control unit (N37 or N37/2) if necessary.

End of test







<b>Testing speed shut-off</b>	
<b>Model Years 1986-I 988</b>	
Connect vacuum tester with Y-fitting to actuator (100) for vacuum control flap. Drive vehicle on dynamometer or open road in 5th gear or "D" at partial load. Read vacuum at the speeds listed below.	
<b>Model Year 1986</b>	
below 56 ± 5 mph:	approx. 700 mbar
above 56 ± 5 mph:	approx. 0 mbar
<b>Model Years 1987, 1988</b>	
below 54 mph:	approx. 150 mbar
above 54 mph:	approx. 0 mbar
OK	Not OK



<p><b>Model Year 1986</b></p> <p>Pest electrical activation of switchover valve (Y27). For this purpose, connect multimeter to connector (arrow) of switchover valve and repeat test drive.</p> <p>If voltage (approx. 12 V) is indicated at speeds above 56 mph (90 km/h), test electrical activation of switchover valve according to wiring diagram. Replace defective parts, if required.</p> <p>If there is no voltage, replace switchover valve.</p>
<p><b>Model Years 1987, 1988</b></p> <p>Test electrical activation of switchover valve (Y28). For this purpose, connect multimeter to plug of switchover valve and repeat test drive.</p> <p>If voltage (approx. 12 V) is indicated at speeds above 54 mph (87 km/h), test electrical activation of switchover valve according to wiring diagram. Replace defective parts, if required.</p> <p>If there is no voltage, replace switchover valve.</p>



End of test.



**Testing microswitch (S27/6)**

**Model Year 1989**

Engine off. Pull off connector on microswitch (S27/6) and test for continuity with ohmmeter between pin 2 and 4 and/or pin 1 and 3.

At idle :  $0 \Omega$


At full throttle:  $\infty \Omega$

OK

Not OK

Replace microswitch (S27/6).

End of test.



**Testing full load contact on microswitch (S27/6) Model Year 1989**

Engine off. Pull off connector on microswitch (S27/6, pos. I). Test for continuity with ohmmeter between pin 1 and 5.

At idle:  $\infty \Omega$


At full throttle:  $0 \Omega$

OK


Not OK

Replace microswitch (S27/6).

End of test.









## 07.1-200 Removal, installation of injection pump



Noise capsule lower part .....	remove, mount (94-0050).
Belt tensioning device .....	remove, reinstall (13340).
Fan shroud and fan .....	remove, reinstall (20-310/335).
Vacuum pump (67) .....	remove, reinstall (43-610).
	Gasket (67a), replace.
Adjusting element of cruise control .....	remove, reinstall (54541).
Assembly cage .....	remove, reinstall
	Special tool 601 589 05 14 00
	Note: Assembly cage deleted on all engines
	as of 09/89 (see 07.1-240).

Central mounting bolt (19) .....	remove, reinstall ‘@left-hand thread’ Tightening torque 40-50 Nm.
Turn crankshaft in direction of rotation .....	to -15° ATDC of 1 st cylinder.
Chain tensioner (156) .....	remove, reinstall, tightening torque 80 Nm (05-310).
Control damper (16) .....	remove, reinstall (only manual transmission).
Injection lines (54-59) .....	on injection pump disconnect, connect, tightening torque 10-20 Nm., special tool 000 589 770 300
Fuel lines (80, 82, 83) .....	disconnect, connect.
Sealing rings (78) .....	replace.
Vacuum lines on stop unit .....	remove, fit.
Couplings on electromagnetic actuators .....	disconnect, connect.
Control linkage .....	disconnect, connect.
Vacuum control valve (65) .....	remove, reinstall, adjust (07.1-I 70).
Mounting bolts (13 and 13a) .....	remove, reinstall, tightening torque 20-25 Nm.
Combination screw (8a) .....	loosen.
Fuel thermostat (86) .....	remove, reinstall.
Injection pump .....	pull out to the rear while counterholding injection timing device.
O-ring (10) .....	replace, lubricate with oil for injection pump installation.
Check if engine .....	is positioned on -15° ATDC of 1 st cylinder, correct if necessary. <b>Caution!</b> Turn engine only in direction of rotation.
Screw plug (11) .....	remove.
Injection pump .....	turn in removed condition with splined wrench (027) and lock with locking bolt (023).
Start of delivery .....	check (07.1-I 12), adjust if necessary (07.1-I 17).

## Special tools



### Note

Until the production breakpoints shown, a gasket with oil pocket must be installed when replacing the gasket (67a) of the vacuum pump.  
As of the production breakpoint, a gasket without an oil pocket is installed.


Engine model design.	Transmission	As of engine end no.
602.911	manual	019187
	automatic	004738

## Removal, installation


- 1 Remove assembly cage (arrow).
- 2 Loosen central mounting bolt (19), unbolt and hold crankshaft against rotation.

### Caution!

**LEFT-HAND THREAD**




- 3 Turn crankshaft in direction of rotation to -15° ATDC of 1st cylinder.




- 4 Remove chain tensioner (156) (05310).

Socket wrench insert  
Special tool 001 589 65 09 00



- 5 Disconnect injection and fuel lines from injection pump.

Socket wrench insert (arrow)  
Special tool 000 589 77 03 00  
with 1/4" ratchet




6 Pull off vacuum lines for idle speed increase, stop unit and vacuum control valve vacuum unit. Pull off ELR double couplings with electromagnetic actuators.


7 Disconnect control linkage on control lever as well as shock absorber and spring.

8 Remove vacuum control valve (only with automatic transmission or EGR).

9 Remove mounting bolts (arrows) and install bracket.




10 Completely remove fuel thermostat (86) by removing bolts (arrows).



A = Supply from fuel tank


11 Pull injection pump out to the rear while holding the injection timing device.




12 Check if the engine is positioned at -15° ATDC of 1st cylinder, correct if necessary.

**Caution!**


Turn engine only in direction of rotation with the installed centering sleeve!



13 Remove screw plug (11).




14 Turn injection pump with splined wrench (027) on the injection pump camshaft until the lug of the governor is visible in the hole, then insert locking bolt (023) in this position and engage in the lug, tighten by hand.



027 Splined wrench  
Special tool 601 589 00 08 00

**Caution!**

Remove locking bolt (023) after installation of the injection pump to avoid damage to the injection pump during starting.



023 Locking bolt  
Special tool 601 589 05 21 00

P07 0451-17

15 Reassemble engine in reverse order.

**Note**

Bleeding of the injection system is automatic when starting the engine.

16 Check start of delivery 07.1-I 12, adjust if required 07. I-I 17.


17 Install, adjust vacuum control **valve** 07.1- 170.



.....


## 07.1-210 Replacing delivery valve seal

---




Air cleaner complete .....	remove, reinstall (09-400).
Delivery valve holder (7) .....	remove, reinstall, tightening torque 35 Nm, special tool 617 589 01 09 00.
Compression spring (7i)	
Copper sealing ring (7f) .....	replace.
Delivery valve (7k) .....	rinse in fuel before installation.
Delivery valve carrier (7g) .....	observe installation position.
O-ring (7h) .....	lubricate prior to installation.

### Special tool





## 07.1-220 Replacing vacuum unit

---




Air cleaner complete .....	remove, reinstall (09-400).
ADA unit .....	remove, reinstall (engines with EGR).
Screw (6b) .....	remove, reinstall. For TORX screws use wrench "T30".
Bracket (6c).....	remove, reinstall.
Vacuum unit (stop) (6) .....	slightly raise during removal, tilt backward to the engine side and pull out.
O-ring (6a) .....	remove, reinstall.
Emergency stop lever (25) .....	push during installation and allow vacuum unit connecting rod to engage in the toggle of the emergency stop lever.

## 07.1-225 Replacing electromagnetic actuator (ELR)



- A 1 st version
- B 2nd version
- 1 Injection pump
- 2 Governor
- 160 Intermediate plate


Air cleaner complete .....	remove, reinstall (09-400).
Screw (6b) .....	2 off remove, reinstall. For TORX screws use wrench "T30".
Bracket (6c) .....	2 off remove, reinstall.
Electromagnetic actuator (Y22) .....	remove, reinstall, electrical connection must face up.
O-ring (161) .....	replace.
Shim (167) (no replacement part) .....	for adjusting dimension "a". (During repairs the previous shims must be reinstalled to ensure that the dimension "a" is correct).



Di mensi on "a"  
14.6-15.7 mm


## 07.1-230 Removal and installation of injectors

---



Fuel bleed hose (50) . . . . .	pull off, fit.
Plug (52) . . . . .	material (fabric),
Injection line cylinder no. 1(54) . . . . .	10-20 Nm (reference value).
Injection nozzle (30) . . . . .	70-80 Nm, special tool 001 589 65 09 00, with inclined injection 30 Nm.
Nozzle plate (53) . . . . .	replace

### Special tool




---

## 07.1-231 Checking injectors

Injection nozzles removed ..... 07.1-230

- A. Facet-type pintle nozzle
- B. Hole-type pintle nozzle



Injection nozzle (30) .....

Buzzing test .....

Spray pattern test .....

Pre-spray .....

Shut-off pressure or opening pressure .....

on tester (052) vigorously pump through 5 times, while keeping valve "a" closed.

**slowly** actuate hand lever "b" approx. 1 stroke per second.

With rapid short strokes, approx. 2 strokes per second, the spray pattern should be closed and should break off well.

A - Spray pattern frayed "poor"

B - Spray pattern closed "good"


check (only with hole-type pintle nozzles).

check by opening valve "a" and slowly operating hand lever "b" at least 1 stroke per second.

**Set value:** 115-125 bar with new nozzles, mtn.  
100 bar with used nozzles.



## Special tool



## Commercially available tools

---

Tester EFEP 60 H	e.g. Bosch, O-7000 Stuttgart Order no. 0 681 200 502
Cleaning needle 0.18 mm dia.	e.g. Bosch, D-7000 Stuttgart Order no. KDEP 2900/4

---

### Warning

**Use** only clean test oil or filtered diesel oil for testing. On no account should the hand be brought in contact with the spray of a nozzle during testing. The spray enters deeply and destroys the tissue. The fuel entering the blood stream may lead to blood poisoning.

## Production breakpoint: August 1989

---

Model	Engine	Engine end no. Manual transmission	Engine end no. Automatic transmission
201.126	602.911')	082780	016395
Identification	1) 2 green color dots 2) 2 violet color dots		

---

Since August 1989 engine 602 has been equipped with finely ground injection nozzles.


## A. Facet-type pintle nozzle

## Checking


---

1 Vigorously pump injection nozzle 5 times with the tester. Then **check buzzing of the nozzle** by slowly actuating the hand lever (approx. 1 stroke per second).

2 **Checking spray:** With short rapid part strokes (at least 2 strokes per second) the spray pattern should be rather closed and break off well.



A Closed spray pattern, well atomized



B Broken spray pattern, too wide and frayed


3 **Checking injection pressure:** Set value 115-125 bar with new nozzle, at least 100 bar with used nozzles.

Slowly move down the hand lever (at least 1 stroke per second) and read injection pressure off pressure gauge.


Shut-off valve must be open for this test.

## B. Hole-type pintle nozzle

1 Before checking: Ensure that the longitudinal bore (15) is unobstructed by means of a cleaning needle 0.18 mm dia.





2 Vigorously pump injection nozzles 5 times on tester. After this carry out **buzzing** test by slowly actuating hand lever (at least 1 stroke per second).



3 **Spray test:** With short rapid part strokes (approx. 2 strokes per second) the spray should be rather closed and break off well.

A Closed spray pattern, well atomized






B Broken spray pattern, too wide and frayed

4 Create **pre-spray** by slowly moving the hand lever down (1 stroke 4-6 s).

A vertical string-type spray pattern should emerge from the center bore (15).

**Note**

On new nozzles the pre-spray is very difficult to create, therefore check longitudinal bore with cleaning needle 0.18 mm dia. for open passage.



**5 Checking injection pressure:**

**Set value:** 115-1 25 bar with new nozzle, at least 100 bar with used nozzle.


Slowly move hand lever down (approx. 1 stroke per second) and read injection pressure off pressure gauge.

Shut-off valve must be open for testing.

## 07.1-232 Reconditioning injectors




---

Injectors removed (07.1-230).



injector needle (31) .....	Visual and sliding test; on hole-type pintle injectors clean center and longitudinal bores; install in the same injector body.
Injector body (32) .....	remove combustion residue.
Intermediate plate (33) .....	polish on surface plate.
Thrust pin (34) .....	Tip must face to the upper part.
Injector clamping nut (35) .....	70-80 Nm.
Compression spring (36)	
Retaining body (37) .....	clamp in protective jaws.
Steel shim (40) .....	adjust to injection pressure. Set value 115-1 25 bar for new injector or injector to be newly adjusted, at least 100 bar for used injector. Depending on the shim thickness higher or lower injection pressure. 0.05 mm produce a pressure differential of approx. 3 bar.

## Special tools




## Commercially available tool

Cleaning needles 0.18 mm dia.


e.g. Bosch, D-7000 Stuttgart  
Order no. KDEP 2900/4

## Reconditioning


1 Dismantle by placing retaining body with protective jaws in the vise so that the bleed fuel connections are not damaged.



2 Clean, remove combustion residue on injector needle seat with the cleaning miller.




Clean injector needle and injector body with brass brush.




On the hole-type pintle injector additionally clean longitudinal and transverse bores.

Clean longitudinal bore with cleaning needle 0.18 mm dia.



Longitudinal bore

Clean transverse bore with cleaning needle 0.35 mm dia.




Transverse bore

### 3 Visual and sliding test.

Immerse injector in filtered diesel fuel. With the injector body held vertically, the injector needle should slide towards the injector seat by its own weight.

4 Polish intermediate plate (33) on both sides on the surface plate.



5 Assemble injector holder with injector.  
Depending on the shim thickness (40) higher or lower injection pressure; 0.05 mm correspond to approx. 3 bar pressure differential.


6 Check function of injector (07.1-231), adjust if required.



## 07.1-235 Removal and installation of fuel pump

---


Air cleaner cover removed (09-400).



Clamp (84) . . . . .	open, close.
Suction line (89) . . . . .	pull off, fit.
Supply fuel filter (82) . . . . .	disconnect, connect.
Nut, 2 off (3c) . . . . .	remove, reinstall.
Washer, 2 off (3b) . . . . .	remove, reinstall.
Fuel pump (3) . . . . .	collect engine oil running out during removal.
Gasket (3a) . . . . .	replace
Delivery outlet (23)	
Injection pump (1)	









## 07.1-240 Removal and installation of injection timing device



Vacuum pump (67) .....	remove, reinstall (43-610).
Gasket (67a) .....	replace.
	<b>Caution!</b>
	<b>2</b> versions, see table.
Combination bolt (67b) .....	dismount, mount.
Cylinder head cover .....	remove, install.
Camshaft sprocket (154) and injection timing device (18) .....	remove, reinstall, with paint mark relative to timing chain (155).
Central mounting bolt (19) .....	remove, tightening torque 40-50 Nm.
	<b>Caution!</b>
	Left-hand thread.
Washer (20), bolt - camshaft sprocket (153) .....	remove, tightening torque 45 Nm.
Washer - camshaft sprocket (152), engine .....	set to 15° ATDC.
Chain tensioner (156) .....	remove, reinstall (05-310), tightening torque 80 Nm.

Camshaft sprocket (154) . . . . .	remove, reinstall.
Locking pin (151) . . . . .	remove with threaded pin part no. 116 589 01 34 00 and impact puller part no. 116 589 20 33 00.
Assembly cage (18a) . . . . .	remove, reinstall. <b>Note:</b> The assembly cage (18a) and the fixing bolts (13b) are deleted on the engines, see table below.
Timing chain (155) . . . . .	with sheet metal strip (approx. 0.5 x 70 x 120) force outward and pull out injection timing device (18) with combination pliers.
Screw plug with gasket (11) . . . . .	remove from injection pump (1).
Injection pump (1) . . . . .	turn with splined wrench (027) and lock with locking bolt (023). <b>Caution!</b> Remove locking bolt.
Engine . . . . .	manually turn 1 revolution and check TDC mark crankshaft-camshaft.
Start of delivery . . . . .	check (07.1-I 12), adjust if required (07.1-117).

**Special tools**



**Note**

Up to the production breakpoints mentioned it is necessary to install a gasket with oil pocket when replacing the gasket (67a) of the vacuum pump.

As of the production breakpoint a gasket without oil pocket has been installed.

**Production breakpoint: May 1986**

---

Engine model designation	Transmission	
602.911	manual	019187
	automatic	004738

---

**Note**

The assembly cage (18a) and the fixing bolts (13b) on the timing device drive are deleted on the 602 engine.

**Production breakpoint: September 1989 (assembly cage deleted)**

---


Model	Engine	Engine end no.	
		Manual transmission	Automatic transmission
201.126	602.911	085358	016711

---

## Removal, reinstallation


- 1 Remove cylinder head cover.
- 2 Mark camshaft sprocket and injection timing device with paint relative to the timing chain.

Camshaft sprocket




- 3 Remove center mounting bolt (19) by counterholding the crankshaft.

**Caution!**  
**LEFT-HAND THREAD**




- 4 Remove camshaft sprocket bolt from camshaft while counterholding the crankshaft.


Tightening torque 45 Nm.



- 5 Turn engine to 15° ATDC of 1st cylinder.




6 Remove camshaft sprocket and chain tensioner (156) to loosen the timing chain (05-310).



7 Pull out locking pin (arrow) and remove assembly cage.

**Note**  
 Assembly cage is deleted on all engines, see table.


impact puller  
 Special tool 116 589 20 33 00  
 Threaded pin M 6  
 Special tool 116 589 01 34 00




8 Force timing chain with sheet metal strip to the outside and pull out injection timing device with combination pliers.

Self-made sheet metal strip

Thickness	approx.	0.5 mm
Length	approx.	140mm
Width	approx.	70 mm




9 Remove screw plug (11).



10 Turn injection pump with splined wrench (027) on the injection pump camshaft until the lug of the governor is visible in the bore. In this position insert locking bolt (023) and engage in the lug, then tighten union nut by hand.

027 Splined wrench  
Special tool 601 589 00 08 00



11 Install injection timing device. Secure central mounting bolt (**left-hand thread**) to 40-50 Nm (observe paint mark).


**12 Remove locking bolt (023)** in order to avoid damage to the injection pump during starting.

13 Reassemble engine.

14 Manually crank engine 1 revolution and recheck TDC mark of crankshaft and camshaft.

15 Check start of delivery with digital tester (07.1-I 12) and correct if required (07.1-I 17).

023 Locking bolt  
Special tool 601 589 05 21 00






## 07.1-241 Reconditioning injection timing device

---

Injection timing device removed (07.1-240).




Bolt (18h) .....	2 off M 6 x 16, remove, reinstall, 15 Nm.
Drive hub (18l) .....	remove, reinstall.
Bolt (18c) .....	2 off M 8 x 16, remove, reinstall, 25 Nm.
Cam (18g) .....	check wear.
Sprocket (18f) .....	check wear.
Bushing (18e) .....	remove, reinstall, check wear.
Segment flange (18b) .....	check wear.
Compression springs (18k) .....	2 off remove, reinstall.
Governor weights (18d) .....	2 off M 8 x 16 remove, reinstall, check wear.



## 07.1-245 Replacing fuel filter

---




Bolt (74) .....	remove, reinstall.
O-ring (76) .....	remove, reinstall, replace.
O-ring (77) .....	remove, reinstall, replace.
Filter (42) .....	remove from the bottom, replace.
Fuel filter upper part (73)	

**Note**

The fuel system is self-bleeding during starting. This is due to the increased delivery rate of the fuel pump and the restrictors in the filter upper part and the injection pump.

Run engine and check for leaks.


Function diagram see 07. 1- 010 section "O".



1074-12138

Fuel filter with additional sealing ring (arrow)

## 07.1400 Electrical wiring diagrams



Engine 602 in model 201


model year 1986

Electrical wiring diagram exhaust gas recirculation

Al p7	Electronic clock/tachometer	S25/9	97 °C Temperature switch (EGR)
A9	A/C compressor	S27/6	Microswitch compressor cut-out (EGR)
A9 kl	Electromagnetic coupling	x29/4	Test coupling TD
A9 i1	Speed sensor	Y22	Electromagnetic actuator (ELR)
A9x	Connector A/C compressor	Y22x	Connector (ELR electromagnetic actuator)
B6	Hall-effect speed sensor	Y27	Switchover valve exhaust gas recirculation
B11/1	Coolant temperature sensor (ELR)	Y28	Switchover valve vacuum control flap
F1	Fuse/relay box	Y29	Switchover valve vacuum transducer (automatic transmission)
E	Coupling	Z	Soldered connector sleeve
U	Coupling	a	Terminal block engine terminal 30/terminal 61 (battery)
K1	Overvoltage protection relay	b	Central electrics, coupling U jack 5
L3	Speed sensor starter ring gear	c	Relay fan, terminal 85, jack 5
L3x	Connector speed sensor starter ring gear	d	Connector 1-pole tail lamp cable harness
N6	Control unit compressor cutout	e	Pressure switch (S31) AC compressor
N8	Control unit ELR	f	Relay fan, terminal 86, jack 4
N37	EGR control unit	g	Washing nozzle heater left
S25/5	Temperature switch 105/115 °C	h	Terminal block interior (X5/1)
S25/6	50 °C Temperature switch		
S25/7	25 °C Temperature switch (EGR)		

### Note

Unidentified grounding points are connected to engine ground or battery ground.




Engine 602 in model 201  
model years 1987 and 1988

Electrical wiring diagram exhaust gas recirculation

A1 p7	Electronic clock/tachometer	S25/9	Temperature switch 97 °C (EGR)
A9	A/C compressor	S27/6	Microswitch compressor cut-out (EGR)
A9 kl	Electromagnetic coupling	x29/4	Test coupling TD
A9 l1	Speed sensor	Y22	Electromagnetic actuator ELR
A9x	Connector A/C compressor	Y22x	Connector (ELR electromagnetic actuator)
B6	Hall-effect speed sensor	Y27	Switchover valve exhaust gas recirculation
B11/1	Coolant temperature sensor (ELR)	Y28	Switchover valve vacuum control flap
F1	Fuse/relay box	Y29	Switchover valve vacuum transducer (automatic transmission)
E	Coupling	Z	Soldered connector sleeve
U	Coupling	a	Terminal block engine terminal 30/terminal 61 (battery)
K1/1	Overvoltage protection relay	b	Central electrics, coupling U jack 5
L3	Speed sensor starter ring gear	c	Relay fan, terminal 85, jack 5
L3x	Connector speed sensor starter ring gear	d	Connector 1 -pole tad lamp cable harness
N6	Control unit A/C compressor cut-out	e	Pressure switch (S31) A/C compressor
N8	Control unit ELR	f	Relay fan, terminal 86, lack 4
N37/2	Control unit exhaust gas recirculation	g	Washing nozzle heater left
S25/5	Temperature switch 105/115 °C	h	Terminal block interior (X5/1)
S25/6	Temperature switch 50 °C		
S25/7	Temperature switch 25 °C (EGR)		

**Note**

Unidentified grounding points are connected to engine ground or battery ground.



1072-16677


Engine 602 in model 201  
 model year 1989  
 Electrical wiring diagram exhaust gas recirculation

A9	A/C compressor	W10	Ground, battery
A9 kl	Electromagnetic coupling	X25	Connector, preglow wiring harness
A9 l1	Speed sensor	x35	Terminal block, battery terminal 30/61
A9x	Connector A/C compressor	X92	Diagnostic test coupling
B1 l/1	Coolant temperature sensor (ELR)	Y22	Electromagnetic actuator ELR
F1	Fuse/relay box	Y22x	Connector (ELR electromagnetic actuator)
G1	Battery	Y27	Switchover valve exhaust gas recirculation
K1/1	Overvoltage protection relay 87E (7-pole)	Y28	Switchover valve vacuum control flap
L3	Speed sensor starter ring gear	Y29	Switchover valve vacuum transducer
L3x	Connector speed sensor starter ring gear	a	To temperature switch S25/6
N6	Control unit A/C compressor cut-out	b	To washer nozzle heating left R2/2
N8	Control unit ELR	c	To connector engine cable harness X26/5
N37/2	Control unit exhaust gas recirculation	d	To pressure switch A/C compressor S31/1
S2/2	Glow starter switch		
S25/7	Temperature switch 25 °C (EGR)		
S25/9	Temperature switch 97 °C (EGR)		
S27/6	Microswitch compressor cut-out (EGR)		

**Note**

Unidentified grounding points are connected to engine ground or battery ground.

## 07.1-500 Vacuum diagrams



Engine 602 in model 201


Model year 1986

Vacuum circuit diagram exhaust gas recirculation

	Injection pump	Y22	Electromagnetic actuator ELR
2	Governor	Y27	Switchover valve EGR
5	ADA unit	Y28	Switchover valve vacuum control flap
6	Vacuum unit (stop)	Y29	Switchover valve (automatic transmission)
60	EGR valve	a	Ventilation to vehicle interior
61a	Choke blue	b	Key cut-out
61b	Choke orange	c	Remaining users
62	Filter	d	Vacuum unit automatic transmission
62c	Ventilation filter		
65	Vacuum control valve		
67	Vacuum pump		
72	Damper		
99	Vacuum control flap		
100	Vacuum unit/vacuum control flap		
123	Transducer		







1072-14047/2

Engine 602 in model 201

Model year 1989

Vacuum circuit diagram exhaust gas recirculation

	Injection pump	Y22	Electromagnetic actuator ELR
2	Governor	Y27	Switchover valve EGR
4	PLA unit	Y28	Switchover valve vacuum control flap
5	ADA unit	Y29	Switchover valve (automatic transmission)
6	Vacuum unit (stop)	a	Ventilation to vehicle interior
60	EGR valve	b	Key cut-out
61a	Choke blue	c	Remaining users
61b	Choke orange	d	Vacuum unit automatic transmission
61c	Choke 0.5 mm orifice diameter	e	Brake booster
61d	Connector		
62	Filter		
65	Vacuum control valve		Vacuum connections on vacuum transducer
67	Vacuum pump	VAC	Vacuum from vacuum pump
72	Damper	v c v	To vacuum control valve
99	Vacuum control flap	ATM	Ventilation to vehicle interior
100	Vacuum unit/vacuum control flap	EGR	Exhaust gas recirculation to exhaust gas recirculation valve
123	Transducer		
140	Check valve brake booster		

## **Diesel injection system - Turbodiesel Engines - 07.1**



Job No.

Survey • injection pumps • Turbodiesel	07.1 – 001
Survey • injectors • Turbodiesel	07.1 – 002
Explanation of injection pump type plate • Turbodiesel	07.1 – 003
Function • injection system • Turbodiesel	07.1 – 010
Testing, adjusting idle speed • Turbodiesel	07.1 – 100
Testing electronic idle speed control with test connector (X92 and XI 1/4)• Turbodiesel	07.1 – 105
Testing, tuning engine • Turbodiesel	07.1 – 110
Testing start of delivery (position sensor RIV method) • Turbodiesel	07.1 – 111
Testing startof delivery - digital tester (RIV method) • Turbodiesel	07.1 – 112
Establishing fuel consumption by road test • Turbodiesel	07.1 – 113
Setting start od delivery (position sensor RIV method) following test • Turbodiesel	07.1 – 116
Setting start of delivery with digital tester (RIV method) following testing • Turbodiesel	07.1 – 117
Testing fuel pump • Turbodiesel	07.1 – 145
Testing fuel pressure (after testing fuel delivery) • Turbodiesel	07.1 – 146
Testing vacuum engine stop for leaks • Turbodiesel	07.1 – 150
Testing vacuum pump • Turbodiesel	07.1 – 160
Testing and setting vacuum control valve for automatic transmission • Turbodiesel	07.1 – 170
Testing control rod travel sensor • Turbodiesel (Model Year 1986/7 only)	07.1 – 180
Testing electronic diesel system (EDS) • Turbodiesel	07.1 – 190
Removal and installation of injection pump • Turbodiesel	07.1 -200
Replacing delivery valve seal • Turbodiesel	07.1 – 210
Replacing vacuum unit • Turbodiesel	07.1 – 220
Replacing actuator of electronic idle speed control (ELR) • Turbodiesel	07.1 – 225
Removal and installation of injectors • Turbodiesel	07.1 – 230
Testing injectors • Turbodiesel	07.1 – 231
Reconditioning injectors (after testing) • Turbodiesel	07.1 – 232
Removal and installation of fuel pump • Turbodiesel	07.1 – 235
Removal and installation of injection timing device- Turbodiesel	07.1 – 240
Reconditioning injection timing device • Turbodiesel	07.1 – 241
Replacing fuel filter • Turbodiesel	07.1 – 245
Retrofitting damper with restriction orifice • Turbodiesel	07.1 – 250
Electrical Wiring Diagrams • Turbodiesel	07.1 – 400
Vacuum Circuit Diagrams • Turbodiesel	07.1 – 500

## 07.1-001 Survey - injection pumps - Turbodiesel

---

### Survey of injection pumps

Engine	Injection pump Bosch designation	Part No.	Bosch combination No.	Test data MB sheet	Issue
--------	-------------------------------------	----------	-----------------------	--------------------	-------

602.96	PES 5 M 55 C 320 RS 158	602 070 13 01	0 400 075 980	2.5 g	01.04.87
603.96	PES 6 M 55 C 320 RS 157	603 070 10 01	0 400 076 992	3.0 w	02.04.87
602.962 <sup>1)</sup>	PES 5 M 55 C 320 RS 177	602 070 45 01	0 400 075 944		
603.970 <sup>1)</sup>	PES 6 M 55 C 320 RS 178	603 070 32 01	0 400 076 968		

<sup>1)</sup> from 09/89.

---

Delivery pump Bosch designation  
FP/KG 24 M 150 is identical on all engines.

**Note**

**It is only possible to properly inspect and set an injection pump on an injection pump test stand.** Test data on microfilm for the various injection pumps are available for repair shops which possess such a test stand.

## 07.1-002 Survey - injectors - Turbodiesel

---

### Injection nozzles/Nozzle holder

Engine		602.96	603.96197 <sup>3)</sup>
Injection nozzle	Bosch designation	DN 0 SD 265	DN 0 SD 265
	MB Part No.	001 017 49 12	001 017 49 12
Nozzle holder	Bosch designation	KCA 27 S 55 <sup>2)</sup>	KCA 30 S 44 KCA 27 S 55 <sup>2)</sup>
	MB Part No.	002 017 40 21 <sup>2)</sup>	002 01728 21 002 01740 21 <sup>2)</sup>
Ejection pressure when injection nozzles are or opening pressure in bar <sup>1)</sup>	new	135- 145	135- 145
	when injection nozzles are used, at least	120	120

<sup>1)</sup> The difference in ejection pressure of the injection nozzles within an engine must not be greater than 5 bar gauge pressure.

<sup>2)</sup> With oblique injection.

<sup>3)</sup> Engine 603.97 only oblique injection.

## 07.1-003 Explanation of injection pump type plate - Turbodiesel

e.g. **PES 5 M 55 C 320 RS 158/1**


<b>P</b>	Pump
<b>E</b>	Self-driven
<b>S</b>	Face flange mounting
<b>5</b>	Number of cylinders
<b>M</b>	Pump size
<b>55</b>	Element diameter in 1/10 mm
<b>C</b>	Modification code letter
<b>320</b>	Installation index
<b>R</b>	Direction of rotation
<b>S158/1</b>	Special version

### RSF

<b>R</b>	Governor
<b>S</b>	Helical spring
<b>F</b>	Drive control

### Location of components with ELR


1	Injection pump
1b	Type plate
2	Governor
3	Fuel pump
6	Stop unit
65	Vacuum control valve
103	ALDA unit
Y22	ELR actuator
L7	Control rod travel sensor (connector not operational with cap closed)





Location of components with ELR

- 1 Injection pump
- 2 Governor
- 3 Fuel pump
- 6 Stop unit
- 103 ALDA unit
- Y22 ELR actuator




## 07.1-010 Function - injection system - Turbodiesel

---

### A. Lubrication of injection pump


The injection pump is connected through an oil passage (arrow) to the engine oil circuit. The oil flows back into the crankcase through the annular gap (x) between bearing and housing.

The O-ring (10) on the flange (1 a) acts as a seal. The drilling (y) serves to relieve oil from the radial seal.



## B. Fuel circuit


### a) Fuel circuit diagram



P07-0496-57

3	Injection pump	73a	Restriction orifice in fuel filter top section $\varnothing 0,8$ mm
15	Fuel pump	86	Fuel thermostat open, position up to + 8 °C, fuel is preheated
30	Bypass valve with restriction $\varnothing 1,5$ mm	86a	Fuel thermostat closed, position from + 25 °C, fuel is no longer preheated
43	Injection nozzles	87	Inlet line - cold fuel
50	Fuel prefilter	87a	Return line - preheated fuel
54	Fuel leak-off hose	148	Heater inlet pipe with fuel heat exchanger
63	Injection line, No. 1 cylinder		
73	Fuel tank		


## b) Low-pressure side



P07-0495-57

3	Injection pump	80	Return line
15	Fuel pump	81	Fuel hose return line
27	Bypass valve with restriction $\varnothing$ 1,5 mm	82	Fuel filter inlet line
42	Hollow screw	83	Injection pump inlet line
43	Fuel filter	84	Hose clip
44	Fuel prefilter	86	Fuel thermostat
50	Fuel leak-off hose	87	Fuel heat exchanger inlet line
52	Plug	87a	Fuel heat exchanger return line
73	Fuel filter top section	88	Fuel thermostat inlet line
74	Fuel filter hollow screw	89	Fuel pump suction line
76	O-ring	131	Plastic holder
77	Fuel filter seal	148	Heater inlet pipe with fuel heat exchanger
78	Seal		

c) High-pressure side



P07-0494-57

30	Injection nozzle - complete	64	Bracket, cylinder 4, nozzle end
52	Plug	64a	Bracket, cylinder 4, injection pump end
53	Nozzle shim	64b	Bolt
54	Injection line 1	66	Linemounting bracket
55	Injection line 2	68	Plastic clips for 3 lines
56	Injection line 3	68a	Plastic clips for 2 lines
57	Injection line 4	69	Rubber base
58	Injection line 5	70	Plastic holder for 3 lines
59	Injection line 6	71	Plastic holder for 2 lines


**Note**

Injection lines for cylinders 2-6 are not illustrated.  
Bracket for injection lines of cylinders 5-6 as  
bracket of cylinder 4.

### C. Fuel prefilter (43)

Installed in the suction line upstream of the fuel pump (3). The filter housing is of transparent plastic.


The mesh size is 600  $\mu\text{m}$  (0.6 mm).



### D. Fuel filter (42)

The fuel filter is installed in the pressure line between fuel pump and injection pump.  
The paper filter element is integrated in a metal housing. The element has a mean pore width of 6-10  $\mu\text{m}$  (0.006-0.01 mm).

- 42 Filter
- 73 Fuel filter top section
- 74 Bolt
- 76 O-ring
- 77 Sealing ring (alu)




#### Note

When the engine is started, the fuel system is bled automatically due to increased delivery of the fuel pump and the restrictions in the top section of the filter as well as at the injection pump.

## E. Fuel preheater (148)

A heat exchanger (148) is installed in the inlet line of the heater in order to preheat the fuel.

Heat exchanger  
C Inlet line  
D Return line  
E Heater inlet  
148 Heat exchanger




### Function

Full preheating up to + 8 °C fuel temperature; the required fuel is drawn in through the heat exchanger by the fuel pump.

From + 8 °C to + 25 °C mixed operation; the required fuel flows partially through the heat exchanger.

Above + 25 °C the heat exchanger is bypassed by the thermostat; the fuel is drawn in directly by the fuel pump. Fuel preheating ensures trouble-free operation with winter-grade diesel fuel as a rule down to approx. -25 °C ambient temperature.


- Fuel thermostat
- A Inlet line from fuel tank
  - B Suction line to fuel pump
  - C Inlet to heat exchanger
  - D Return line from heat exchanger



## F. Fuel pump (3)

As a result of the high delivery of the fuel pump, the fuel system is self bleeding, which eliminates the need for a hand priming pump. Delivery  $> 150 \text{ cm}^3/30 \text{ s}$ , at a starting speed  $> 150/\text{min}$ , measured in the fuel return line.

- E Pressure side
- D Suction side







A restriction in the bypass valve at the injection pump is required for bleeding the injection pump.

Bypass valve with restriction 1,5 mm dia.  
(arrow).


The bypass valve prevents unfiltered fuel flowing along the return line into the injection pump if the inlet line is clogged (e.g. filter).



Restriction with bypass valve  
a Housing  
b Ball  
c Spring  
d Slide  
e Inlet  
f Restriction orifice 1,5 mm dia.

## G. Start of injection adjusting equipment


An adjusting device (arrow) is attached to the injection pump flange in order enabling adjustment of the start of delivery while the engine is running.



## H. Reverse flow damping valve in delivery valve holder



Reverse flow damping valves (7b) are installed in the delivery valve holders (7) of the injection pump in order to reduce the hydrocarbon content in the exhaust gas through prevention of afterspraying of the injection nozzles.

Two annular grooves act as identification marks on the delivery valve holder (7) (arrows). The reverse flow damping valve (7b) is a disc valve (7c) opening in the direction of the injection nozzle with a restriction orifice of 0.5 mm dia.. The valve seat (7d) is riveted into the delivery valve holder.



## I. Timing device

The time device is mounted on the injection pump shaft and is attached with a central bolt having a **left-hand thread**.



Timing device adjustment curve  
 $n$  = rpm of injection pump  
 $PW^\circ$  = Adjustment angle of injection pump


## J. RSF governor

### a) Design and operating principle


The governor is a minimum/maximum speed governor. Its governor spring (2m) is sized and set in such a way that it does not govern in the part load range, with the exception of torque control (refer to "Control when starting and at full load").

In the part load and full load range, the control rod (2t) of the injection pump is operated only from the accelerator pedal, which is connected through the accelerator control linkage to the control lever (2g) of the governor.

The position spring (2n) is pretensioned and the position speed set by the adjusting screw (3).



- 2 Governor
- 2a Guide lever
- 2b Stop screw for position quantity
- 2c Relay lever
- 2d Fulcrum lever
- 2e Spring retainer (torque control)
- 2f Full load adjusting screw
- 2g Control lever
- 2h Sliding sleeve
- 2i Flyweights (pump governor group)
- 2l Position auxiliary spring cutoff
- 2k Adjusting screw for position auxiliary spring (position stabilizer)
- 2l Tensioning lever
- 2m Governor spring
- 2n Position spring
- 2o Position auxiliary spring (position stabilizer)
- 2p Steering arm
- 2r Stop lever
- 2s Emergency stop lever
- 2t Control rod
- 3 Adjusting screw for position speed
- 3a Locking nut
- 6 Vacuum unit (stop)




## b) Control positions

Control lever (2g) rests against the idle stop screw (2b). As the engine speed increases, the sliding sleeve (2h) passes through the idle position. Guide lever (2a) swivels around the pivot point "A" and thus operates against the idle spring (2n).

At a certain engine speed, the guide lever (2a) moves against the adjusting nut of the idle auxiliary spring (2o). The movement of the sliding sleeve (2h) is transmitted through the relay lever (2c) and fulcrum (2d) in the same direction to the control rod of the injection pump. After passing through the idle position, the sliding sleeve (2h) moves against the spring retainer (2e).


If the engine speed increases further (e.g. deceleration), above a certain engine speed, the spring retainer (2e) is over-compressed followed by the governor spring (2m). The control rod is thus brought into the "stop position" (deceleration fuel cutoff).



- a Start
- b Stop
- c Position stage

### c) Control with actuator


The lift rod (163) rests against the guide lever (2a). The actuator (Y22) is supplied by the electronic idle speed control unit with a clocked D.C. voltage in the frequency range of approx. 50 Hz. If engine speed drops (e.g. drive position engaged or power steering turned to full lock), the actuator is energized with a higher voltage. This causes the lift rod (163) to press against the guide lever (2a) and the control rod (2t) to move in the direction "a" **increased quantity**. As soon as the engine speed increases, the voltage is reduced and the control rod (2t) moves in the direction of "b" **reduced quantity**.



- 161 Seal
- 162 Electrical connection
- 163 Lift rod
- 164 Solenoid coil

### d) Start position

If the control lever (2g) is moved against the full load stop (c) (fixed stop on governor housing) when the engine is not running, the relay lever (2c) moves around pivot point "B" and moves the fulcrum lever (2d) with it in the direction of Start. When the control lever is in the full load position (2g "Full throttle") the idle auxiliary spring (2o idle stabilizer) is pressed away from the guide lever by the idle cutoff auxiliary spring (2j). This enables a more rapid cutoff from the start position of the governor.




- a Start-t
- b stop

### e) Full load speed regulation/ compensation

After passing through the idle step (c) (refer to ill. of control when at idle) the governor sleeve (2h) moves against the spring retainer (2e). This causes the relay lever (2c) and fulcrum lever (2d) to move the control rod of the injection pump into the full load position.

When a certain engine speed is reached, the spring retainer (2e) is over-compressed by a certain distance (d) (compensation).


If the engine speed continues to rise, the force of the flyweights is sufficient to over-compress the governor spring (2m) (full load speed regulation). The start of cutoff depends on the preload of the governor spring (2m).



### f) Engine stop

The vacuum unit (6) is pressurized with vacuum from the vacuum pump through the glow start switch of the vehicle. This causes the diaphragm of the vacuum unit to move against the compression spring.


The vacuum unit (6) is connected to a stop lever (2r), which swivels about the pivot point "D", pulling the control rod of the injection pump into "Stop" position. This causes the deflecting spring of the fulcrum lever to be over-compressed. The control rod can be pulled into the "Stop" position from the outer side of the governor in the same way by means of the emergency stop lever (2s).



a Start  
b Stop

## K. Intake manifold pressure compensator(ALDA)

The intake manifold pressure compensator (ALDA device) is comprised of a housing (103) with barometer unit (103b). The absolute pressure acts upon the barometer units through a port (103a) to the charge air pipe of the engine. Accordingly, the barometer units react to each pressure change with a change of length. All movements are transmitted to the compound lever of the governor and to the control rod. As the absolute pressure drops, the barometer units expand. The correction linkage (103c) of the units is pressed downwards and acts on the compound lever to move the control rod in the direction of "reduced quantity". As the absolute pressure rises, caused by a higher air and/or charge pressure, the movement is performed in the opposite direction - i.e. in the direction of "increased quantity". As the effect of the ALDA device diminishes, the more the control lever is moved in the idle direction. When the control lever is in the idle position, the effect is approximately zero.




103d Adjusting screw  
(factory-set by manufacturer)

### Absolute pressure with charge operation

The intake air under atmospheric pressure is further compressed by the turbocharger. Atmospheric and charge pressure together produce the absolute pressure prevailing in the charge air pipe of the engine.


- n<sub>l</sub> Speed at the start of charge operation
- a Atmospheric pressure, corresponding to suction quantity
- b Charge pressure
- c Absolute pressure, corresponding to charge quantity
- n Engine speed
- p Pressure in bar



## L. Control rod travel sensor (L7)


The control rod travel sensor is installed in the governor of the injection pump. It consists of an iron core, two coils (measured value and fixed value coil) and two short-circuit rings. It is connected to the electronic control unit by a 3-pin plug.

The coils (b) and (d) are attached to the iron core (a) which is fixed in the housing. The short-circuit ring (e) is connected to the control rod (2t) and is displaced with the control rod without touching on the bottom leg of the iron core. The fixed value coil (b) and the short-circuit ring (c) are attached to the top leg.



### Function

The fixed value coil (b) with the short-circuit ring (c) represents a constant inductance. Depending on the change in position of the control rod (2t), the distance between the short-circuit ring (e) and measuring coil (d) changes. The variable inductance produced is then compared to the constant inductance. From this the electronic unit determines the control rod travel.





## M. Reference impulse verification(RIV)

Two signals are required for checking start of delivery when the engine is running (dynamic).


- TDC pulse from the crankshaft
- Reference impulse from the injection pump

Both pulses are supplied by pulse generators. To obtain a signal, the generator pins must be moved past the pulse generators at a minimum rate (position speed).

A measuring instrument measures the time gap of the two pulses and converts the result into an angular value, which is then indicated.

### Note

The position sensor can be used, as for naturally aspirated engines, for checking the start of delivery when the engine is not running (stationary).



P07-0453-57

001	Digital tester	016	Diagnostic socket
2	Governor (Injection pump)	017	RI generator
2i	Flyweight with RI generator pin	021	TDC generator
015	Test cable	59	TDC generator pin


## N. Electronic position speed control (ELF?)

### Function

The engine speed sensor (L3) detects engine speed (144 pulses/revolution) and passes this to the control unit (N8) in the form of an alternating voltage.

This processes the speed signal and performs a set/actual value comparison. Position speed is maintained at a constant level by the actuator (Y22) irrespective of engine load.

Set position speed is raised in accordance with a specified characteristic curve by the temperature sensor (B11/1) at coolant temperatures  $< 60\text{ }^{\circ}\text{C}$ .



### System diagnostics (Engine 602)

The ELW system can be tested by means of the self-test routine integrated into the control unit. A signal can be retrieved with the test connector (X92 or XI 1/4), which provides concrete information regarding a component fault. The number of signals indicates whether and which component is faulty, or whether the components in the control loop are faulty.

### Note

Engine 603 is fitted with the control unit having system diagnostics as of a later date.


### Production breakpoint:

Control unit with "RO2" 05188.

Pulse read out	Component
1	All functions "in order"
2	Engine speed signal "fault"
3	Coolant temperature "fault"
6	ELR control loop "fault" <sup>1)</sup>

<sup>1)</sup> Only short-circuit faults are detected on control units with the designation "RO1". Control units with "RO2" also detect interrupt.


## Location of components



**B11/1** Coolant temperature sensor  
**K1/1** Overvoltage protection  
**L3** Engine speed sensor  
**L3x** Engine speed sensor plug connection

**N8/1** ELR control unit  
**x92** Test connector  
**Y22** ELR actuator

## ELR block diagram




## O. Facet pintle nozzle

Bosch Designation DN 0 SD 265

The facet pintle nozzle differs from the pintle nozzle in having an oblique face angled at approx.  $6^\circ$  (arrow) on the throttling pintle (41), which improves the throttling effect.

- 31 Nozzle needle
- 32 Nozzle body
- 41 Throttling pintle
- 44 Spray pintle





## P. Nozzle holder

Bosch Designation:

KCA 27 S 55, for oblique injection

KCA 30 S 44, for vertical injection

The thickness of shim (40) determines the pre-load of the compression spring (36) and thus the opening pressure of the injection nozzle. The opening pressure can be set by fitting shims of different thicknesses. The fuel flows to the nozzle seat through the respective inlet orifice (a) in the holder (37), intermediate disk (33) and injection nozzle. During the injection process, the injection pressure raises the nozzle needle, and fuel flows through the annular orifice at the throttling pintle into the pre-chamber. Once the injection pressure drops, the compression spring (36) pushes the nozzle needle (31) back down onto its seat; the Injection process is completed.



Nozzle holder KCA 27 S 55

(for oblique injection)

31 Nozzle needle

32 Nozzle body

33 Intermediate disk

34 Pressure pin

35 Nozzle tensioning nut

36 Compression spring

37 Holder

38 Fuel bypass port

40 Shim

45 Inlet orifice


a Fuel inlet

b Leak fuel (return)

## Q. Oblique Injection

The nozzle holder combination is fastened to the top section of the prechamber tilted at 5° relative to the longitudinal axis of the prechamber. This oblique Injection produces a more intensive mixing of air and fuel.

- R9 Glow plug
- 109 Sealing sleeve
- 110 Prechamber
- 112 Threaded ring
- 113 Sealing shim
- 114 Nozzle holder



**Together with the prechamber modification, the following additional benefits result:**


- Improved cold start
- More favorable air/fuel mixing as a result of shorter glow plug (now 23 mm was previously 25 and 27 mm) in combination with recess and the concave in the ball pin.
- Particle reduction and improvement in the emission of hydrocarbons and carbon monoxide.

## R. Injection lines

The injection lines are designed so as to allow the injection pump to swivel when the engine is running.

### Note



The plastic clips (68 and 68a) must be fitted as close as possible to the radius of the injection lines (arrows). The plastic clips (71) must be locked in place.





## S. Vacuum engine stop with car key (glow start switch)

The vacuum for the key-operated engine stop is supplied by the check valve (140) of the main vacuum line.



### Vacuum line routing

1	Injection pump	A	Intermediate panel
6	Vacuum unit (stop)	c	Other ancillaries
61c	Valve, glow start switch	e	To brake booster
67	Vacuum pump		
140	Check valve/main vacuum line		


## **T. Electronic diesel system (EDS)**

The electronic control unit processes the following functions:

- a) Electronic idle speed control (ELR)
- b) Exhaust gas recirculation (EGR)
- c) Recirculating air control for trap oxidizer, (California Engine 603.96 Model Year 1986/87 only).
- d) Charge pressure control (P2 control) Engine 602.962 from Model Year 1990.
- e) System diagnostics

The control unit processes the incoming signals and supplies a current (mA) to the vacuum transducer, as well as to the actuator of the injection pump. The entire system is tested by means of a signal to other outlets, which merge into a test connector.


Influencing variables of Electronic Diesel System (EDS) Engine 602.96 and 603.96




1) Model Year 1986/187 only

2) Effective Model Year 1988 Integrated in control unit.

Influencing variables of electronic diesel system(EDS) Engine 603.970  
from Model Year 1990



**Influencing variables of Electronic Diesel System (EDS) Engine 602.962  
from Model Year 1990**




\* Pressure in front of inlet valves

**a) Electronic idle speed control (ELF?)**

A speed sensor detects the engine speed (144 pulses/revolution) and passes it on to the EDS control unit in the form of an alternating voltage. The EDS control unit processes the speed signal and performs the set value/actual value comparison. This enables idle speed to be maintained at a constant level by the actuator irrespective of engine load. Set idle speed is raised in accordance with a fixed characteristic curve by the temperature sensor at coolant temperatures  $< 60^{\circ}\text{C}$ .

**Block diagram of idle speed control (ELR)**



### b) Exhaust gas recirculation (EGR)

Exhaust gas recirculation is initiated as soon as the following conditions are met:

- Coolant temperature between 60°C and 110°C
- Engine speed between idle and 2800 rpm or 3500 rpm on Engine 602.962 from Model Year 1990
- Control rod travel less than 9 mm
- Battery voltage 1 l-1 4 Volts

Depending on the input signals of the sensors e.g. control rod travel, engine speed etc., the EDS control unit determines the matching quantity of recirculated exhaust gas for each operating state. The vacuum transducer is energized and supplies the corresponding vacuum to the EGR valve.


The EGR quantity is reduced as engine load and speed increase. This means  
Increase in the control current = increase in EGR quantity.

Reduction in control current = reduction in EGR quantity.

#### Note

Temperature and engine speed are dependent on the control unit version. Refer to test routine for exact data.

### Block diagram EGR




The EGR system with EGR valve, vacuum transducer, air flow sensor and EDS control unit operates as a closed control loop.

**c) Recirculating air control for trap oxidizer  
(California Engine 603.96 Model Year  
1986/87 only)**

In order to achieve improved combustion conditions for the trap oxidizer, the recirculating air valve is continuously opened or closed according to a performance characteristic map.

Following the closing operation, a residual vacuum of approx. 30 mbar is retained at the recirculating air valve. The recirculating air valve is open between 1000 and 3400 rpm. The control rod travel must be less than 9 mm.

**Block diagram recirculating air control**





**d) Charge pressure control (P2 control)**  
**Engine 602.962 from Model Year 1990**

A “**characteristic map**” (P2 control) is stored in the **EDS** control unit. The pressure values obtained as a function of injection quantity and engine speed produce an optimum engine operation with respect to **performance**, **NQ**, **HC** and **particle emissions**.

**Function**

---

Particle emissions are lowered by reducing the pressure (P2) in front of the intake valves under part load conditions.

A control circuit exists in the EDS control unit through which a pressure comparison of “P2 **actual**” and “P2 **reference**” is performed (refer to block diagram).


Any pressure difference is compensated for by the charge pressure control valve or by the pressure control flap.

These pressure actuators are operated by the vacuum transducers by means of an electronically adjustable vacuum.

**Charge pressure control is dependent on:**

- Coolant temperature
- intake air temperature
- Intake air pressure
- Engine speed
- Position of control rod (control rod travel)

Block diagram charge pressure control (P2 control), Engine 602.962 Model Year 1990



### e) System diagnostics

The "electronic diesel system" can be checked for component faults respectively and stored by means of the self-test routine integrated in the EDS control unit.

Temporary faults, which last longer than 4 seconds, are also stored.

E.g. sensor faults with the exception of speed sensors are memorized, as well as short-circuits in the actuators or their lines.

The pulse display can be tapped via the test connector (XI 1/4), socket 4 and the individual faults evaluated with the aid of a pulse counter.

Depending on the readout, the defective component or its leads can be determined.

Model Year 1986/87

EDS control unit **with** fault detection.

Only permanently occurring faults are detected.

### f) Location and function of components

#### Model Year 1986/87

Test connector (X92) is used for diagnostics.

The diagnostic test signal can be taken from the test connector.

Models 124 and 201 in  
component compartment  
right

.....  
Modul13    Format 1 ,0    (77 × 58 mm)

\_\_\_\_\_  
Bild-Motiv

\_\_\_\_\_  
Foto/Zg-Nr.

\_\_\_\_\_  
Abgabe


\_\_\_\_\_  
Korrektur

\_\_\_\_\_  
Freigabe

\_\_\_\_\_  
Bild-Nr.    **P07-2467- 13**

.....


Model 126



## Function of components


### Control unit (N39)

The control unit processes the incoming signals and supplies a current (mA) to the pressure converter, EGR switchover valves, as well as to the actuator of the injection pump. The entire system can be tested by means of a signal passed through four other outlets merging into a test connector.




Model 124 behind battery in component compartment


Model 126 in right foot well behind side panelling




Model 201 behind the battery in  
components compartment



Model 124. 128  
(Engine 602.962)



Model 126.13  
(Engine 603.970)  
Installed on the right in the  
passenger compartment




### Altitude sensor (integrated in control unit) from Model Year 1990

The quantity of recirculated exhaust gas is influenced by the atmospheric pressure sensor as a function of altitude or air pressure. The altitude sensor supplies a voltage signal to the control unit which drops as air pressure drops (increasing altitude). The control unit matches the quantity of exhaust gas recirculated to the respective air pressure by reducing the pressure converter current.


### Over-voltage protection (K1 or K1/1)

The power for the electronic control units is supplied through the over-voltage protection relay.

Models 124, 201 behind the battery  
in the component compartment



The battery voltage is supplied constantly to terminal 30. A 10A fuse is fitted between terminal 30 and 30a. The fault memory is constantly energized through terminal 30a. When the ignition is switched on, the relays are actuated through terminal 15 by an electronic unit. The EDS control unit is thus energized through terminal 87E and other ancillaries through terminal 87. The over-voltage protection is achieved by means of a 22 volt Zener diode. Voltage peaks in excess of 22 volts occurring ahead of the over-voltage protection are switched directly to ground by the Zener diode. An overload is prevented by a fuse. Terminals 87E and 87L are protected separately.




Model 126 in component compartment next to ABS control  
unit


**Altitude sensor (B18)**

**Model year 1986/87**

The quantity of exhaust gas recirculated is influenced by the altitude correction sensor as a function of altitude or air pressure. The sensor supplies a voltage signal to the control unit which drops as air pressure drops (increase in altitude). The control unit matches the quantity of exhaust gas recirculated to the air pressure by reducing the pressure converter current.




Model 124, 201 in component compartment



Model 126 in right footwell

**Air flow sensor potentiometer (B2/1)**

Fitted in the air flow between air filter and exhaust gas turbocharger.




- A from air filter
- B to exhaust gas turbocharger

The intake air deflects the air flow sensor flap against the restoring force of a spring into a defined angular position. The position is measured by means of a potentiometer, and converted into a voltage.

The intake air temperature is detected by a temperature sensor (B2/1a) in the air flow sensor.


Air flow sensor  
Model 201 without round flange




### Resistance trimming plug (R18/1) for idle speed

For setting the idle speed.  
Specification:  $630 \pm 20$  rpm


Model 124



Model 126




Model 201






**Reference resistor (R18/2) for exhaust gas recirculation**


Model 124 in components compartment



Model 126 at right of car  
Interior next to control unit  
(N39)





Model 201 in component  
compartment next to battery




### Vacuum transducer (Y31/1, Y31/2 and Y31/3)

The vacuum transducers are supplied with a control current as an input signal depending on the operating state. The pressure converter then supplies the matching vacuum for the actuators.


- Engine 602.962 Model Year 1990
- Y31/1 Vacuum transducer • EGR valve
- Y31/2 Vacuum transducer • pressure control flap
- Y31/3 Vacuum transducer • charge pressure control



Engine 603.96 in Model 124




Engine 603.96/97  
Y31/1 Vacuum transducer EGR  
valve in Model 126



Engine 602.96 in Model 201


### Engine speed sensor (L3)

It detects engine speed at the starter ring gear (144 pulses/revolution) and sends it to the control unit in the form of an alternating voltage.




### Test connector (X11/4)

The pulse display can be tapped by the test connector.




Model 124



Model 126

### Coolant temperature sensor EDS (B11/4)


The coolant temperature is detected by the temperature sensor (EDS) (B11/4) and is actuated by the EDS control unit. The resistance of a coolant temperature sensor EDS varies as a function of coolant temperature.



## EGR valve

The EGR valve is bolted to the mixing pipe on the side of the cylinder head. It is connected to the exhaust manifold, charge air distribution pipe and a corrugated pipe. The EGR valve is opened by means of a controlled vacuum from the vacuum transducer.


- A Exhaust gas to charge air distribution pipe
- B Exhaust gas from exhaust manifold
- a Vacuum connectron
- b Spring
- c Diaphragm
- d Valve



## Cruise control (Tempomat), Model Year 1990

In order not to influence the control of the cruise control in the part load area, the charge pressure is rendered inoperative by the cruise control/charge pressure relay (K12/1) during cruise control operation.



Model 124  
K12/1Cruise control/charge  
pressure shutoff relay



Model 201  
K12/1Cruise control/charge  
pressure shutoff relay

### Pressure sensor (B5/1) Engine 602.962

Fitted right behind the bulkhead in the direction of travel. The pressure sensor detects the pressure and converts it into a voltage, which is processed by the EDS control.





Absolute pressure characteristic (P<sub>abs</sub> in mbar) with 5 V voltage supply

### Mixture housing (94a) with pressure control flap (99) and vacuum unit (100)

(Engine 602.962 only) from Model Year 1990


In order to increase the vacuum in the charge air distribution pipe, a pneumatically operated pressure control flap is fitted to the mixture housing. The pressure control flap closes the fresh air port during engine operation with EGR. A minimum opening (arrows) between the pressure control flap and the mixture housing is maintained. The vacuum unit (100) is actuated by the pressure convertor pressure control flap (refer to function diagram).






- 60 EGR valve
- 100 Vacuum unit

P07-2074-13



Model Year 1990, Engine 602.962

B2/1	Air flow sensor potentiometer with intake air temperature sensor, EDS	Y22	ELR actuator
B5/1	Pressure sensor (EDS)	Y31/1	EGR vacuum transducer
B11/4	Coolant temperature sensor	Y31/2	Pressure convertor - pressure control flap
K1/1	Over-voltage protection relay	Y31/3	Pressure convertor - charge pressure control
L3	Engine speed sensor - starter ring gear	60	EGR valve
L3x1	Plug connector, engine speed sensor - starter ring gear	99	Pressure control flap in mixture housing
L7	Control rod travel sensor	100	Vacuum unit, pressure control flap
x1114	Test connector	137a	Vacuum unit, charge pressure control valve




P07-0470-57

Engine 603.960 in Model 126, Model Year 1986 Federal  
 Engine 602.961 in Model 201, Model Year 1987 Federal

1	Injection pump	S25/6	Temperature switch 50 °C
2	Governor	S66	Switch, engine overload protection
60	EGR valve	Y22	Actuator
61a	Restriction, blue	Y29	Switch-over valve, vacuum amplifier
61b	Restriction, orange	Y30	Switch-over valve, engine overload protection
62	Filter	Y31/1	Vacuum transducer, exhaust gas recirculating valve
62a	Filter	a	Fresh air flow to car interior
65	Vacuum control valve	A	Intake air
67	Vacuum pump	B	Exhaust gas
72	Damper		
103	ALDA unit		
110	Exhaust manifold		
123	Vacuum amplifier		
137	Exhaust gas turbocharger		
138	Charge air distribution pipe		
B2/1	Air flow sensor potentiometer	PRE	Charge pressure from ALDA unit
B2/1a	Intake air temperature sensor	TRA	To vacuum unit of automatic transmission
B11/4	Coolant temperature sensor	VAC	Vacuum from vacuum pump
B18	Altitude sensor	v c v	To vacuum control valve
L3	Engine speed sensor, starter ring gear	ATM	Fresh air flow to car interior
L7	Control rod travel sensor	OUT	Exhaust gas recirculation to exhaust gas recirculating valve or recirculating air valve
N39	EDS control unit		






Engine 602.962, Model Year 1990

1	Injection pump	N39	EDS control unit
2	Governor	S66	Switch, engine overload protection
60	Exhaust gas recirculating valve	Y22	ELR actuator
61a	Restriction	Y30	Switch-over valve, engine overload protection
61b	Restriction	Y31/1	Vacuum transducer, exhaust gas recirculating valve
61d	Connector (without restriction)	Y31/2	Vacuum transducer, pressure control flap
62	Filter	Y31/3	Vacuum transducer, charge pressure control
62a	Filter	a	Fresh air flow to car interior
65	Vacuum control valve	c	Other ancillaries
67	Vacuum pump	A	Intake air
72	Damper	B	Exhaust air
99	Pressure control flap in mixture housing		
100	Vacuum unit, pressure control flap		
103	ALDA unit		Pressure and vacuum connections at vacuum transducer or vacuum amplifier
110	Exhaust manifold		
123	Vacuum amplifier	PRE	Charge pressure from ALDA unit
137	Exhaust gas turbocharger	TRA	To vacuum unit of automatic transmission
137a	Vacuum unit, charge pressure control valve	VAC	Vacuum from vacuum pump
138	Charge air distribution pipe	v c v	To vacuum control valve
179	Vacuum reservoir	ATM	Fresh air flow to car interior
B2/1	Air flow sensor potentiometer with intake air temperature sensor, EDS	OUT	Output from vacuum transducer Y31/1 to EGR valve
B2/1a	Intake air temperature sensor	OUT	Output from vacuum transducer Y31/2 to vacuum unit of pressure control flap
B5/1	EDS pressure sensor	OUT	Output from vacuum transducer Y31/3 to vacuum unit of charge pressure control valve
B11/4	EDS coolant temperature sensor		
L3	Engine speed sensor, starter ring gear		
L7	Control rod travel sensor		

## V. Engine overload protection



A pressure switch is fitted in the charge air pipe for overload protection of mechanical parts in the engine. If the charge pressure rises above  $1.1 \pm 0.15$  bar gauge pressure, air is admitted to the ALDA unit through the switchover valve and the quantity of fuel is limited to that of a naturally aspirated engine.

- A Full load quantity without charge pressure  
( $P = 1050$  mbar)
- B Full load quantity with charge pressure




### Location of components

- 1 Injection pump
- 2 Governor
- 3 Fuel pump
- 6 Stop unit
- 103 ALDA unit
- Y22 Actuator



Y30 Switchover valve, engine overload protection

S66 Switch, engine  
overload protection




## W. Handling electronic control units after accident repair

It is necessary to change electronic control units after an accident if at least one of the following conditions is met:

1. The housing is recognizably deformed or damaged.
2. The supporting surface or console is deformed; the outside of the unit exhibits no damage.
3. The plug connector is damaged or corroded by moisture.
4. The functional check or the self-test of the equipment indicates faults.

When electrical components, e.g. ELR control unit, have been removed for repair work and then used again, these are to be checked in accordance with the existing documents after assembly.

07. 1400 Testing, **adjusting idle speed - Turbodiesel**



P07-0518-57

Tester (001) and pulse generator (021) .....	connect and disconnect.
Accelerator control .....	examine for ease of operation.
Idle stop on Bowden cable .....	check, the spring plate (226) must be resting against the compression spring (227) free of tension.
Engine .....	raise to coolant temperature of approx. 80°C.
2-pin connector on actuator (Y22) .....	detach, fit on again.
Idle speed .....	check, adjust. Loosen locking nut (3a) for this step.
Engine running .....	check. Turn on all ancillary components for this step.

### Test and adjustment data


Engine	Electronic idle speed control		Position of resistance trimming plug
	Idle speed rpm <b>with control</b>	Idle speed rpm Plug on actuator detached <b>without control</b>	
602.96	680 ± 20	620 ± 40	4
603.96/97	630 ± 20	570 ± 40	4

### Adjusting idle speed by means of resistance trimming plug

If problems arise regarding idle speed, it is possible to vary idle speed. The positions of the resistance trimming plug are listed in the table opposite.

Position of resistance trimming plug	Engine 602	Engine 603
1	610 ± 20	570 ± 20
2	630 ± 20	590 ± 20
3	650 ± 20	610 ± 20
4	---	680 ± 20
5	700 ± 20	650 ± 20
6	720 ± 20	670 ± 20
7	740 ± 20	700 ± 20

### Special tool




### Commercial tools

Multimeter	e.g.	Sun, DMM-5
Digital tester	e.g.	Bosch, MOT 002.01 Sun, DIT 9000

## Setting


- 1 Connect the digital tester (001) and the pulse generator (021).
- 2 Examine accelerator control for ease of movement and condition.




### Checking idle stop:

For this step, the spring plate (226) of the Bowden cable (230) must be resting against the compression spring (227), free of tension.

Engine 602.96




Engine 603.96



Set Bowden cable (230) with the adjusting nut (232) from the car interior, if necessary.

3 Raise engine to coolant temperature of approx 80 °C.


4 Detach 2-pin connector at actuator.



5 Set idle speed. Loosen locking nut (arrow) for this step.


Specifications:

Engine	Idle speed in rpm <b>with control</b>	Idle speed in rpm <b>without control</b> Plug on actuator detached
602. 96	680 ± 20	620 ± 40
603. 96197	630 ± 20	570 ± 40



6 Turn on all ancilliary components and check for smooth engine running.

## 07. 1- 105 Testing electronic Idle speed control with test connector (X92 and XI 1/4) - Turbodiesel



Digital tester (001) and pulse generator (021) . . . . .	connect.
Pulse counter (013) . . . . .	connect to battery (G1) and to test connector (X92).
Accelerator control . . . . .	check for ease of movement.
idle stop at Bowden cable (230) . . . . .	check, the spring plate (226) must be resting against the compression spring (227) free of tension.
Fuse of over-voltage protection . . . . .	check.
Engine . . . . .	raise to coolant temperature of approx. 80°C.
Engine . . . . .	run at idle speed.
Start button of pulse counter (013) . . . . .	operate for 2 to 4 seconds
Display . . . . .	read and note.
Start button . . . . .	press again, no new display appears if no further fault in system.



Number of pulses indicates whether and which component is faulty, or whether components in the control circuit are defective.

**Assignment (X92)**

- Jack 1            ground
- Jack 2            TD signal
  
- Jack 4            pulse output, EDS control unit  
                      (N39)

Pulse readout	Component/faulty circuit
1	all functions "in order"
2	engine speed signal "fault"
3	coolant temperature "fault"
6	ELR control loop "fault"

Only short-circuit faults are detected with control units designation "R01". Control units with designation "R02" also detect interrupts. Production breakdate: control unit with "R02", May 1988.



P07-0531-13



P07-0532-13

**Pulse readout "2"**

Engine speed sensor (L3) to connector (L3x) . . . test, resistance 0.4–2.5kΩ  
engine idle voltage > 4 V ~.

**Pulse readout "3"**

Coolant temperature sensor (B1 1 /1) . . . . . test, specified value + 20 °C 2.2-2.8 kΩ

### Pulse readout "6"

2-pin connector of ELW actuator (Y22) detach




(for at least 3 s) and fit on again. . . . . Engine speed increases briefly.

Test idle speed, adjust if necessary.

### Test and adjustment values

Engine	Idle speed in rpm <b>with control</b>	Idle speed in rpm <b>without control</b> Plug on actuator detached
602. 96	680 ± 20	620 ± 40
603. 96197	630 ± 20	570 ± 40

### Special tools




### Commercial tools

Multimeter	e.g. Sun, DMM-5
Digital tester	e.g. Bosch, MOT 002.02 Sun, DIT 9000

### Connection diagram

Connect digital tester and pulse generator.

Connect pulse counter (013) to battery (G1) and test connector (XI 1/4).




### Note

**The** U-batt LED in display panel must light up;  
if not:

- Test fuse of pulse counter
- Test jack 1 of test connector (XI 1/4) to battery positive (approx. 12 V)
- Test jack 4 of test connector (XI 1/4) to battery positive (approx. 12 V).

Check accelerator control for ease of movement.  
Check idle stop at Bowden cable (230).

The spring plate (226) of the Bowden cable (230) must be resting against the compression spring (227) free of tension in the idle position.



Test fuse in the over-voltage protection.

Raise engine to coolant temperature of approx.  
80°C.

Run engine at idle speed.

Operate start button of pulse counter (013) for  
between 2 and 4 seconds.

Check readout on the display of the pulse  
counter (013) and note.

Again press start button for between 2 and 4  
seconds. If there is no other fault in the system,  
no new readout appears.

Rectify noted faults according to test routine or  
perform test of components.



**Note regarding pulse readout**

Numbers from 1 to 6 appear on the display panel  
of the pulse counter.




The number 1 means that no fault has been  
detected in the electronic system. All the other  
numbers are assigned to a certain fault circuit.


## Testing components

### Testing over-voltage protection (K1/1)



## Pulse readout "2"








**Pulse read out "3"**

**Testing coolant temperature sensor (B11/1)**  
 Engine off. Detach plug on temperature sensor and test resistance to ground. Refer to diagram for specified values. Measure resistance at two temperature measuring points.

Example:  
 + 20 °C = 2.2-2.8 kΩ  
 + 80 °C = 290-370 Ω

Yes	No
-----	----



Test voltage at I-pin connector (arrow).  
 "Ignition" on.


Readout: approx. 5 Volts

Yes	No
-----	----

Rectify cable interrupt.  
Replace control unit (N8).




↓

End of test






## Pulse readout "6"



Engine at idle. Detach 2-pin connector (arrow) from ELR actuator (Y22). Connect multimeter and press button "V =".

Readout: approx. 12 V




Yes                      No

Check cables according to wiring diagram. Test fuse of over-voltage protection relay (K1/1).

If the cables are in order, replace control unit (N8 or N8/1).

End of test

Engine at idle. Detach 2-pin connector (arrow) at the ELW actuators (Y22).




Test idle speed:  
Specification:

M602	690 ± 40 rpm	manual transmission
	620 ± 40 rpm	automatic transmission
M603	570 ± 40 rpm	

Yes                      No


Loosen locking nut and adjust idle speed (arrow).

To the left = higher  
To the right = lower



End of test

## 07.1-110 Testing, tuning engine - Turbodiesel



P07-0038-59





Test sheet .....	Complete, enter measured values.
Coolant level .....	check, correct.
Engine oil level .....	check; pay attention to oil level (visual inspection).
Oil level in automatic transmission .....	check, correct.
Air filter .....	remove and install.
Tester (001, 013, 017) .....	connect.
Pulse generator (021) .....	connect.

Accelerator control linkage	check ease of movement, condition. Lubricate bearing points, relay levers, ball sockets.
Full throttle stop	check from accelerator pedal; adjust Bowden cable if necessary.
Idle stop	check. Min. specified value 11.5 Volts.
Engine	raise to coolant temperature of approx. 80°C.
Air conditioning or automatic climate control	turn off.
Idle speed	check, adjust if necessary. Detach plug from actuator.
Start of delivery	check. RI specified value 15° ATDC
Max. speed at no-load	check. Specified value: 5150 ± 150 rpm
Timing device	check. Specified value: at 5100 rpm approx. + 3° to + 5° using governor pulse method (RIV).
Electronic diesel system (EDS)	check, with pulse counter (013) (07.1-190).

**Test and adjustment data**

Engine	Idle speed in rpm with control	Idle speed in rpm without control Plug at actuator disconnected	Start of delivery with digital tester RI specification	Maximum speed at no-load or end of cutoff in rpm	Timing device at no-load or end of cutoff RIV method in degrees
602. 96	680 ± 20	620 ± 40	14 ± 0.5° ATDC	5150 ± 150	+ 3° to + 5°
603.96/97	630 ± 20	570 ± 40	15 ± 1° ATDC		

## Special tools



## Commercial testers

### Used without adapter

Digital testers

e.g. Bosch, ETD 019.02 or MOT 350/500/501  
Sun, DIT 9100  
AVL, Diesel-Tester 873


### Used with adapter

Digital testers

e.g. Bosch, MOT 001.03

Lambda tester  
(with EDS only)

e.g. Bosch, KDJE-P 600  
Hermann, L 115




P07-0452-57

Connection diagram for existing testers with adapter

001	Digital tester	017	RI generator
010	Adapter	021	TDC pulse generator
011	Trigger clamp	2	Governor
015	Test cable with connector	2i	RI generator pin
016	Diagnostic socket	59	TDC generator pin


## Testing, tuning

- 1 Complete test sheet. Enter test values.
- 2 Check coolant level, correct.
- 3 Check engine oil level, paying attention to condition of oil. Visual inspection.
- 4 Check oil level and automatic transmission.
- 5 Connect tester (013, 001, 017) according to connection diagram.
- 6 Connect pulse generator (021).
- 7 Remove and install air filter element.
- 8 Check accelerator control for ease of movement and condition. Lubricate bearing points, relay levers, ball sockets.
- 9 Check full throttle stop from accelerator pedal; adjust at adjusting screw (229) if necessary.




Engine 602. 96

P30-2089-13




Engine 603.96

10 Check idle stop.  
The spring plate (226) of the Bowden cable (230) must be contacting the compression spring (227).




Engine 602.96



Engine 603.96

Set Bowden cable (230) with adjusting nut (232) from the car interior, if necessary.






11 Test voltage at the battery.  
Specification: at least 11.5 V.

12 Raise engine to coolant temperature of approx. 80° C.

13 Turn off air-conditioning or automatic climate control.

14 Test idle speed.  
Detach to 2-pin connector on actuator. Set idle speed. Loosen locking nut (arrow) for this step.



Engine	Idle speed in rpm <b>with control</b>	Idle speed in rpm <b>without control</b> Plug on actuator disconnected
602.96	680 ± 20	620 ± 40
603.96197	630 ± 20	<b>570 ± 40</b>


Read off start of delivery  
RI specification 15 ± 1 ° ATDC.

15 Test “maximum speed” at no-load.  
Specification: 5150 rpm ± 150

16 Test timing device at no-load.  
Specification: at approx. 5100 rpm  
+ 3 to + 5° using RIV method.

17 Test electronic diesel system.  
(07.1-190).

07.1-1 11 **Testing start of delivery (position sensor RIV method) - Turbodiesel**






- |  |  |
|--|--|
| Screw plug (arrow) on governor housing (2) . . . . . | unscrew, tightening torque 30 - 35 Nm.   |
| Position sensor (007) . . . . .                      | install.   |
| Battery terminal (009) . . . . .                     | connect to B +.  |
| Crankshaft, crank by hand until . . . . .            | lamps "A" and "B" on indicating instrument (008) light up simultaneously; take reading on scale. Adjust the start of delivery if necessary (07.14 16) RI value (indirect start of delivery). |

## Test and adjustment data

Engine	Start of delivery (governor pulse) test value, ° ATDC
602.96	$15 \pm 1$
603.96	$15 \pm 1$
602.962 From 09/89	$14 \pm 0.5$ <sup>1)</sup>
603.970 From 09/89	$14 \pm 0.5$ <sup>1)</sup>

<sup>1)</sup> Adjust once 15,000 mi; adjustment value 14.5° ATDC

## Special tools




## Test


- 1 Remove plug (11).

### Caution!

Collect leaking oil.




- 2 Install position sensor into governor housing, ensuring that the guide pin of the position sensor (arrow) is facing upwards. Tighten union nut by hand.




3 Connect position sensor as shown in connection diagram.

- 007 Position sensor
- 008 Indicating instrument
- 009 Battery terminal (battery positive)
- 2 Governor
- 2i Flyweight (RI generator pin)



4 Use special tool to turn crankshaft by hand (in direction of rotation only) until lamp "B" lights up. Turn on carefully until **both** lamps "A + B" light up. In this position take reading of RI value (indirect start of delivery) on the scale.

If only lamp "A" lights up, repeat the test.




5 Remove position sensor.

6 Install plug.  
Tightening torque 30-35 Nm.

7 Perform leak tightness inspection with engine running.

8 Check oil level, correct if necessary.

**07.1-I 12 Testing start of delivery - digital tester (RIV method) - Turbodiesel**



P07-0519-59

- |  |   |
|--|---|
| Screw plug (arrow) on governor housing (2) . . . . . | unscrew, tightening torque 30 - 35 Nm.  |
| Tester (001, 017, 021) . . . . .                     | connect.  |
| Engine, run at idle . . . . .                        | read off RI value, adjust start of delivery if necessary (07.14 16 or 07.1-I 17). |

### Test and adjustment values

Engine	Start of delivery (governor pulse) test value, °ATDC
602. 96	$15 \pm 1$
603. 96	$15 \pm 1$
602. 962 From 09/89	$14 \pm 0.5$ <sup>1)</sup>
603. 970 From 09/89	$14 \pm 0.5$ <sup>1)</sup>

<sup>1)</sup> Adjustment once at 15, 000 mi; adjustment value 14. 5" ATDC


### Conventional tools

#### Used without adapter

Digital testers	e.g. Bosch, ETD 019.002 Sun, DIT 9100 AVL, Diesel-Tester 873
-----------------	--

#### Used with adapter

Digital testers	e.g. Bosch, MOT 001.03
-----------------	------------------------






P07-0452-57


### Connection diagram for existing testers with adapter

001	Digital tester	017	RI generator
010	Adapter	021	TDC pulse generator
011	Trigger clamp	2	Governor
015	Test cable with connector	2i	RI generator pin
016	Diagnostic socket	59	TDC generator pin


### Special tools




- 1 Unscrew plug (11) on the governor housing.



- 2 Thread in RI generator (017, arrow) at governor (injection pump).



- 3 Screw in TDC pulse generator (021) at bracket (engine).





- 
- 4 Connect the digital tester as shown in the connection diagram.
  - 5 With engine at idle, take reading of RI value (indirect start of delivery) at the digital tester at idle speed and compare with specification.
  - 6 Turn off engine.
  - 7 Disconnect digital tester.
  - 8 Screw in plug at governor. Tightening torque 30-35 Nm.
  - 9 Perform leakage test with engine running.
  - 10 Check engine oil level, correct if necessary.

## 07.1-1 13 Establishing fuel consumption by road test - Turbodiesel

---

- 1 Fill up vehicle tank in the presence of the customer with the vehicle on level ground.
- 2 Drive approx. 100 km (62 mi.), of this approx. 40 km (25 mi.) highway and approx. 60 km (37 mi.) back roads and city traffic.
- 3 After driving fill up again and calculate fuel consumption.

### Example 1:

Fuel consumption in liters/100 km


$$= \frac{\text{Fuel quantity consumed in liters}}{\text{Kilometers driven}} \times 100$$

### Example 2:

Fuel consumption in miles/gallon

$$\frac{\text{Miles driven}}{\text{Fuel quantity consumed in gallons}}$$

## 07.1-I 16 Setting start of delivery (position sensor RIV method) following test - Turbodiesel



P07-0520-55

Crankshaft .....	crank in direction of rotation to 15° ATDC of No. 1 cylinder.
Fastening bolts (13 and 13a) on injection pump flange and on supporting bracket .....	loosen, tightening torque 20 - 25 Nm.
Indicating instrument (008) and terminal (009) ...	connect.
Injection pump .....	swivel by turning adjusting screw at start of delivery adjusting device (8) Both lamps "A" and "B" in indicating instrument (008) must light up.
	<b>Direction of rotation of adjusting device (8) or screw</b>
	to right = start of delivery retarded
	to left = start of delivery advanced
	RI specification 15° ATDC.
Position sensor (007) .....	remove.
Screw plug (arrow) .....	screw in.
Accelerator control linkage .....	check, adjust if necessary (30 - 300).
Leakage test .....	perform with engine running.

Engine oil level .....	check, correct.
Leakage check .....	perform with engine running.
Engine oil level .....	check, correct.


**Note**

Check start of delivery before performing setting work (07. 1411) .



**Setting**

---

1 Turn crankshaft in direction of rotation to 15° ATDC of No. 1 cylinder.



2 Loosen fastening bolts (arrows) on the injection pump flange and on supporting bracket.



Bolton supporting bracket (arrow)

3 Connect indicating instrument (008) and terminal (009) to battery positive.

4 Swivel injection pump by turning the adjusting screw on the start of delivery adjusting device until both lamps light up.


**Direction of rotation of adjusting screw**

to right = start of delivery retarded  
to left = start of delivery advanced

RIV specification:  $15^{\circ} \pm 1^{\circ}$  ATDC

**Note**

If the adjustment facility is not adequate, the injection pump must be moved over. Remove, install injection pump (07. 1-200).



5 Tighten fastening bolts on injection pump flange and on supporting bracket. Tightening torque 20-25 Nm.

6 Remove position sensor.


7 Screw in plug. Tightening torque 30-35 Nm.

8 Check accelerator control linkage, adjust if necessary (30-300).

9 Perform leakage test with engine running.

10 Check engine oil level, correct if necessary.

## 07.1-117 Setting start of delivery with digital tester (RIV Method) following testing - Turbodiesel



P07-0517-57

Fastening bolts (13 and 13a) on injection pump flange and on supporting bracket .....	loosen.
Engine .....	run at idle speed.
RI value (indirect start of delivery) .....	set by turning adjusting device (8).
	<b>Direction of rotation of adjusting device (8) or screw</b>
	to right = start of delivery retarded
	to left = start of delivery advanced
	RI specification $15^{\circ} \pm 1^{\circ}$ ATDC
Engine .....	turn off.
Fastening bolts (13 and 13a) on injection pump flange and on supporting bracket .....	tighten, tightening torque 20-25 Nm.

Tester (001) . . . . .	disconnect.
Screw plug (arrow) on governor . . . . .	screw in, tightening torque 30-35 Nm.
Accelerator control linkage . . . . .	check, adjust if necessary (30-300).
Leakage check . . . . .	perform with engine running.
Engine oil level . . . . .	check.



**Note**

Check start of delivery before performing setting work (07.1-I 12).

**Setting**

---

- 1 Loosen fastening bolts (arrows) on the injection pump flange and on supporting bracket.




Bol t on supporting bracket(arrow)

- 2 Run engine at idle.
- 3 Set RIV value (indirect start of delivery) by turning the adjusting screw on the start of delivery adjusting device.

**Direction of rotation of adjusting screw**

- to right = start of delivery retarded  
to left = start of delivery advanced

RIV specification:  $15^{\circ} \pm 1^{\circ}$  ATDC




**Note**

If the adjustment facility is not adequate, the injection pump must be moved over. Remove, install injection pump (07.1-200).

- 4 Turn off engine.
- 5 Disconnect tester.
- 6 Screw in plug on governor, tightening torque 30-35 Nm.
- 7 Tighten fastening bolts on injection pump flange and on supporting bracket. Tightening torque 20-25 Nm.
- 8 Check accelerator control linkage, adjust if necessary (30-300).
- 9 Perform leakage test with engine running.
- 10 Check engine oil level, correct if necessary.



## 07.1-145 Testing fuel pump - Turbodiesel



Testers (001, 021) .....

Return line (81) .....

Glow start switch .....

connect.

disconnect and hold in measuring vessel (approx. 1 l).

### Note

The return line to the fuel tank must be sealed. move into position "0", the injection pump is in the zero delivery position.





Contact handle (040) ..... connect to terminal 30 and terminal 50 and start engine for 30 seconds. Use stop watch (041). Specification: delivery at least 150 cm<sup>3</sup>/30 seconds at 150 rpm. Replace fuel filter and/or delivery pump if necessary.

Fuel pressure ..... test (07.1-I 46).

**Test data**

Engine	602, 603
Delivery at least 150 rpm	At least 150 cm <sup>3</sup> /30 s
Test condition	Glow start switch in position "0"

**Special tools**




**Commercial tools**

Digital tester	e.g. Bosch, MOT 001.03
Graduated glass or beaker (at least 1 litre)	
Stop watch	


## Testing

1 Connect digital tester (001) as shown in connection diagram.




001 Digital tester  
021 TDC pulse generator

2 Disconnect return line (E) and hold in measuring vessel.




3 Turn glow start switch into position "0", the injection pump is in the "zero" delivery position.


4 Detach connector (X27) and plug adaptor cable to terminal 50.



Model 124



Model 201




Model 126

5 Connect contact handle to adaptor cable or terminal 50 (term. 50) and to terminal 30 (term. 30) and start engine for 30 seconds.  
**(Starting voltage at least 10 V)**



Delivery: at least 150 cm<sup>3</sup>/30 seconds.

If the specified value is not reached, test fuel pressure (07.1- 146).


## 07.1-146 Testing fuel pressure (after testing fuel delivery) - Turbodiesel



Fuel line "A" on filter top section (73) .....	remove, reinstall.
Tester (054) .....	disconnect, connect.
Run engine .....	specified values at idle speed > 0.3 bar at full-load > 0.5 bar. If the specified values are not reached, replace fuel filter.



## 07.1450 Testing vacuum engine stop for leaks - Turbodiesel



P07-0510-57

1	Injection pump	A	Intermediate panel
67	Vacuum pump	c	Other ancillaries
140	Check valve/main vacuum line	e	To brake booster

Key in steering lock . . . . .

turn to position "2".


Tester (019) 201 589 13 21 00 . . . . .

connect to "brown" suction line and pressurize with 400 + 50 mbar vacuum (maximum permissible vacuum drop 6 mbar/min.).


Tester (019) 201 589 13 21 00 .....

connect to vacuum unit (6) and pressurize with 300 + 50 mbar vacuum (maximum permissible vacuum drop 5 mbar/min.). If there is too much vacuum loss, determine cause and rectify.

**Special tool**



## 07.1-160 Testing vacuum pump - Turbodiesel



07-0515-57'

- |   |  |
|---|--|
| Main vacuum line (B) .....                  | disconnect at brake booster (A).   |
| Vacuum line at ancillaries connection ..... | detach, and use 0.8 mm gauge to check that restriction orifice is clear. |
| Vacuum tester (019) 201 589 13 21 00 .....  | connect to ancillaries connection and test vacuum at idle speed.         |


Specification: 700 mbar after 30 s.

If specified vacuum reading is not reached  
replace vacuum pump.



07. 170 **Testing and setting vacuum control valve for automatic transmission - Turbodiesel**

---



P07-0524-57

**Note**

Test conditions:

run engine up to normal operating temperature  
(approx. 80°C coolant temperature).

Accelerator control correctly set (30-300).

Vacuum tester (019) .....

connect to damper (72) of vacuum line and take reading of vacuum at idle speed.

Specification: Engine 602,  $420 \pm 25$  mbar  
Engine 603,  $385 \pm 25$  mbar


With engine off, move accelerator control to full-load stop.

Specification: 0 mbar, it may be necessary to set vacuum control valve. Test vacuum lines, test vacuum pump, replace vacuum control valve.

Fastening bolts (65c) .....


loosen, run at full throttle until control lever of injection pump is resting against full-load stop. Turn vacuum control valve (65) in direction of arrow until resistance is felt. Tighten vacuum control valve in this position.

A seal (arrow) is installed in the vacuum control valve to prevent dust and dirt getting into the valve.



P27-2255-13

### Special tool



201 589 13 21 00  
00 42 80

## 07.1-180 Testing control rod travel sensor- Turbodiesel (Model Year 1986/87 only)


**Problem:**

Poor performance and/or high fuel consumption.

**Test conditions:**

Engine coolant temperature > 80°C.

Air-conditioning system off.







- |                   |       |  |
|-------------------|-------|--|
| Contact box (004) | ..... | connect into circuit at EDS control unit (N39) as shown in connection diagram. |
| Multimeter (003)  | ..... | connect to jacks 3 and 11. Press button "V = ".                                |

Pressure, vacuum tester (019) .....	connect to ALDA unit (103) and pressurize with 1000 mbar gauge pressure. White pressure line detached.
Parking brake .....	apply. <b>Start</b> engine, depress service brake. Engage drive position "D", apply full throttle and take reading of voltage at 1500-2200 rpm and note. Specification: $3.27 \pm 0.08$ V, at $\leq 1600$ m above MSL. Pay attention to note 07.1-I 90.
Pressure, vacuum tester .....	disconnect and admit air to ALDA unit (103). Pressure line must not be connected. Stall engine as above. Take reading and note, compare with table.

**Note**

A measurement or hard brake application must not last longer than 5 seconds. A pause of at least 2 minutes should occur between two hard brake applications.

**Special tools**



**Commercial tester**

Multimeter

e.g. Sun, DMM-5

Compare voltage reading or corrected voltage of control rod travel sensor with table.

### Control rod travel sensor voltage

Engine speed	Pressure at ALDA	Height above MSL	Position of control lever at governor	Spec. voltage at control rod travel sensor evaluation circuit
rpm	mbar	m		$U_a$ corr. volts
1500–2200	1000 (gauge pressure)	≤ 1600	at full-load stop	$3.27 \pm 0.08$
1500–2200	Atmospheric pressure without tester, pressure line at ALDA disconnected	0	at full-load stop	$2.45 \pm 0.10$
		100		$2.43 \pm 0.10$
		200		$2.42 \pm 0.10$
		300		$2.40 \pm 0.10$
		400		$2.39 \pm 0.10$
		500		$2.37 \pm 0.10$
		600		$2.35 \pm 0.10$
		700		$2.34 \pm 0.10$
		800		$2.32 \pm 0.10$
		900		$2.31 \pm 0.10$
		1000		$2.29 \pm 0.12$
		1100		$2.28 \pm 0.12$
		1200		$2.26 \pm 0.12$
		1300		$2.25 \pm 0.12$
1400	$2.23 \pm 0.12$			
1500	$2.22 \pm 0.12$			
1600	$2.20 \pm 0.12$			

Measure reference voltage at jacks 23 (red) and 3 (black). If the reference voltage ( $U_{ref}$ ) is beyond  $5 \pm 0.1$  V, the two control rod travel sensor outlet voltages ( $U_{a, actual}$ ) measured previously, must be recalculated as follows:

$$U_{a, corr} = \frac{U_{a, actual} \times 5 \text{ V}}{U_{ref}}$$

If the control rod travel sensor voltages do not agree with the figures stated in the table above, the injection pump must be reset on an injection pump test stand.

## 07. 1- 190 Testing electronic diesel system(EDS)- Turbodiesel


---

- A. Engine 602.96 in Model 201 Federal Model Year 1987
- B. Engine 603.96 in Models 124 and 126 Federal and California Model Year 1986/87
- C. Engines 602.962 and 603.970, Model Year 1990


### Test conditions

- Coolant temperature approx. 80°C
- Air-conditioning: **OFF**
- Shift selector lever position P
- Fuse in over-voltage protection relay in order
- Battery voltage report 12 volt at over-voltage protection between jacks 1 and 5


## Special tools




1025890463001




201 589 00 99 00)



~ 1 5 8 9 1 3 2 1 0 0 )




124 589 00 21 00




603 589 00 21 00

**07**




124 589 33 63 00

**07 28 54**



124 589 19 21 00

**07 83**



903 589 01 63 00

## Commercial tools

Multimeter

e.g. Sun, DMM-5

Digital testers

e.g. Sun, EMT-I 01 **9**/Master 3  
Sun, DIT 9000  
All-Test, 361 O-MB  
Bosch, MOT 002.01

Y distributor


117078 01 45

Lambda control tester

e.g. Bosch KDJE-P600  
Hermann L 115

**Test cable  
shop-made**

Test cable (XI 1)



Pin assignment of test socket  
 Position 3 to jack 6  
 Position 4 to jack 2  
 Position 5 to jack 3  
 Position 6 to jack 3

**Scope of parts**


Position	Designation	Part no.	Quantity/dimension
1	Test socket	123 545 00 26	1
2	Jacks	001 545 28 26	3
-	Cable	Commercial	Length as per drawing
3	Terminal, red	Commercial	1
4	Terminal, black	Commercial	1
5	Connector	Commercial	Ø 4.8 mm
6	Connector	Commercial	Ø 4 mm



## A. Engine 602.96 in Model 201 Federal Model Year 1987

- a) Testing
- b) Testing components
- c) Testing electronic idle speed control

### a) Testing



Digital tester (001) and pulse counter (021) .....

connect, disconnect.

Lambda control tester (012) .....

connect to battery (G1) and test connector (X92).

Connect, disconnect, press 100% IR switch.

Contact box (004) .....	connect, disconnect with test cable (002) to EDS control unit (N39).
Vacuum tester (019) .....	connect, disconnect with Y distributor at EGR valve.
Digital tester (003) .....	connect, disconnect to contact box (004).
Fuse at over-voltage protection (K1/1) .....	test.
Selector lever .....	move into position "P".
Air-conditioning/automatic climate control .....	<b>off.</b>
Engine .....	bring to operating temperature (coolant temperature to <b>80° C</b> ).

**Note**

When performing the test work, the air intake hose between the air flow sensor and exhaust gas turbocharger must be fitted, otherwise no signal will pass from the air flow sensor to the EDS control unit (N39).

Connector "a" .....	hold approx. 1 second to battery ground 100% readout.
Connector "a" .....	remove. 0% readout, no fault in system. Readout fluctuates, fault in system (refer to troubleshooting table).

**Note**

One pulse = 0% - 100% - 0%.

The number of pulses indicates which electrical component is faulty.

Repeat test until there are no further pulses displayed.

### Trouble-shooting table




Fault readout	Component or circuit not operating
1	Engine speed sensor (L3)
2	Control rod travel sensor (L7)
3	Air flow sensor potentiometer (B2/1) electrical faults
4	Altitude sensor (B18)
5 <sup>1)</sup>	Exhaust control circuit, electrical and mechanical faults a. Exhaust gas recirculation valve EGR (60) b. Vacuum transducer (Y31/1) c. Air flow sensor (B2/1)
8	Coolant temperature sensor (B1 1/4)
9	Intake air temperature sensor in air flow sensor (B2/1a)
10	Reference resistor (R18/2) exhaust gas recirculation (EGR)
11	Resistance trimming plug (R18/1) idle speed control (ELR)


<sup>1)</sup> Hold engine speed above 1200 rpm for at least 5 seconds, otherwise no readout.

Double connector of ELR solenoid Y22 . . . . .	Disconnect and fit on again (at least 3 seconds). Engine speed increases briefly.
Engine . . . . .	Run engine at approx. 1200 rpm and approx. 250 mbar. Briefly apply full throttle. Vacuum drops to 0 mbar.
Engine . . . . .	off.
EGR valve . . . . .	Pressurize EGR valve with approx. 300 mbar vacuum. EGR valve audibly closes.





## b) 'Testing components

### Fault readout "1"









## Fault readout "2"






## Fault readout opening "3"



### Note




If airflow sensor removed, also perform "Testing air temperature sensor (B2/1a)" (Fault readout 9).

## Fault readout "4"





**Fault readout "5"**



A closed  
B open

**b) Testing vacuum transducer (Y31/1)**

Connect vacuum tester with Y distributor to vacuum transducer (Y31/1). Connect multimeter with test cable to transducer (Y31/1). Press button "A". Increase engine speed until approx. 250 mbar is reached.

**Note**

Ensure that connector of vacuum transducer (Y31/1) is correctly connected.

Refer to diagram for specified values.  
Example: 250 mbar = 400-500 mA



**Current at vacuum transducer**





0 mA                      too low                      too high



Check that vacuum vent (black) and filter are clear.

Check that supply line (blue) is clear.  
Check whether there is an interruption in vacuum line (white/purple/brown) between transducer and EGR valve. If vacuum line and vacuum are in order, replace vacuum transducer (Y31/1).




End of test










## Fault readout "8"






## Fault readout "9"



## Coolant temperature sensor and intake air

Temperature in °C	Resistance $\pm 10\%$	Voltage in V $\pm 100\%$
20	2.5 k $\Omega$	3.85
30	1.7 k $\Omega$	3.47
40	1.18 k $\Omega$	3.05
50	833 $\Omega$	2.63
60	600 $\Omega$	2.22
70	440 $\Omega$	1.85
80	327 $\Omega$	1.5
90	243 $\Omega$	1.22
100	185 $\Omega$	0.99




## Fault readout "10"



### Note

When replacing the resistance trimming plug (R18/2), fit only plug with an identical part no.

## Fault readout "11"







### Note




The resistance trimming plug ELR (R18/1) is installed in position "4".



### c) Testing electronic idle speed control

#### Testing idle speed control






### Setting idle speed by means of resistance trimming plug(R18/1)

If problems occur regarding idle, idle speed can be altered.

The positions of the resistance trimming plug are listed in the table below.


Position of resistance trimming plug	Idle speed in rpm
1	$610 \pm 20$
2	$630 \pm 20$
3	$650 \pm 20$
4	$680 \pm 20$
5	$700 \pm 10$
6	$720 \pm 20$
7	$740 \pm 20$



## C. Engines 602.962 and 603.970 Model Year 1990

- a) Testing
- b) Testing with pulse counter
- c) Trouble-shooting schedule
- d) Test program with contact box  
(Engine 602.962)
- e) ELR, EGR function test, P2 control
- f) Test program with contact box  
(Engine 603.970)
- g) ELR and EGW function test (Engine 603.970)

### a) Testing



Digital tester (001) and pulse counter (021) .....	disconnect, connect.
Pulse counter (013) .....	connect, disconnect to battery (G1) and with adaptor to test connector (X92 or XI 1/4).
Contact box (004) .....	connect, disconnect with test cable (002) to EDS control unit (N39).
Digital multimeter (003) .....	connect, disconnect at contact box (004).
Vacuum tester (019) .....	connect, disconnect with Y distributor at EGR valve.
Fuse at over-voltage protection (K1/1) .....	test.
Selector lever .....	move into position "P".
Air-conditioning/automatic climate control .....	switch off.
Engine .....	bring to operating temperature (coolant temperature approx. 80°C).
Start button of pulse counter (013) .....	operate for 2-4 seconds.
Display .....	read off and note.
Start button .....	press again. If no new display appears, there is no further fault in the system.

## Engine 602.962

The number of pulses indicate whether and which component is faulty and whether components in the control circuit are faulty.

Pulse readout	Component/controlloop
1 <sup>3)</sup>	All functions "in order"
2	Control rod travel sensor (L7)
3	Air flow sensor potentiometer (B2/1)
4	EDS control unit (N39) atmospheric pressure sensor
5 <sup>2)</sup>	Vacuum transducer (Y31/1) or fault in exhaust control loop
6	EDS control unit (N39) internal power supply
7	Engine speed sensor (L3)
8	Coolant temperature sensor (B1 1/4)
9	Intake air temperature sensor (B2/1a)
10	Not assigned
11 <sup>1)</sup>	ELR actuator or vacuum transducer (Y31/1)
12	Not assigned
13	EDS control unit (N39) defective (internal memory)
14	Pressure sensor (B5/1), EDS defective
15	Vacuum transducer, charge pressure control (Y31/2) pressure transducer pressure control flap (Y31/3) or faults in charge pressure control loop

1) Readout only in the case of short-circuit.

2) Readout only at 900 rpm for at least 5 seconds, fault is not stored.

3) In the event of complaints perform functional test on ELR, EGR, P2 control.

### Engine 603.970

The number of pulses indicates whether and which component is faulty and whether components in the control circuit are faulty.

Pulse readout	Component/control loop
1 <sup>3)</sup>	All functions "in order"
2	Control rod travel sensor (L7)
3	Air flow sensor potentiometer (B2/1)
4	EDS control unit (N39) altitude sensor
5 <sup>2)</sup>	Vacuum transducer (Y31 /1) or fault in exhaust control loop
6	EDS control unit (N39) Internal power supply
7	Engine speed sensor (L3)
8	Coolant temperature sensor (B11/4)
9	Intake air temperature sensor (B2/1a)
10	Power supply
11 <sup>1)</sup>	ELR actuator or vacuum transducer (Y31/1)
12	Not assigned
13	EDS control unit (N39) defective


<sup>1)</sup> Readout only in case of short-circuit.

<sup>2)</sup> Readout only at 900 rpm for at least 5 seconds, fault is not stored.

<sup>3)</sup> In the event of complaints, perform ELR and EGR function tests.

## b) Testing with pulse counter

### Connection diagram



### Notes regarding pulse readout

If a problem occurs but no fault is indicated on the pulse readout, perform the function test, section "7.4".

The number 1 indicates no fault detected in the electronic system. All other numbers are assigned to a particular fault group.

The numbers from 1 to 11 appear on the display panel of the pulse counter.

If the LED U-Batt appears after connecting, pulse counter and power supply for pulse counter are in order.

## Testing

---

1 Connect pulse counter as shown in the connection diagram.

### Note

**LED U-Batt** in display panel must light up; if not:

- a) test fuse of pulse counter.
- b) test jack 1 of test connector (XI 1/4) to battery positive (1 I-I 4 V).
- c) test jack 4 of test connector (XI 1/4) to jack 1 (6-12 V).

2 Engine at idle.

3 Operate start button for between 2 and 4 seconds.

4 Take readout of pulse output and note.

Display "1" = no fault

Greater than "1" = fault in system

5 Again press start button for between 2 and 4 seconds. If no further fault exists in system, the previous readout appears once again.

6 Repeat until the first fault is displayed again.

7 Rectify noted faults (pulse readout) according to trouble-shooting schedule.

8 Perform component test.

## Erasing fault memory

After a fault has been rectified, the pulse display must be erased as follows:

9 Operate start button and readout the rectified fault, then press start button for 6-8 seconds.

### Note

Each display pulse must be erased

**individually.**

The fault is eliminated and erased when the fault code no longer appears on the fault display.

Display of a number larger than 1, further faults in system.



### c) Trouble-shooting schedule

#### Engine 602.962

The number of pulses indicates whether and which component is faulty and whether components in the control circuit are faulty.

Pulse readout	Component/control loop
1 <sup>3)</sup>	All functions "in order"
2	Control rod travel sensor (L7)
3	Air flow sensor potentiometer (B2/1)
4	EDS control unit (N39) atmospheric pressure sensor
5 <sup>2)</sup>	Vacuum transducer (Y31/1) or faults in exhaust control loop
6	EDS control unit (N39) internal power supply
7	Engine speed sensor (L3)
8	Engine coolant sensor (B11/4)
9	Intake air temperature sensor (B2/1a)
10	Not assigned
11 <sup>1)</sup>	ELR actuator or vacuum transducer (Y31/1)
12	Not assigned
13	EDS control unit (N39) defective (internal memory)
14	Pressure sensor (B5/1), EDS defective
15	Vacuum transducer, charge pressure control (Y31/2). Vacuum transducer, pressure control flap (Y31/3) or fault in charge pressure control circuit

1) Readout only in the case of short-circuit.


2) Readout only at 900 rpm for at least 5 seconds, fault is not stored.

3) In the event of complaints perform functional test on ELR, EGR, P2 control.


### d) Test program with contact box (Engine 602.962)

#### Connection diagram contact box


- 002 25-pin test cable 124 589 33 63 00
- 003 Multimeter
- 004 35-pin contact box 124 589 00 21 00
- 005 Test cable 124 589 34 63 00
- N39 EDS control unit



#### Symbols for test instruments:



- Contact box
- Multimeter
- Jack
- Pin









- Voltage measurement (volt, direct voltage)
- Resistance measurement (ohm)

On/off ratio readout	Test step/ test scope	Test connection	Operation/ requirement	Specifi- cation	Possible cause/remedy
1	1.0	-	-	-	
2	2.0 Control rod travel sensor (L7)		Ignition: <b>OFF</b> EDS control unit disconnected	$50 \pm 4 \Omega$ $25 \pm 2 \Omega$ $\infty \Omega$ $\infty \Omega$	Replace control rod travel sensor or injection pump Cables






On/off ratio readout	Test step/ test scope	Test connection	Operation/ requirement	Specification	Possible cause/remedy
[2]	2.1 Control rod travel sensor (L7)		Ignition: <b>OFF</b> Connector on control rod travel sensor (L7) disconnected	$50 \pm 4 \Omega$	Replace control rod travel sensor or injection pump
				$25 \pm 2 \Omega$	
3	2.2 Cables		Ignition: <b>OFF</b> Connector on control rod travel sensor (L7) disconnected	$< 1 \Omega$	Cable interrupt
				$< 1 \Omega$	
				$< 1 \Omega$	
3	3.0 Air flow sensor potentiometer (B2/1)		Ignition: <b>ON</b> EDS control unit (N39) connected	$5 \pm 0.5 \text{ v}$	EDS control unit (N39)
				$< 0.5 \text{ v}$	
			Engine at idle	$1.7 \pm 0.2 \text{ v}^1)$	EDS control unit (N39)

<sup>1)</sup> Voltage rises as speed increases.

On/off ratio readout	Test step/ test scope	Test connection	Operation/ requirement	Specifi- cation	Possible cause/remedy
[3]	3.1 Air flow sensor potentio- meter (B2/1)	 3                      2 4	Ignition: OFF EDS control unit (N39) disconnected	500- 1200 Ω	Air flow sensor potentiometer (B2/1)
		 3                      1 0	Air flow sensor in off position	50- 200 Ω	Air flow sensor potentiometer (B2/1)
		 3                      1 0	Air flow sensor plate fully deflected	560- 1100 Ω	Air flow sensor potentiometer (B2/1)
4	3.2 Cables	 1 0                      B2/1 3	Connector on air flow sensor potentiometer (B2/1) disconnected	< 1 Ω	Cable interrupt
		 2 4                      B2/1 4		< 1 Ω	Cable interrupt
4	4.0	-	-	-	Replace EDS control unit (N39) (atmospheric pressure sensor)
5 <sup>2)</sup>	5.0 Vacuum transducer (Y31/1)  EGR valve	 18                      1  Vacuum at EGR valve	Engine 900 rpm ± 50  approx. 300 mbar <sup>4)</sup>	> 3 V <sup>4)</sup>	Supply line black/white leaking. Air admission line (black) blocked. Air admission filter (62a) dirty. Supply line black/white or vacuum line black (rubber) blocked or leaking. Vacuum transducer (Y31/1). Cables, EDS control unit, air flow sensor potentiometer, EGR valve

2) Readout only at 900 rpm for at least 5 seconds, fault is not stored.

4) Apply full throttle briefly, vacuum and voltage drops. The test values are reference values.

On/off ratio readout	Test step/ test scope	Test connection	Operation/ requirement	Specifi- cation	Possible cause/remedy
[5] <sup>2)</sup>	5.1 Cables	<b>N39</b> 	Ignition: <b>OFF</b> Connector on vacuum transducer (Y31/1) detached	<b>&lt; 1 Ω</b>	Cable interrupt
		<b>N39</b> 			
6	6.0	-		-	Internal power supply. Replace EDS control unit
7	7.0 Engine speed sensor (L3)		Engine at idle EDS control unit disconnected	<b>&gt; 3 V <sup>1)</sup></b>	Engine speed sensor, distance, dirt, cables
	7.1 TD signal		Engine at idle EDS control unit connected	<b>&gt; 3.5 V<sup>6)</sup></b>	Cable (N39) to (XI 1/4) Short circuit or EDS control unit
	7.2 Engine speed sensor (L3)	  L3x   - * - 2	Ignition: OFF EDS control unit disconnected  Plug connector (L3x) detached	Beru <sup>5)</sup> 527 Ω ± 10 % VDO <sup>5)</sup> 1900 Ω ± 10 %  Beru <sup>5)</sup> 527 Ω ± 10 % VDO <sup>5)</sup> 1900 Ω ± 10 %	Engine speed sensor (L3) Cables  Engine speed sensor (L3) ((M27))

1) Voltage rises as speed increases.

2) Readout only at 900 rpm for at least 5 seconds, fault is not stored.

5) Measured at 20°C ambient temperature (for each 10°C change in ambient temperature the resistance changes by 4%).

6) Voltage drops by approx. 0.5 V and stabilises.

On/off ratio readout	Test step/ test scope	Test connection	Operation/ requirement	Specifi- cation	Possible cause/remedy
[7]	7.3 Cables			< 1 Ω	Cable interrupt
a	a.0 Coolant temperature sensor (B11/4)		Ignition: ON EDS control unit connected	<sup>3)</sup>	Coolant temperature sensor, cables, EDS control unit
	8.1 Coolant temperature sensor (B11/4)		Ignition: OFF EDS control unit connected	<sup>3)</sup>	Coolant temperature sensor
	a.2 Cable		Ignition: OFF EDS control unit disconnected	< 1 Ω	Cable interrupt
	9.0 Intake air temperature sensor (B2/1a)		Ignition: ON EDS control unit connected	<sup>3)</sup>	Temperature sensor, intake air, air flow sensor, cables, EDS control unit

<sup>3)</sup> Refer to table of coolant temperature sensor and intake air.

On/off ratio readout	Test step/ test scope	Test connection	Operation/ requirement	Specifi- cation	Possible cause/remedy
[9]	9.1 Intake air temperature sensor (B2/1a)	<p>N39 3 ← Ω → 22</p> <p>B2/1 1 - * → 2</p>	Ignition: OFF EDS control unit disconnected	<sup>3)</sup>	Cable to intake air temperature sensor Temperature sensor
	9.2 Cables	<p>N39 2 2 ← Ω → B2/1 1</p> <p>N39 3 ← Ω → B2/1 2</p>	Ignition: <b>OFF</b> EDS control unit disconnected Connector on air flow sensor potentiometer (B2/1) detached	< 1 Ω  < 1 Ω	Cable interrupt  Cable interrupt
10	10.0 Power supply	<p>N39 1 4 ← V → 1</p>	Engine approx. 1500 rpm	11–14 V	Alternator regulator Lima Voltage > 18 V
11 <sup>1)</sup>	11.0 ELR actuator (Y22)	<p>N39 3 ← V → 2</p>	EDS control unit connected	11–14 V	Actuator (Y22) Cables
		<p>N39 2 ← V → 1</p>	Ignition: <b>ON</b> Engine at idle	2.5 ± <sup>2)</sup> 0.5 v	EDS control unit (N39)

1) Readout only in the case of short-circuit.







2) Reference value, voltage drops as speed increases.



3) Refer to table of coolant temperature sensor and intake air.

On/off ratio readout:	Test step/ test scope	Test connection	Operation/ requirement	Specifi- cation	Possible cause/remedy
[11] <sup>1)</sup>	11.1		Ignition: OFF EDS control unit disconnected	$4 \pm 1 \Omega$	Actuator (Y22) Cables
	11.2 Cables		Ignition: OFF Detach connector at actuator (Y22)	$< 1 \Omega$	Cable interrupt
				$< 1 \Omega$	Cable interrupt
13					Internal memory Replace EDS control unit (N39)
14	14.0 Pressure sensor (B5/1)		Ignition: ON EDS control unit connected	$> 5 \text{ v}$	Pressure sensor Pressure lines Electrical cables
	14.1 Pressure sensor (B5/1)		Engine at idle	$> 1.5 \text{ v}$ $0 \text{ mbar}$	Pressure sensor Pressure lines Electrical cables
		Pressure tester with Y distributor on pressure sensor	Apply full throttle briefly	Voltage rises, pressure rises $> 500 \text{ nbar}$	
	14.2 Pressure sensor (B5/1)		Ignition: OFF EDS control unit detached	$1.4 \pm 1.2 \text{ k}\Omega$	
	14.3 Cables			$< 1 \Omega$	Cable interrupt

<sup>1)</sup> Readout only in the case of short-circuit.



On/off ratio readout	Test step/ test scope	Test connection	Operation/ requirement	Specifi- cation	Possible cause/remedy
[14]	14.4 Cables	<b>N39</b> 	Ignition: OFF EDS control unit disconnected	< 1 Ω	Cable interrupt
	14.5 Cables	<b>N39</b> 	Ignition: OFF EDS control unit disconnected	< 1 Ω	Cable interrupt
15	15.0 Vacuum transducer (Y31/2)	<b>N39</b> 	Engine at idle EDS control unit connected	Approx. 0.4 v < 100 mbar	Vacuum transducer (Y31/2) Vacuum lines EDS control unit
	Vacuum unit, pressure control flap	Vacuum tester with Y distributor on vacuum transducer (Y31/2) Output (OUT)	Increase speed slowly to approx. 2000 rpm	Vacuum increases Voltage rises	
	15.1 Cables	<b>N39</b> 	Ignition: <b>OFF</b> EDS control unit disconnected Connector on (Y31/2) detached	< 1 Ω	Cable interrupt
	15.2 Cables	<b>N39</b> 	Connector on (Y31/2) detached	< 1 Ω	Cable interrupt
	15.3 Vacuum transducer (Y31/3)	<b>N39</b> 	Engine at idle EDS control unit connected	Approx. 4 v < 300 mbar	Vacuum transducer (Y31/3) Vacuum lines EDS control unit
	Vacuum unit, charge pressure control valve	Vacuum tester with Y distributor on vacuum transducer (Y31/3) Output (OUT)	Increase speed slowly to approx. 2000 rpm	Voltage drops Vacuum drops	Vacuum transducer (Y31/3) Vacuum lines EDS control unit

On/off ratio readout	Test step/ test scope	Test connection	Operation/ requirement	Specifi- cation	Possible cause/remedy
[15]	15.4 Cables	 	Ignition: <b>OFF</b> EDS control unit disconnected	< 1 Ω  < 1 Ω	Cable interrupt  Cable interrupt

#### Coolant temperature sensor and intake air

Temperature in °C	Resistance ( ± 10%)	Voltage in V ( ± 10%)
20	2.5 kΩ	3.85
30	1.7 kΩ	3.47
40	1.18 kΩ	3.05
50	833 Ω	2.63
60	600 Ω	2.22
70	440 Ω	1.85
80	327 Ω	1.5
90	243 Ω	1.22
100	1a5 Ω	0.99

## e) ELR, EGR function test, P2 control

### Note


This test is to be performed when in the event of complaint concerning the pulse readout, no fault is displayed.

### Engine 602.962 with P2 control

Test step/ test scope	Test connection/ test instrument	Operation/ requirement	Specifi- cation	Possible cause/ remedy
1.0 Idle speed control	Revolution counter with TDC generator	Engine at idle Coolant tempera- ture approx. 80°C	680 rpm ± 20	Actuator, injection pump, engine speed sensor, EDS control unit (N39), refer to test steps 7 and 11
		Plug detached from actuator	610 rpm ± 20	Set speed at injection pump. Injection pump
2.0 Exhaust control circuit	Connect vacuum tester with Y distributor to EGR valve	Engine running at 900 rpm ± 50 and approx 300 mbar. Briefly apply full throttle	Vacuum drops	Perform mechanical test on vacuum transducer (Y31 /1) and air flow sensor (B2/1). EDS control unit (N39) EGR valve
3.0 EGR valve	Connect vacuum tester directly to EGR valve.	Engine off Pressurize EGR valve with 300 mbar and disconnect again.	EGR valve audibly closes	Replace EGR valve.

Test step/ test scope	Test connection/ test equipment	Operation/ requirement	Specifi- cation	Possible cause/remedy
4.0 Charge pressure control  Vacuum unit Charge pressure control valve	Connect vacuum tester (020) with Y distributor to output (OUT) from vacuum transducer (Y31/3)	Engine at idle  Slowly increase speed to approx 2000 rpm	> 300 mbar  Vacuum reduces	Vacuum supply Vacuum line Vacuum transducer (Y31/3) EDS control unit (N39)
4.1 Vacuum unit Pressure control flap (100)	Connect vacuum tester (020) with Y distributor to vacuum unit pressure control flap (100)	Engine at idle  Slowly increase speed to approx. 2000 rpm	< 100 mbar  Vacuum increases	Vacuum supply Vacuum line  Vacuum transducer (Y31/2) Pressure line on pressure sensor (B5/1) EDS control unit

## 07.1-200 Removal and installation Of injection pump - Turbodiesel



P07-0808-87

Bottom section of noise encapsulation	remove, fit (94-0050).
Belt tensioning device	remove, install (13-340).
Fan cowl and fan	remove, install (20-335).
Vacuum pump (67)	remove, install (43-610). Replace gasket (67).
Assembly sleeve (067)	install, remove, so that engine can be turned over easily. Special tool 601 589 05 14 00 (engines effective 09/89).
Radiator	remove, install (20-470). Model 201.128 only.
Actuator of cruise control	Remove, install (54-541), Engine 603 only.

Central fastening bolt (19) with washer (20) .....	Unscrew, screw in, tightening torque 40-50 Nm.
	<b>Caution!</b>
	Left-hand thread
Crankshaft .....	in direction of rotation
	turn to <b>15°</b> ATDC of no. 1 cylinder.
Chain tensioner (156) .....	remove, install <b>(05-310)</b> .
	Special tool 001 589 65 09 00.
Injection lines (54-59) at injection pump .....	disconnect, connect.
	Tightening torque <b>10-20</b> Nm.
	Special tool 000 589 77 03 00.
Fuel lines (80, 82, 83) .....	disconnect, connect, replace seals.
	<b>Caution!</b>
	Do not mix up hollow bolt (27) and overflow orifice (15).
Fuel thermostat (86) and fuel line (89) .....	disconnect, connect.
Pressure lines at ALDA unit (103) and vacuum lines .....	disconnect, connect.
Electric cables .....	disconnect, connect at control rod travel sensor (L7) and at actuator (Y22).
Accelerator control linkage .....	detach, attach. Check setting (30-300).
Injection pump (1) .....	Remove bolt (13 and <b>13a</b> ), tightening torque 20-25 Nm. Withdraw injection pump to the rear; <b>hold timing device tight</b> when performing this step.
O-ring (10) .....	replace.
Start of delivery adjusting device(8) .....	remove, install; remove bolt (8a) for this step.
Spring (25) .....	detach, reattach.

Screw plug (11) ..... remove and turn removed injection pump with serrated wrench (027) until lug is visible in the governor housing hole. In this position, push in locking bolt (023) until it is felt to engage.







**Caution!**

Remove locking bolt (023) after installing injection pump and refit screw plug (11).

Start of delivery ..... check (07.1-I 12), set if necessary.

Vacuum control valve (65) ..... remove, install, set (07.1-I 70).

**Special tools**




## Removal and installation

1 Loosen central fastening bolt (19), unbolt while holding crankshaft tight.


### Caution!

Left-hand thread


Mount assembly basket using bolts (67b), so that the engine can be cranked easily (on engines effective 09189).



2 Turn crankshaft in direction of rotation to 15° ATDC of no.1 cylinder.



3 Remove chain tensioner (05310).




156 Wrench socket  
Special tool 001 589 65 09 00



4 Detach injection and fuel lines at the injection pump.

Arrow      Box wrench socket  
Special tool 000 589 77 03 00  
with 1/4" ratchet



5 Disconnect vacuum lines at vacuum unit for stop unit and vacuum control valve. Detach 2-pin connector at actuator (Y22) of electronic idle speed control.


6 Disconnect electric cables at control rod travel sensor (L7) and at actuator (Y22).

7 Disconnect pressure line at ALDA unit.


8 Detach accelerator control linkage at control lever and spring.

9 Remove vacuum control valve.

10 Remove injection pump; remove fastening bolts (arrows) and bolt on mounting bracket for this step. Withdraw injection pump to the rear, holding timing device in place.



11 Remove fuel thermostat (86) complete; remove bolts (arrows) for this step.




A Inlet from fuel tank


12 Check whether the engine is positioned at 15° ATDC of no. 1 cylinder; adjust if necessary.

**Caution !**


Engine must only be cranked in direction of rotation!



13 Unscrew plug (11).




14 Use serrated wrench (027) to turn injection pump on the injection pump crankshaft until the lug of the governor is visible at the hole, i.e. push in locking bolt (023) in this position until it is felt to engage, and tighten by hand.



027 Serrated wrench  
Special tool 601 589 00 08 00

**Caution!**

Remove locking bolt (023) after installing injection pump, otherwise the injection pump will be damaged when starting the engine.



023 Locking bolt  
Special tool 601 589 05 21 00

P07-0451-17

15 Install remaining parts on engine.

**Note**


When starting engine, the injection system is automatically bled.

16 Check start of delivery (07. I-I 12); set start injection if necessary (07. I-I 17).

17 install vacuum control valve and set (07. I-I 70).

## 07.1-210 Replacing delivery valve seal - Turbodiesel


---



P07-0442-15

Delivery valve holder (7) .....	tightening torque 35 Nm, Special tool 617 589 01 09 00.
Compression spring (7i) copper seal (7f) .....	replace
Delivery valve (7k) .....	rinse in fuel before installing.
Delivery valve carrier (7g) .....	Make note of installed position.
O-ring (7h) .....	oil before assembling.


### Special tool



617 589 01 09 00

## 07.1-220 Replacing vacuum unit - Turbodiesel


Preceding work:  
Charge air pipe removed (14- 180) .




Screw (6b) .....	remove, install (use TORX-T30).
Bracket (6c) .....	remove, install.
Stop unit (6) .....	raise slightly when removing, tilt back towards engine and withdraw.
O-ring (6a) .....	remove, install.
Emergency stop lever (25) .....	press when installing and engage connecting rod of vacuum unit into the rocker of the emergency stop lever.

## 07.1-225 Replacing actuator of electronic idle speed control (ELR) - TurboDiesel

---



Screw	(6b)	.....	remove, install, (use TORX T30).
Bracket	(6c)	.....	remove, install.
Actuator (Y22) with intermediate plate (160)		....	remove, install, electrical connection must be facing upwards.
O-ring	(161)	.....	replace.
Shim	(167)	.....	for setting size "a".




Size "a" 14.6-15.7 mm

P07-0467-37


## 07.1430 Removal and Installation of injectors - Turbodiesel

---



Bypass oil hose (50), plug (52) .....	remove, refit.
Injection line (54) .....	remove, install, tightening torque 10–20 Nm as reference value.
Injection nozzle (30) .....	remove, install, tightening torque 70-80 Nm, Special tool 001 589 65 09 00.
Nozzle seal (53) .....	replace.


### Special tool





## 07.1-231 Testing injectors - Turbodiesel


Preceding work:  
Removal and installation of injectors (07-230)



Injection nozzle (30) .....	pump 5 times vigorously on tester (052) 000 589 00 68 00; close valve "a" for the step.
Chatter .....	test; slowly operate hand lever "b" approx. 1 stroke per second for this step.
Jet .....	test. With short, rapid strokes, approx. 2 strokes per second, the jet must be closed and be properly formed. A - Stringy jet "poor" B - Closed jet "good"
Ejection pressure or opening pressure .....	test. Open valve "a" for this step and operate hand lever "b" slowly (at least 1 stroke per second). Specification: 135-145 bar for new nozzles min. 120 bar for used nozzles,

## 07.1-232 Reconditioning injectors (after testing) - Turbodiesel

Preceding work:  
 Removal and installation of injectors (07.1-230)  
 Testing Injectors (07.1-231)



Injection nozzles . . . . .	disassemble( 1).
Nozzle needle (31) . . . . .	remove, install, visual and sliding inspection; clean center and longitudinal bore of hole pintle nozzles; install in the same nozzle body.
Nozzle body (32) .. . . .	remove combustion residues.
Intermediate disc (33) . . . . .	dress on surface plate.
Pressure pin (34) . . . . .	remove, install, point must be facing toward top section.
Nozzle tensioning nut (35) . . . . .	unscrew, reinstall, tightening torque 70-80 Nm.
Compression spring (36) . . . . .	remove, insert.
Holder (37) . . . . .	to strip down and assemble the injection nozzles, clamp in protective jaws of vice.

Steel washer (40) .....




set for ejection pressure.

Specification:

135-145 bar for new or newly set nozzle, at least 120 bar for used nozzle. Ejection pressure higher or lower depending on thickness of washer.


0.05 mm results in approx. 3 bar pressure difference.

### Special tools




### Reconditioning


1 Disassemble injection nozzle by clamping body in vice with protective jaws so that the leak oil line connections are not damaged.



2 Clean nozzle needle and nozzle body with a brass wire brush.



Remove combustion residues on seat of nozzle needle with a scraper.




3 Visual and sliding inspection.

Dip nozzle in filtered diesel fuel. With the nozzle body held upright, the nozzle pintle must slide towards the nozzle seat by its own weight.


4 Dress intermediate disc (33) on a surface plate.

5 Assemble nozzle holder with injection nozzle. Ejection pressure is set with the steel washer (40). Ejection pressure is higher or lower depending on thickness of the washer; 0.05 mm results in approx. 3 bar pressure difference.

6 Test injection nozzles (07.1-231). Set if necessary.



## 07.1-235 Removal and installation of fuel pump - Turbodiesel




Clip (84) .....	open, close.
Suction line (89) .....	detach, fit on.
Fuel filter inlet (82) .....	disconnect and connect.
Nuts (3c) .....	remove, install.
Washers (3b) .....	remove, install.
Fuel pump (3) .....	remove, install, collect engine oil flowing out during removal.
Gasket (3a) .....	replace.
Inlet connector (23) .....	remove, install when replacing the fuel pump.



## 07.1-240 Removal and Installation of Injection timing device- Turbodiesel

Vacuum pump removed (43-610)



P07-0528-55

Cylinder head cover . . . . .	remove, install.
Engine or crankshaft . . . . .	position on 15° ATDC.
Camshaft gear (154) and timing device (18) . . . . .	fix in position to timing chain with hose strap.
Chain tensioner (156) . . . . .	remove, install (05-310). Tightening torque 80 Nm.
Bolt (153) for camshaft gear . . . . .	unbolt, reinstall. Tightening torque 45 Nm. Note washer (152).
Camshaft gear (154) . . . . .	remove, install.
Central fastening bolt (19) . . . . .	unbolt, reinstall, tightening torque 40-50 Nm.







**Caution!**

Left-hand thread

Check washer (20), replace if necessary.

Locking pin (151) .....	withdraw with threaded pin (116 589 01 34 00) and impact puller (116 589 20 33 00).
Mounting basket (18a) .....	remove, install.
Timing chain (155) .....	press to the outside with metal strips (approx. 0.5 x 70 x 120) and withdraw timing device (18) with universal pliers.
Timing device (18) .....	remove, install.
Screw plug with seal (11) .....	remove from injection pump (1).
Injection pump .....	turn with serrated wrench (027) and lock in position with locking bolt (023).
Engine or crankshaft .....	<b>Caution!</b> Remove locking bolt. crank 1 revolution by hand and check TDC setting on crankshaft and camshaft.
Start of delivery .....	check (07.1-I 12), set if necessary (07.1-I 17).

**Special tools**







## Removal and Installation

---

- 1 Remove cylinder head cover.
- 2 Turn engine to 15° ATDC of no.1 cylinder.




- 3 Fix camshaft gear and timing device in place with cable strap.



Camshaft gear


- 4 Remove chain tensioner (156) to relieve the load on the timing chain (05-310).



- 5 Remove bolt for camshaft gear on camshaft; hold crankshaft in place when performing this step.

Tightening torque 45 Nm.

Remove camshaft timing gear.



6 Remove central fastening bolt (19); hold crankshaft in place when performing this step.


**Caution!**

Left-hand thread

7 Withdraw locking pin (arrow) and remove mounting basket.


Impact extractor  
M6 threaded pin

Special tool 116 589 20 33 00  
Special tool 116 589 01 34 00




8 Press timing chain out of the way with metal strips and use universal pliers to withdraw timing device.

Shop-made metal strips  
Thickness approx. 0.5 mm  
Length approx. 140 mm  
Width approx. 070 mm




9 Unscrew plug (11).



10 Use serrated wrench (027) to turn injection pump on injection pump camshaft until the lug of the governor is visible in the hole. In this position, push in locking bolt (023) until it is felt to engage and tighten union nut by hand.

027 Serrated wrench  
Special tool 601 589 00 08 00



11 Install timing device. Tighten central fastening bolt to 40–50 Nm.

**Caution!**


Left-hand thread

12 Remove locking bolt (023) otherwise the injection pump will be damaged when engine is started.

13 Assemble engine.

14 Test start of delivery with digital tester (07.1-I 12), set if necessary (07.1-I 17).


023 Locking bolt  
Special tool 601 589 05 21 00



## 07.1-241 Reconditioning injection timing device- Turbodiesel

Preceding work:


Removal and installation of timing device (07.1-240)



Bolt (18h) . . . . .	..a.....	M6 x 16, remove and install. Tightening torque 15 Nm.
Drive hub (18l) . . . . .		remove, install.
Bolt (18c) . . . . .		M8 x 16, remove and install. Tightening torque 25 Nm.
Cam (18g) . . . . .		examine for signs of wear.
Sprocket wheel (18f) . . . . .		examine for signs of wear.
Bush (18e) . . . . .		remove, install, examine for signs of wear.
Segment flange (18e) . . . . .		examine for signs of wear.
Compression spring (18k) . . . . .		remove, install.
Flyweight (18d) . . . . .		M8 x 16, remove, install, examine for signs of wear.

## 07.1-245 Replacing fuel filter • Turbodiesel

---




Bolt (74)	.....	remove, install.
O-ring (76)	.....	replace.
O-ring (77)	.....	replace.
Filter (42)	.....	withdraw downwards, replace.
Fuel filter top section (73)	.....	check that restriction orifice 0.8 mm (on return line) is clear.
Leakage	.....	check (with engine running).

### Note

When the engine is started, the fuel system is bled automatically as a result of the high output of the fuel pump and the restriction orifices in the top section of the filter as well as at the injection pump.

## 07.1-250 Retrofitting damper with restriction orifice - Turbodiesel

---



### Engine 603.96

A damper with restriction orifice can be retrofitted to prevent cruise control surging on hills at engine speeds between 2000 and 3000 rpm.

## Parts listing


Figure Item	Quantity	Designation	Part No.
1	1	Y distributor	601 078 02 45
2	2	Reducer	117 078 03 81
3	4	Rubber hose approx. 40 mm long	117 997 09 82
4	12	Hose clip 0.8 mm	916 002 008 100
61c	1	Restriction 0.3 mm (red)	000 078 03 56
6	1	Tecalan tube (white) approx. 400 mm long	000 158 1435
Y30/1	1	3/2 solenoid switch-over valve	001 540 86 97
7	1	Bend	117 078 05 81
8	1	Connector	116 276 09 29 *
	2	Bushes	003 545 26 26
	2	Hose clips 11 mm	916 033 01.1 100
9	1	2-pin connector, switch-over valve	011 545 71 28
9/1	1 *	Accumulator	000 078 19 68
	1	Hose strap	002 997 09 90
10	1	Tecalan tube approx. 600 mm long white	000 158 14 35
	1	Cable 0.75 approx. 200 mm long	commercial
	1	Cable 0.75 approx. 900 mm long	commercial
	1	Cable 0.75 approx. 900 mm long	commercial

**Scope of work**

1 Install solenoid switchover valve (Y30/1).


a) Model 126

Install solenoid switchover valve (Y30/1) on the intermediate panel next to the switchover valve (Y29).




b) Model 124

On Model 124, the switchover valve (Y29) must be moved to the right.



2 Fit out delivery lines as shown in the illustration opposite.






3 install delivery lines with accumulator (9/1).


a) Model 126

Attach delivery lines with accumulator (9/1) on Model 126 to fuel line bracket with hose strap.




b) Model 124

Attach accumulator (9/1) to bracket of preglow cable harness with hose strap.




4 Make electric cable harness as shown in the drawing below.



Solder on electric cables as shown in wiring diagram: short cable to contact 2 brown/red of switchover valve (Y30). Long cable to contact 1 brown/red of microswitch (S27/1).


Plug 2-pin connector onto switchover valve.



### Wiring diagram

**Y30** Solenoid **switch-over** valve, engine overload protection  
**Y30/1** Solenoid switchover valve  
**S25/6** 50°C temperature switch  
**S27/1** Microswitch  
**S66** Switch, engine overload protection (1.2 bar)


**Y29** Vacuum amplifier switchover valve, (diesel with automatic transmission).  
**a** to control unit (N6) contact 5  
**b** to control unit (N6) contact 4



Vacuum line routing (California Engine 603.96, Models 124 and 126)

1	Injection pump	a	Fresh air flow to car interior
2	Governor	b	Key operated engine stop
6	Vacuum unit	c	Other ancillaries
60	Exhaust gas recirculation valve	d	Vacuum unit, automatic transmission
61a	Restriction blue	e	Brake booster
61b	Restriction orange		Pressure and vacuum connections at vacuum transducer or vacuum amplifier
61c	Restriction	PRE	Charge pressure from ALDA unit
61d	Restriction	TRA	To vacuum unit, automatic transmission
62	Filter	VAC	Vacuum from vacuum pump
62a	Filter	v c v	To vacuum control valve
62c	Air admission filter	ATM	Fresh air supply to car interior
65	Vacuum control valve	ARF	Exhaust gas recirculation to exhaust gas recirculation valve or air recirculation valve
67	Vacuum pump		
72	Damper		
103	ALDA unit		
123	Vacuum amplifier		
137	Exhaust gas turbocharger		
137b	Recirculation air valve		
136	Charge air distribution pipe		
140	Check valve, brake booster		
Y22	ELR actuator		
Y29	Switch-over valve, vacuum amplifier for automatic transmission		
Y30	Swttchover valve, engine overload protection		
Y31	Vacuum transducer, air recirculation valve		
Y31/1	Vacuum transducer (EGR)		

# 07.1-400 Wiring Diagrams - Turbodiesel




Wiring diagram electronic diesel system Engine 602.961 Federal Model 201 Model Year 1987

A9	Refrigerant compressor	X18/1	Plug connection, <b>tail</b> lamp wiring harness/compressor wiring harness
<b>A9k1</b>	Electromagnetic clutch		
<b>A9/1</b>	RPM sensor	X48	Sleeve terminal (solder connector)
<b>B2/1</b>	Air flow sensor potentiometer	X62	Plug connection, speed sensor, starter ring gear
<b>B11/4</b>	Coolant temperature sensor, idle speed control	X92	Test connection for <b>diagnostics (8-pin)</b>
B18	Altitude sensor	Y3	<b>Kickdown</b> valve <b>automatic transmission</b>
<b>K1/1</b>	Relay, overvoltage protection	Y22	Actuator (ELR)
L3	Engine speed sensor, starter ring gear	<b>Y31/1</b>	Vacuum transducer, exhaust gas recirculation
L7	Control rod travel sensor	a	To terminal block X35, <b>terminal 30/61</b> (battery)
N6	Control unit, compressor shutoff	b	To <b>electrical</b> centre connector U contact 5
N39	Control unit (EDS)	c	To relay, double auxiliary fan ( <b>K8/1</b> ) contact 5
<b>R18/1</b>	Resistance trimming plug (ELR)	d	To electrical centre connector W contact 4
<b>R18/2</b>	Reference resistor (EGR)	e	To relay, double auxiliary fan ( <b>K8/1</b> ) contact 4
<b>S25/5</b>	Temperature switch <b>105/1 15°C</b>		To tachometer (AI p7)
<b>S27</b>	A/C compressor/charge pressure cut-out microswitch	g	To switch, engine overload protection ( <b>S66</b> )
<b>S30/1</b>	<b>Kickdown</b> switch		
<b>S31</b>	Pressure switch, refrigerant compressor		
<b>W10</b>	Battery ground		

**Note**


Ground points not shown go to engine ground or battery ground.



P07-0490-55

Wiring diagram engine overload protection Engine 602.961 Federal Model 201.128 effective Model Year 1987

S25/5	Temperature switch 105/115°C	a	To relay K9 auxiliary fan contact 4
S25/6	Temperature switch 50°C	b	To relay K9 auxiliary fan contact 5
S27	A/C compressor/charge pressure cut-out microswitch	c	To control unit N6 compressor cutoff contact 4
S66	Switch, engine overload protection	d	W 10 battery ground
Y29	Switchover valve, vacuum amplifier	e	To control unit N6 compressor cutoff contact 12
Y30	Switchover valve, engine overload protection		




Wiring diagram electronic diesel control Engine 602.962, Model Year 1990 and 1991

A9	Refrigerant compressor	S30/1	Kick-down switch
A9k1	Electromagnetic clutch	S31/1	Pressure switch, refrigerant compressor, OFF 2.0/30/ON 2.6/22
A9l1	Engine speed sensor	S66	Switch, engine overload protection
A9x1	Plug connection, refrigerant compressor	W10	Battery ground
B2/1	Air flow sensor potentiometer with intake air temperature sensor (EDS)	X4/1	Cable connector, terminal 30/interior, 2-pin
B5/1	Pressure sensor (EDS)	X4/10	Cable connector, terminal 30/terminal 61 battery
B11/4	Coolant temperature sensor (EDS)	X11/4	Test connection for diagnostics, 8-pin (pulse readout)
F1	Fuse and relay box	X26	Plug connection, interior/engine
G1	Battery	X81/1	Plug connection, engine cable harness/Tempomat/1-pin
K1/1	Relay over-voltage protection 87E/87L (7-pin)	Y3	Kick-down valve, automatic transmission
K12/1	Relay, Tempomat/charge pressure cutoff	Y22	Actuator (ELR)
L3	Engine speed sensor, starter ring gear	Y30	Switchover valve, engine overload protection
L3x1	Plug connection, engine speed sensor, starter ring gear	Y31/1	Vacuum transducer (EGR)
L7	Control rod travel sensor	Y31/2	Vacuum transducer, pressure control flap
N6	Control unit, refrigerant compressor cutoff	Y31/3	Vacuum transducer, charge pressure control
N39	Control unit (EDS)	Z6/2	Sleeve connector (solder connection on clutch housing)
S2/2	Glow start switch	Z7	Sleeve connector, terminal 87 (solder connection in cable harness)
S27	A/C compressor/charge pressure cut-out microswitch	a	K9 relay, additional contact 4, terminal 15



## 07.1-500 Vacuum Circuit Diagrams- Turbodiesel



Vacuum Line Routing Electronic Diesel System Engine 602.961 Federal Model 201  
Model Year 1987

1	Injection pump	Y31/1	Vacuum transducer, exhaust gas recirculation valve
2	Governor	a	Ventilation to passenger compartment
6	Vacuum unit stop	b	Key shut-off
9	Vacuum reservoir	c	Other ancillaries
60	Exhaust gas recirculation valve	d	Vacuum unit, automatic transmission
61a	Restriction	e	Brake booster
61b	Restriction		
62	Filter		
62a	Filter		
65	Vacuum control valve		Pressure and vacuum connections to vacuum transducer or vacuum amplifier
67	Vacuum pump	PRE	Charge pressure from ALDA unit
72	Damper	TRA	To vacuum unit, automatic transmission
103	ALDA unit	VAC	Vacuum from vacuum pump
123	Vacuum amplifier	v c v	To vacuum control valve
137	Exhaust gas turbocharger	ATM	Ventilation to passenger compartment
138	Charge air distribution pipe	OUT	Exhaust gas recirculation to exhaust gas recirculation valve
140	Non-return valve - brake booster	sw	black
Y22	ELR actuator	bl	blue
Y29	Vacuum amplifier switch-over valve, automatic transmission	br	brown
Y30	Switch-over valve, engine overload protection	gr	grey
		vl	violet
		rt	red
		ws	white

