
A. Models 107, 116

Lubricants

Centering sleeve, per sleeve approx. 6 grams	refer to specifications for service products page 266.2	
Clamp connection		
Tightening torques		Nm
Self-locking hex. nuts for	M 10	45
fastening companion plates	M 12	65
Hex screws to propeller shaft intermediate bearing		25
Clamping nut to propeller shaft		30–40
Hex screws for attaching tunnel closing plate to frame floor	M 8	25
	M 10	45
Hex bolts for attaching engine mount to tunnel closing	plate	25
Special tools		
Torque wrench 25–130 Nm with plug-in ratchet 1/2" square	11004-10064	001 589 66 21 00
Open-end element 46 mm for plugging into torque wrench	11004-9074	126 589 00 01 00




- 1 Front propeller shaft2 Rear propeller shaft


- 3 Clamping nut7 Propeller shaft intermediate bearing
- 10 Centering sleeve 12 Companion plate

Removal


- 1 Remove exhaust system.
- 2 Unscrew shielding plate.



- 3 Lift transmission and jack up.
- 4 Loosen clamping nut of propeller shaft for about 2 turns without pushing back rubber sleeve (slides along).




5 On model 107, unscrew hex bolts on tunnel closing plate (19) as well as the two screws (20) of the rear engine mount and remove tunnel closing plate (19).




Model 107

6 On model 116, unscrew hex bolts of rear engine carrier on frame floor as well as those for rear engine mount and remove.




Model 116

7 Unflange propeller shaft on transmission and on rear axle.




- 8 Unscrew hex bolts for attaching propeller shaft intermediate bearing to frame floor.
- 9 Disconnect compensating lever of parking brake.



10 Force propeller shaft from centering pin of rear axle drive pinion and pull out toward the rear. Make sure that the propeller shaft is not separated.


Attention!

If the propeller shaft must be separated, mark all parts in relation to each other since the propeller shaft is balanced as a unit. On model 107.042 starting August 1982 the front and rear propeller shaft are pertinently identified.



11 On models 107.022/042 starting September 1982 with radially or tangentially soft companion plates, the vulcanized centering bushings on companion plate must be loosened prior to sliding propeller shaft out of universal flange (arrows). For this purpose, use a cylindrical mandrel of 10 mm dia. and approx. 150 mm in length.

Note: Check companion plates, centering sleeves and propeller shaft intermediate bearing for damage, if any. Replace damaged parts.




Installation


- 12 Fill cavities of the two centering sleeves with the specified grease (approx. 6 grams per sleeve).
- 13 Slide propeller shaft with companion plates on centering pins on transmission and on rear axle.
- 14 Attach propeller shaft intermediate bearing to frame floor, but do not yet tighten.
- 15 Attach propeller shaft to transmission into rear axle. Tightening torque of self-locking hex nuts (14) for M 10 = 45 Nm and for M 12 = 65 Nm.


Attention!


Renew self-locking hex. nuts on principle.

- Front propeller shaft 10
- Centering sleeve Hex screw
- Companion plate Washer
- Self-locking hex. nut
- Transmission three-arm flange
- 16 Mount tunnel closing plate or rear engine carrier to frame floor, tightening torque of hex screws for M 8 = 25 Nm and for M 10 = 45 Nm.












18 Tighten clamping nut on propeller shaft to 30–40 Nm, making sure of seating sleeve well.



19 Tighten hex bolts for attaching propeller shaft intermediate bearing to frame floor to 25 Nm.



20 Attach compensating arm of parking brake.



- 21 Mount shielding plate.
- 22 Install exhaust system.

