
## a) Testing check valve

- 1 Pull distributor (a) from check valve (32).
- 2 Connect vacuum line of tester (refer to arrow), evacuate and read gauge.
- 3 If gauge shows a pressure increase, replace check valve.




32 Check valve a Distributor


## b) Testing vacuum reservoir

4 Pull vacuum line (e), color code grey/light blue, out of distributor (a).

a Distributor
e Vacuum line
Color code grey/light blue
(suction line to vacuum reservoir)




- 5 Connect vacuum line of tester (refer to arrow) to vacuum line (e) and evacuate.
- 6 If readout on gauge changes, replace gasket of vacuum reservoir (33) or replace vacuum reservoir (vacuum tank).



33 Vacuum reservoir e Vacuum line

## c) Testing temperature switch

7 Pull vacuum line, color code black, from temperature switch (35), connect tester (d) and check temperature switch for passage. Temperature switch (35) should have passage at coolant temperature above 40 °C (104 °F).




Layout of temperature switch in regulating valve

- 4 Regulating valve
- 22 Heating water pump 35 Temperature switch 35 Temperature switch (water valve) 45 Holder

- 46 Clamp
- 47 Hose clamp 48 Electric plug 53 Screw

183 -16593



- 4 Regulating valve
- b Blind plug
  c Vacuum plug with vacuum lines
  d Tester
- 8 Disconnect tester and reinstall vacuum line.

## d) Testing vent lines

- 9 Unsrew sheet metal screw (arrow) on vacuum plug (c) for regulating valve (4) and pull off plug.

- Regulating valve
   Vacuum plug with vacuum connection 1 to 9 and v
- 10 Connect tester to vacuum connection (v), color code black, of vacuum plug (c). Check line (39) for passage (also refer to 83-626/2).
- 11 Connect tester to vacuum connection (9), color code white, of vacuum plug (c). Check line (36) for passage (also refer to 83-626/2).



4 Regulating valve c Vacuum plug with vacuum connection 1 to 9 and v

