

WORK DESCRIPTION FOR FIELD MEASURE

Check front axle stabilizer; replace if necessary

Check/test procedure

1. Perform test drive on uneven road at approx. 10 km/h (6mph) with steering movements to the left and right.

i Check whether creaking noises come from area of the front axle stabilizer.

- a. Noises **present**: Carry out **work procedure**.
- b. Noises **not** present: **End measure**.

Work procedure

1. Replace front axle stabilizer.

i For basic data, see AR32.35-P-2200EQS.

Parts

Quantity	Designation	Part no.
As required (1)	Tubular torsion bar with bushing, front	A 296 323 16 00
As required (4)	Hexalobular bolt, torsion bar to integral carrier; M10X35	N 000000 006979

i Small parts such as screws/bolts, lock nuts, sealing rings, cable ties, fluids, sealants, etc. are not listed in the parts list. The required small parts are taken into account in the budgeting.

Operation text and flat rate

Operation no.	Operation text	Flat rate	Accounting no./ damage code
02-0138	Check front axle stabilizer	Time prescribed by foreperson	32 920 21
02-0139	Replace front axle stabilizer (after check) Includes: Remove/install lower engine cover	1.0 h	32 920 21
