



**Version 1 (except model 116.036 and 123)**

- 1 Switch  
 SP = Resume  
 V = Decel  
 A = Off  
 B = Accel
- 2 Control univ
- 3 Sensor
- 4 Actuator
- 5 Stop lamp switch
- 6 Stop lamp
- a Terminal 15



**Version 1 (model 116.036 up to chassis end No. 000 689)**

- 1 Switch  
 SP = Resume  
 V = Decel  
 A = Off  
 B = Accel
- 2 Control univ
- 3 Sensor
- 4 Actuator
- 5 Stop lamp switch
- 6 Stop lamp
- a Terminal 15
- b Fuse 4 in main fuse box



**Version 2 all models (model 123 with automatic transmission from start of production)**

- 1 Switch  
 SP = Resume  
 V = Decel  
 A = Off  
 B = Accel
- 2 Control univ
- 3 Sensor
- 4 Actuator
- 5 Stop lamp switch
- 6 Stop lamp
- a Terminal 15

