Removal

- 1 Unscrew both screws on bottom of cover.
- 2 Pull out cover in downward direction.

Installation

3 For installation proceed vice versa.

Note: When inserting cover, slide holding springs under clips on instrument panel.