

Removing Glovebox Cover

Unscrew both hinge screws.

Unscrew both stop screws.

Note: Remove screw in range of center console with offset screw driver.

Removing Trimstrip for Glovebox Cover

Unscrew trimstrip screws.

Remove trimstrip with lock.

Removal of Lock for Glovebox Cover

Remove trimstrip with lock.

Unscrew lock from trimstrip.