
Removal


1 Unscrew knurled nuts (2). Remove lamp carrier (1) and pull off coupling for electric connections.



2 Unscrew fastening nuts (1). Remove housing in inward direction, light window with gasket in outward direction.

Installation

3 For installation proceed vice versa.



Cable layout of couplings

Left	Right
1 vacant 2 brown 3 black/white 4 gray/yellow 5 black/red 6 gray/black 7 vacant 8 gray/green	gray/violet brown black/gree gray/yellov black/red gray/black vacant

