## Preparation for test


1 Remove glove box (68-140).


## Connecting tester

- 2 Connect vacuum connection line (4) to black vacuum line (37) while removing blind seal.
- 3 Connect the two 10-point plugs (1) of tester to plug connection (5).
- 4 Connect connection (3) of tester to vehicle ground (seat rail).

Layout 10-point plug connection for tester

- 5 Plug connection for tester 37 Vacuum connection for tester





Volt or ohmmeter needle
Connection (vehicle ground)
Vacuum connection line

- 5 Voltmeter switch
- 6 Mode switch 7 Vacuum measuring instru-
- 8 Voltmeter
- ment

