
## Model 124 with 4MATIC

## Oil grades

ATF	Refer to MBNA Factory Approved Service Products list
Torque specifications	Nm
Oil filler and drain plug	50

## Special tools



## Commercial tools

14 mm hex. driver insert, 1/2" square drive

obtain locally

Note: When checking fluid level, the vehicle should be level.

Remove filler plug.

Note: If more than approx. 50 cc of fluid flows out of filler hole, the multi-disc clutches AV or ZS are leaking. Check oil level in hydraulic oil reservoir in engine compartment.

Repair or replace transfer case.

The fluid level is correct, if a small amount of fluid flows out or if fluid level extends up to lower edge of opening.

If not, add fluid.

Install filler plug and torque to 50 Nm.

