
All models

- Switch radio on.
- Clean antenna mast with cleaning pad.
- Switch radio off.
- Repeat procedure several times.



Wipe mast dry with a clean rag.

