



Check Regularly and Before a Long Trip



1448



1539

- 1 Fuel Supply:** Turn fuel filler cap to the left and hold on to it until possible pressure in tank has been released, then remove the cap.
- 2 Tire Inflation Pressure:** Check at least every two weeks. For details see page 79.
- 3 Fluid Level in Automatic Transmission:** See page 75.
- 4 Coolant Level:** See page 73.
- 5 Windshield Washer System:** See page 101.
- 6 Engine Oil Level:** See page 74.
- 7 Brake Fluid:** See pages 101 and 102.

Battery: Add distilled or tap water only, see page 84.

Vehicle Lighting: Check function and cleanliness. For replacement of light bulbs, see pages 80, 81 and 82.