

WORK DESCRIPTION FOR FIELD MEASURE

Code: 21P5891109

Version: 2.1

Update Digital Operator's Manual and supply printed operator's manual, replace if necessary

Model 118 with code 801

i The codes correspond to:

- 801 - MODIFICATION YEAR 2020/1.
- 549 - CONNECT 20 HIGH (NTG6).
- 548 - CONNECT 20 MID (NTG6).
- 547 - CONNECT 20 ENTRY (NTG6).
- 545 - CONNECT 5 (NTG6).
- 859 - CENTRAL DISPLAY SIZE M.
- M260 - FOUR-CYLINDER INLINE SPARK-IGNITION ENGINE M260.
- M016 - UPRATED ENGINE.
- M139 - FOUR-CYLINDER INLINE SPARK-IGNITION ENGINE M139 - AMG.
- ME08 - HYBRID DRIVE 75KW-84KW (90KW-V213) VAR. (PLUG-IN).
- 2XXL - FEDERAL REPUBLIC OF GERMANY.

Model: C118 with code 801

Work procedure A:

Update Digital Operator's Manual with parts scope

Page 2/3

Work procedure B:

Supply printed operator's manual as an aftermarket measure, replace if necessary, with parts scope

Page 3/3

Operation text and flat rate

Page 3/3

Model: C118 with code 801**Work procedure A**

i Update Digital Operator's Manual.

- i**
- Ensure use of **XENTRY Diagnosis version** BD/DVD (**09/2020**) or higher.
 - Before starting the work procedure, install the **current version of all add-ons** in **XENTRY Diagnosis**.
 - Make sure to follow the operation steps exactly as described in XENTRY Diagnosis.
 - Use a battery charger to ensure sufficient power supply of the vehicle **on-board electrical system battery** (greater than 12.5 V).
 - If XENTRY Diagnosis is already connected to the vehicle, start with **operation step 2**.
- i** If two or more software updates or SCN codings are performed during one workshop visit, operation items 02-4762 and 02-5058 may be invoiced only **once for each workshop order**.

1. Connect XENTRY Diagnosis.

2. Update COMAND Online control unit software.

i To do this, select menu item "Quick test view – COMAND Online – Adaptations – Commissioning of control unit – Commissioning of the already installed control unit".

i Then follow the user guidance in XENTRY Diagnosis.

3. Disconnect XENTRY Diagnosis.

4. Carry out **work procedure B**.

Parts scope – Digital Operator's Manual

Quantity	Designation	Part no.
1	Digital Operator's Manual	*

* **The Digital Operator's Manuals relating to the vehicle identification number and equipment variant must be procured via the parts job in the Xentry Portal.**

Work procedure B

i Supply printed operator's manual as an aftermarket measure, replace if necessary.

1. Check whether the printed operator's manual is in the vehicle document wallet and whether it is the correct version, supply if necessary.

i If a printed operator's manual is **not present**, the printed operator's manual must be placed in the vehicle document wallet as an aftermarket measure.

i If there is a printed operator's manual, compare it with the parts table and replace if necessary.

Parts scope – Printed operator's manual

Quantity	Part no.	Designation	Language	Code
As required (1)*	A 118 584 94 03	OPERATOR'S MANUAL A-HIGH US-ENL USA CAN A-2021	English USA	801+549+12B
As required (1)*	A 118 584 84 03	OPERATOR'S MANUAL A-MID A-ENTRY US-ENGL USA CAN A-2021	English USA	801+(547/548)+12B
As required (1)*	A 118 584 16 04	ACCORDION-FOLD DOCUMENT BRIEF INSTRUCTIONS US-ENGL USA CAN A-2021	English USA	801+12B
As required (1)*	A 118 584 29 04	AMG SUPPLEMENT US-ENGL USA CAN A-2021	English USA	801+(M260+M016/M139)+12B

* The operating instructions must be procured via the parts job in the Xentry Portal.

Operation text and flat rate

Operation no.	Operation text	Flat rate	Accounting no./ damage code
02-9445	Update Digital Operator's Manual (with XENTRY Diagnosis connected)	0.1 h	58 911 09
02-9471*	Check operator's manual, supply if necessary	0.1 h	58 911 09
02-4762**	Connect/disconnect diagnostic system (XENTRY Diagnosis)	0.1 h	58 911 09
02-5058**	Connect/disconnect starter battery charger (with XENTRY Diagnosis connected)	0.1 h	58 911 09

* The operation item includes checking 3 operator's manuals, supply if necessary. Thus, the operation item is to be used in the corresponding frequency depending on the vehicle equipment. For 1 to 3 operator's manuals, the operation item is to be used once. For 4 to 6 operator's manuals, the operation item is to be used twice. For 7 to 9 operator's manuals, the operation item is to be used three times.

** Operation item may be invoiced only once for each workshop order.