

WORK DESCRIPTION FOR FIELD MEASURE

Code: 21P5498706

Version: 2.0

Update Mercedes-Benz Intelligent Drive control unit software

Model 205

- i** • Ensure use of **XENTRY Diagnosis version** BD/DVD (**12/2020**) or higher.
- Before starting the work procedure, install all the **add-ons that are updated daily** in **XENTRY Diagnosis**.
- Make sure to follow the operation steps exactly as described in XENTRY Diagnosis.
- Use a battery charger to ensure sufficient power supply of the vehicle **on-board electrical system battery** (greater than 12.5 V).
- If XENTRY Diagnosis is already connected to the vehicle, start with **operation step 2**.
 - i** If two or more software updates or SCN codings are performed during one workshop visit, operation items 02-4762 and 02-5058 may be invoiced only **once for each workshop order**.

Work procedure

1. Connect XENTRY Diagnosis.
2. Update **N62/4 – Mercedes-Benz Intelligent Drive** control unit software.
 - i** To do this, select menu item "Quick test view" – Control units – N62/4 – Mercedes-Benz Intelligent Drive – Control units – Adaptations – Control unit update – Update of control unit software".
 - i** Then follow the user guidance in XENTRY DIAGNOSIS/DAS.
3. Disconnect XENTRY Diagnosis.

Operation text and flat rate

Operation no.	Operation text	Flat rate	Accounting no.
02-9334	Update N62/4 Mercedes-Benz Intelligent Drive control unit software (with XENTRY Diagnosis connected)	0.1 h	54 987 06
02-4762*	Connect/disconnect diagnostic system (XENTRY Diagnosis)	0.1 h	54 987 06
02-5058*	Connect/disconnect starter battery charger (with XENTRY Diagnosis connected)	0.1 h	54 987 06

* Invoice operation item only once for each workshop order.

Mercedes-Benz
Global Service & Parts