

WORK DESCRIPTION FOR FIELD MEASURE

Code: 21P5492212

Version: 2.0

Perform SCN coding in the active suspension and damping system control unit

Model 167

- i** • Ensure use of **XENTRY Diagnosis version 09/2021** or higher.
- Before starting the work procedure, install the **current version of all add-ons** in **XENTRY Diagnosis**.
- Make sure to follow the operation steps exactly as described in XENTRY Diagnosis.
- Use a battery charger to ensure sufficient power supply of the vehicle **on-board electrical system battery** (greater than 12.5 V).
- If XENTRY Diagnosis is already connected to the vehicle, start with **operation step 2**.
 - i** If two or more software updates or SCN codings are performed during one workshop visit, the operation items 02-4762 and 02-5058 may only be invoiced **once for each workshop order**.

Work procedure

1. Connect XENTRY Diagnosis.
2. Perform SCN coding in the **active suspension and damping system** control unit.
 - i** To do this, select menu item "Quick test view - N51/8 Active suspension and damping system (Active suspension) - Adaptations - Control unit update - Updating of SCN coding".
 - i** Then follow the user guidance in XENTRY Diagnosis.
3. Disconnect XENTRY Diagnosis.

Operation text and flat rate

Operation no.	Operation text	Flat rate	Accounting no./ damage code
02-9446	Perform SCN coding in the active suspension and damping system control unit (with XENTRY Diagnosis connected)	0.1 h	54 922 12
02-4762*	Connect/disconnect diagnostic system (XENTRY Diagnosis)	0.1 h	54 922 12
02-5058*	Connect/disconnect starter battery charger (with XENTRY Diagnosis connected)	0.1 h	54 922 12

* Operation item may only be invoiced once for each workshop order!

Mercedes-Benz
Global Service & Parts