

WORK DESCRIPTION FOR FIELD MEASURE

Code: 21P5892207

Version: 2.0

Update Digital Operator's Manual

Model 167

Work procedure

- i** • Ensure use of **XENTRY Diagnosis version 12/2021** or higher.
- Before starting the work procedure, install all the **add-ons that are updated daily** in **XENTRY Diagnosis**.
- Make sure to follow the operation steps exactly as described in XENTRY Diagnosis.
- Use a battery charger to ensure sufficient power supply of the vehicle **on-board electrical system battery** (greater than 12.5 V).
- If XENTRY Diagnosis is already connected to the vehicle, start with **operation step 2**.
 - i** If two or more software updates or SCN codings are performed during one workshop visit, the operation items 02-4762 and 02-5058 may only be invoiced **once for each workshop order**.

1. Connect XENTRY Diagnosis.

2. Update Digital Operator's Manual.

i To do so, select menu item "Quick test view – A26/17 MBUX multimedia system (Head unit) – Adaptations – Control unit update – Updating of control unit software".

i Then follow the user guidance in XENTRY Diagnosis.

i The Digital Operator's Manuals are automatically downloaded via the Retail Data Storage to XENTRY Diagnosis matched to the affected vehicle.

3. Disconnect XENTRY Diagnosis.

Operation text and flat rate

Operation no.	Operation text	Flat rate	Accounting no./ damage code
02-9445	Update Digital Operator's Manual (with XENTRY Diagnosis connected)	0.1 h	58 922 07
02-4762*	Connect/disconnect diagnostic system (XENTRY Diagnosis)	0.1 h	58 922 07
02-5058*	Connect/disconnect starter battery charger (with XENTRY Diagnosis connected)	0.1 h	58 922 07

* Operation item may only be invoiced once for each workshop order!

Mercedes-Benz
Global Service & Parts