

# WORK DESCRIPTION FOR FIELD MEASURE

Code: 23P5499318

Version: 2.0

## Update ESP control unit software

Model 297

- i** • Always use the **latest** XENTRY Diagnosis software release with all available add-ons.
  - Make sure to follow the operation steps exactly as described in XENTRY Diagnosis.
  - Use a charger to ensure sufficient power supply of the **12 V on-board electrical system battery** (greater than 12.5 V).
  - If the charger and XENTRY Diagnosis are already connected to the vehicle, start with **operation step 2**.
- i** If two or more software updates or SCN codings are performed during one workshop visit, operation items 02-4762 and 02-5058 may be invoiced **only once for each workshop order**.

### Work procedure

1. Connect XENTRY Diagnosis.
2. Update ESP control unit software.
  - i** To do this, select menu item "Quick test view → **N30/3 – Electronic Stability Program (ESP®)** → Adaptations → Control unit update → Update of control unit software".
  - i** Then follow the user guidance in XENTRY Diagnosis.
3. Disconnect XENTRY Diagnosis.

### Operation text and flat rate

Operation no.	Operation text	Flat rate	Accounting no./ damage code
02-9334	Update <b>N30/3 – Electronic Stability Program (ESP®)</b> control unit software (with XENTRY Diagnosis connected)	0.1 h	54 993 18
02-4762*	Connect/disconnect diagnostic system (XENTRY Diagnosis)	0.1 h	54 993 18
02-5058*	Connect/disconnect starter battery charger (with XENTRY Diagnosis connected)	0.1 h	54 993 18

\* Operation item may be invoiced only once for each workshop order.

Mercedes-Benz  
Global Service & Parts