

WORK DESCRIPTION FOR FIELD MEASURE

Code: 24P5499114

Version: 2.0

Update left and right rear seat control unit software

Model 167

- i** • Always use the **latest** XENTRY Diagnosis software release with all available add-ons.
- Make sure to follow the operation steps exactly as described in XENTRY Diagnosis.
- Use a battery charger to ensure sufficient power supply of the vehicle **on-board electrical system battery** (greater than 12.5 V).
- If XENTRY Diagnosis is already connected to the vehicle, start with **Work Procedure Step 2**.
- i** If two or more software updates or SCN codings are performed during one workshop visit, operation items 02-4762 and 02-5058 may be invoiced **only once for each workshop order**.

Work procedure

1. Connect XENTRY Diagnosis.
2. Update **left rear seat** control unit software.
 - i** To do this, select menu item "Quick test view – **N32/5 – Left rear electrical seat adjustment – Adaptations – Update of control unit software**".
 - i** Then follow the user guidance in XENTRY Diagnosis.
3. Update **right rear seat** control unit software.
 - i** To do this, select menu item "Quick test view – **N32/6 – Right rear electrical seat adjustment – Adaptations – Update of control unit software**".
 - i** Then follow the user guidance in XENTRY Diagnosis.
4. Disconnect XENTRY Diagnosis.

Operation text and flat rate

Operation no.	Operation text	Flat rate	Accounting no./ damage code
02-9334*	Update rear seat control unit software (with XENTRY Diagnosis connected)	0.1 h	54 991 14
02-4762**	Connect/disconnect diagnostic system (XENTRY Diagnosis)	0.1 h	54 991 14
02-5058**	Connect/disconnect starter battery charger (with XENTRY Diagnosis connected)	0.1 h	54 991 14

* The operation item must be repeated as often as necessary. Please manually enter the affected control unit in the workshop order.

** The operation item may be invoiced only once for each workshop order.