

15. Tighten the five bolts evenly by tightening every other bolt until all the bolts are tight.
Observe a tightening torque of 110 Nm (80 lb-ft).
16. Correct tire pressure.

Important!

Retighten wheel mounting bolts after approx. 800 km (500 miles).
Observe a tightening torque of 110 Nm (80 lb-ft).

Tire Inflation Pressure

A table (see fuel filler flap or last page) lists the tire inflation pressures specified for summer and winter tires as well as for the varying operating conditions.

Important!

Tire pressure differs by approx. 0.1 bar (1.5 psi) per 10 °C (18 °F) of air temperature change. Keep this in mind when checking tire pressure inside a garage – especially in the winter.

Example:

If garage temperature =
approx. +20 °C (+68 °F)
and, ambient temperature =
approx. 0 °C (+32 °F)
then the adjusted air pressure =
specified air pressure + 0.2 bar
(+3 psi).

Tire pressures listed for light loads are minimum values offering high driving comfort. Increased inflation pressures for heavy loads produce favorable handling characteristics with lighter loads and are perfectly permissible. The ride of the vehicle, however, will become somewhat harder.

Tire temperature and pressure increase with the vehicle speed. Tire pressure should therefore only be corrected on cold tires. Correct tire pressure in hot tires only if pressure has dropped below the pressure listed in the table and the respective operating conditions are taken into consideration.

