Mercedes-Benz Maintenance System — Passenger Cars

REGULAR MAINTENANCE INSPECTION — Every 12,500 Miles



All 1979 Models (With additional work at 37,500)

Mercedes-Benz
service

Customer:	Work Order No.:					
Address:	License No.:					
City & State:	Mileage:					
Zip Code or Province:	Time Promised:					
Maintenance Work to be Performed: ☐ MB Maintenance Service with oil change and oil filter service. ☐ Oil: Brand-Viscosity	Special Maintenance Work Performed at Extra Cost: Sliding Roof: Clean guide channels and lubricate lightly. Lighting System: Check headlights and aim. Battery: Clean housing and terminals; grease terminals lightly. Paint finish and chrome care. Clean Engine and Engine Compartment: lubricate all control linkages. Special Instructions from Customer:					
Visual Inspection: Check For Leakage and General C □ Engine □ Rear Axle □ Steering □ Brakes □ Transmission □ Shock Absorbers Result:	☐ Front Axle☐ Undercarriage☐ Body Condition☐ Exhaust System					
Section I: Lubrication Se	rvice with Oil Filter Change					
Oil Change Oil Change 151 Engine oil with filter change.	OCO					

(continued)

Section I: Lubrication Service with Oil Filter Change

240D-300D-300CD- 300TD-300SD 280E-280CE 280 SE 450-All 6.9	Check Fluid Level and Replenish (Check for leakage).	240D-300D-300CD- 300TD-300SD 280E-280CE 280 SE 450-AII	Body and Chassis Lubrication
	120 Automatic transmission.		350 Door hinges.
	121 Manual transmission (240 D only).		393 Door locks and hinges.
	139 Hydropneumatic suspension.		395 Hood.
	130 Rear axle.		375 Outside rear view mirror.
	134 Power steering.		{ 415 Engine control linkages, control
	465 Windshield washer system.		813 shafts and cables (not required on
	484 Air conditioning.		control shafts with plastic bearings).
	700 Brake system.		Use only the following factory-recom-
	821 Battery.		mended hydraulic oils: BP Hydraulic 1:
	990 Radiator.		Castrol DB Hydraulic Fluid; Ésso Univers J-43; Mobile Aero HFA; Shell Aero
	Lubricate 300TD Rear door hinges and bearings for Gas pressure springs with oil can.		Fluid 4.

Section II: Electronic Engine Test and Engine Maintenance

240D-300D-300CD-300TD-300TD-300TD-300TD-300SD 280E-280CE 280 SE 450-All		240D-300D-300CD-300TD-300SD 280E-280CE 280 SE 450-All 6.9	
	Mechanical		
	753 Adjust valve clearances.		787 Check start of delivery.*
	202 Clean Filter element; replace every 37,500 miles.		813 Throttle control linkage: check for ease of movement.
	762 Clean flame arrester.		832 Analyze engine with oscilloscope.
	757.01		797 Check and adjust manual idle speed adjuster.
	757 Check all drive belt tension and condition.		798 Check and adjust basic idle speed
	785 Exhaust manifold heater flap. Check		plus CO emission for gasolinė engines.
	for free movement and free up as required.		895 Check alternator fastening bolt for tightness.
	770 Replace spark plugs.		~
	772 Check ignition timing and ignition change-over.	*Once only after 1	2,500 miles

Section III: Safety Check

240D-300D-300CD- 300TD-300SD	280E-280CE 280 SE 450-All 6.9		240D-300D-300CD- 300TD-300SD	280E-280CE	450.All	6.9	!	Reti Reta	ghtening aining Par	of Nuts, Bo	olts, and	
		025 Steering system: check play at steering wheel, in shaft coupling and in ball joints of tie rods and drag link. Check rubber boots for leak tightness.) [] [] [9	924 : 988 \	Steering ge Wheel bolt Check fund	ear mounting s.		
		983 Wheels: remove and reinstall. Check wheel disc for condition. Check inner rim for dirt accumulation.						-	stor Dire war	o lights. ectional signa ning lights. idshield wipe	als: Hazard	
		982 Tires: check tire tread wear and other tire damage.						_	wine	dshield wash iting and ven	ier.	
		987 Correct tire air pressure. 712 Check disc brakes (includes items 703, 707, 708, 709.) Measure brake disc thickness. Brake calipers: check for leaks and free movement of pistons (703). Brake pads: remove, clean, check, replace if required (707). Brake discs: check condition, clean cooling fins (708). Brake discs (solid): check condition, clean (709).					(- - - 097 (Road test of Clut Mar Auto Air of Brake test	or dynamome	eter ssion. mission. d/road. on	
		009 Parking brake: check brake cable action.					*	Γire	tread dept	h and brake	performanc	е
		706 Parking brake: re-adjust.028 Front axle ball joints: check for developed play and rubber boots for leak tightness.					ron	t—L	eft KP	Fron	t-Right	
						R	Rear	—L∈	eft	Rea	ır—Right	
						11	۷		KP	IN.	KP	
240D-300D-300CD-	Maintenance Additional Maintenance Work to be Performed Every 37,500 Miles Maintenance Additional Maintenance Work to be Performed Every 37,500 Miles October 3000 3000 3000 3000 3000 3000 3000 30											
240D 300T	280E-28 280 SE 450-AII 6.9	Oil Change	240E 300T	280E-28	450-All	6.9						
	0000	170 Automatic transmission oil change. Filter Replacement or Cleaning] [uel pre-filte heck throt	er: check tle control lir	ıkage.	
		 174 Automatic transmission: replace filter element. 202 Air filter element: replace. 847 Fuel filter: replace filter 845 Fuel main filter: Replace filter element and filter housing. 			ם כ]	38	88 Fi re 81 R	fill with ne	nt wheel bear		

Date _

(continued)		(continu	ued) Maintenance	: Additional Mainten Every 37,500 Miles	ance Work to be Performed ::
240D-300D-300CD- 300TD-300SD	280E-280CE, 280 SE	450-AII 6.9	Tightoning of Nuts and P	olto	
			Tightening of Nuts and B 871 Intake and exhaust mar	ifold nuts	
]	and exhaust flange bolt Exhaust pipe flange on		
			876 Carburetor mounting fla	ange screws.	
			Checking		
			501 Check clutch lining thic (manual transmission o (240 D only).		
			625 Check front wheel toe-i	n.	
			030 Check propeller shaft jo for wear or damage.	oint discs	
			628 Check pressure reserve hydropneumatic spring		

767 Replace catalyst, Engine M110

if required.

at 37.500 miles (California version only) and sometime after 50,000 miles,

Service Manager (Signature) ___